

# Operating instructions Washer-dryer



To avoid the risk of accidents or damage to the appliance, it is **essential** to read these instructions before it is installed and used for the first time.

en-AU, NZ M.-Nr. 11 976 031

Caring for the environment			
Warning and Safety instructions	7		
Operating the washer-dryer	17		
Control panel	17		
Touch display and sensors	17		
Main menu	18		
Examples of how to operate the appliance	19		
Applications	21		
Before the first use	22		
Miele@home	23		
1. Setting the language	24		
2. Setting up Miele@home	24		
3. Setting the clock format	25		
4. Removing the transit bars	25		
5. Setting up TwinDos	26		
6. Starting the calibration programme	29		
Environmentally friendly washing and drying	30		
Washing	31		
1. Preparing the laundry	31		
2. Selecting a programme	32		
3. Selecting programme settings	33		
4. Loading the drum	35		
5. Adding detergent	36		
Replacing detergent cartridges	36		
6. Starting the programme	42		
7. End of the programme/unloading laundry	43		
Spin cycle	43		
Programme chart	45		
Programme sequence	51		
Extras	54		
Detergent	56		
Water softeners	56		
Fabric softeners, liquid starch, starch	56		
Colour run and dye removers/dyes	57		
Drying	60		
1. Preparing the laundry	60		
2. Selecting a programme	61		
3. Selecting programme settings	62		

4. Loading the drum	63
5. Starting the programme	63
6. End of the programme/unloading laundry	64
Programme chart	65
Timed drying	70
Thermospin	71
Extras	71
Washing and Drying	72
1. Preparing the laundry	72
2. Selecting a programme	72
3. Loading the drum	72
4. Selecting programme settings	73
5. Adding detergent	73
6. Starting/Ending the programme	73
After each washing or drying programme	74
7 ttor oddir Wdorning or drying programmo	
Changing the programme sequence	75
Changing the programme (safety lock)	75
Cancelling a programme	75
Interrupting a programme	75
Forestrite pregrammes	76
Favourite programmes	76
Creating a favourite programme	76
Washing/Drying assistant	77
Timer/SmartStart	78
Cleaning and care	80
Starting maintenance programmes	80
Clean "TwinDos"	80
Clean machine	81
Rinse out fluff	81
Cleaning the external casing and fascia panel	82
Cleaning the detergent dispenser drawer	82
Cleaning the water inlet filter	84
Problem solving guide	85
A programme cannot be started	85
Fault messages after a programme has been cancelled	86
Fault messages at the end of a programme	87
Problems with TwinDos	89
Problems with TwinDos	90

General problems with the washer-dryer  An unsatisfactory wash result  Unsatisfactory drying result.	91 94 95 96
The door will not open  Opening the door in the event of a blocked drain outlet and/or power cut	96
ServiceContact in case of fault	99 99
Warranty	99
Optional accessories	99
Installation	
Front view	
Rear view	
Installation surface	
Removing the transit bars	
Refitting the transit bars	
Levelling the washer-dryer	
The Miele water protection system	
Water intake	107
Drainage	
Electrical connection	109
Technical data	110
Consumption data	111
Garment care label symbols	112
Settings	113
Controls / Display	
Language -	114
Code	
Memory	
Clock display	
Volume	
Display brightness	
Temperature unit	115

Programme sequence	115
TwinDos	115
Soiling	116
Water plus level	116
Maximum rinse level	116
Soak duration	116
Longer pre-wash Cottons	117
Gentle action	
Comp laundry protection	117
Drying levels	117
Extended cool down	
Network	118
Miele@home	118
Remote control	119
SmartGrid	119
Remote Update	119
Appliance parameters	121
Copyright and licences for operating and control software	121
Copyright and licences for the communication module	
Installation requirements	122
Low water pressure	122
Suds cooling	122
Temperature reduction	122
Detergents and care products	122
Detergent	
Sensitive Skin (powder detergent)	
Specialist detergents	
Fabric care \$\tag{\pi}	
Additive 2	
Machine care products	
Machine Care products	120

# Caring for the environment

# Disposal of the packing material

The transport and protective packaging has been selected from materials which are environmentally friendly for disposal, and can normally be recycled.

Recycling the packaging reduces the use of raw materials in the manufacturing process and also reduces the amount of waste in landfill sites. Ensure that any plastic wrappings, bags etc. are disposed of safely and kept out of the reach of babies and young children. Danger of suffocation.

# Disposing of your old appliance

Electrical and electronic appliances often contain valuable materials. They also contain specific materials, compounds and components, which were essential for their correct function and safety. These could be hazardous to human health and to the environment if disposed of with your domestic waste or if handled incorrectly. Please do not, therefore, dispose of your old appliance with your household waste.



Please dispose of it at your local community waste collection / recycling centre for electrical and electronic appliances. You are also responsible for deleting any personal data that may be stored on the appliance prior to disposal. Please ensure that your old appliance poses no risk to children while being stored prior to disposal.



It is essential to read these instructions.

This washer-dryer complies with all current local and national safety requirements. However, inappropriate use can lead to personal injury and damage to property.

Read the operating instructions carefully before using the washerdryer. They contain important information on safety, installation, use and maintenance of the appliance. This prevents both personal injury and damage to the washer-dryer.

In accordance with standard IEC 60335-1, Miele expressly and strongly advises that you read and follow the instructions in "Installation", as well as in the "Warning and Safety instructions".

Miele cannot be held liable for injury or damage caused by noncompliance with these instructions.

Keep these operating instructions in a safe place and pass them on to any future owner.

# **Correct application**

- This washer-dryer is intended for use in domestic households and similar residential environments, by guests in hotel or motel rooms, bed & breakfasts and other typical living quarters. This does not include common/shared facilities or commercial facilities within hotels, motels or bed & breakfasts.
- This washer-dryer is intended for the following applications only:
- washing textiles which have a care label stating that they are washable
- drying textiles which have been washed in water and have a care label stating that they are suitable for tumble drying.

All other types of use are not permitted. Miele cannot be held liable for damage resulting from incorrect or improper use or operation.

- The washer-dryer is not intended for outdoor use.
- ► This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning its use by a person responsible for their safety.

# Safety with children

- ➤ Young children must be kept away from the washer-dryer unless they are constantly supervised.
- ▶ Older children may only use the washer-dryer unsupervised if they have been shown how to use it safely. Children must be able to understand and recognise the possible dangers caused by incorrect operation.
- ► Children must not be allowed to clean or maintain the washerdryer unsupervised.
- Please supervise young children in the vicinity of the washerdryer. Never allow children to play with the appliance.

# **Technical safety**

- ▶ Before installation check the washer-dryer for visible signs of damage. Do not install or use a damaged appliance.
- ▶ Before connecting the appliance, make sure that the connection data on the data plate (voltage, frequency, and connected load) match the mains electricity supply. If in doubt, consult a qualified electrician.
- The electrical safety of this appliance can only be guaranteed when continuity is complete between it and an effective earthing system which complies with current local and national safety regulations.

It is essential that this standard safety requirement is observed and regularly tested. If in any doubt, have the electrical installation inspected by a qualified electrician.

Miele cannot be held liable for the consequences of an inadequate earthing system (e.g. electric shock).

- Do not connect the washer-dryer to the mains electricity supply by a multi-socket adapter, extension lead or similar. These do not guarantee the required safety of the machine (fire hazard due to the risk of overheating).
- ▶ Unauthorised repairs could result in unforeseen dangers for the user, for which the manufacturer cannot accept liability. Repairs should only be carried out by a Miele authorised service technician, otherwise any subsequent damage will not be covered by the warranty.
- Please observe the instructions in "Installation" and "Technical data".

- This washer-dryer is supplied with a special lamp to cope with particular conditions (e.g. temperature, moisture, chemical resistance, abrasion resistance and vibration). This lamp must only be used for the purpose for which it is intended. The lamp is not suitable for room lighting. Replacement lamps may only be fitted by a qualified electrician or a Miele authorised technician.
- The electrical plug must be easily accessible after installation so that the washer-dryer can be disconnected from the electricity supply if necessary.
- ► In the event of a fault or for cleaning purposes, the washer-dryer must be disconnected from the mains electricity supply. It is only completely isolated from the electricity supply when:
  - switched off at the wall socket and the power plug is withdrawn from the socket
  - the mains circuit breaker has been switched off, or
  - the screw-out fuse is removed (in countries where this is applicable).
- ► The Miele water protection system protects from water damage provided the following conditions are met:
  - The machine is correctly plumbed in and connected to the electricity supply.
  - If a fault or damage has been identified, the washer-dryer must be repaired by a competent person before further use.
- ► The machine must only be connected to the on-site water supply using a new hose kit. Old hose kits must not be re-used. Check the condition of the hoses regularly so that you can replace them in good time and avoid the risk of any water damage.
- The water inlet pressure must be at least 100 kPa and must not exceed 1000 kPa.

- ► Faulty components must only be replaced by Miele original spare parts. Miele can only guarantee the safety standards of the appliance when Miele replacement parts are used.
- ▶ If the connection cable is faulty, it must only be replaced by a Miele authorised service technician to protect the user from danger.
- This washer-dryer must not be operated in mobile installations (e.g. on a ship).
- Do not make any alterations to the washer-dryer, unless authorised to do so by Miele.
- ► Temporary or permanent operation with a self-sufficient or non-mains synchronous energy supply system (e.g. isolated networks, back-up systems) is possible. A requirement for the operation is that the energy supply system complies with all current local and national requirements that apply to stand-alone, solar and/or battery systems.

The protective measures provided in the installation and in this Miele product must also be assured in their function and operation in isolated operation or in non-mains synchronous operation, or replaced with equivalent measures in the installation.

- The manufacturer's warranty will be invalidated if the washer-dryer is not repaired by a service technician authorised by Miele.
- ▶ In areas which may be subject to infestation by cockroaches or other vermin, pay particular attention to keeping the machine and its surroundings in a clean condition at all times. Any damage which may be caused by cockroaches or other vermin will not be covered by the machine warranty.

#### **Correct use**



READ THE INSTRUCTIONS

Warning: Risk of fire / Flammable materials. To avoid the possible danger of fire, please read these warnings carefully.

- Do not install the washer-dryer in rooms that are subject to frost. Frozen hoses may burst or split, and the reliability of the electronic control unit may be impaired at temperatures below freezing point.
- ▶ Before using the machine for the first time, check that the transit bars at the rear of the appliance have been removed (see "Installation Removing the transit bars"). During the spin cycle, a transit bar which is still in place may result in damage to the washerdryer and adjacent furniture or appliances.
- Turn off the tap if the washer-dryer is to be left for a longer period of time (e.g. while on holiday), especially if there is no floor drain (gully) in the immediate vicinity.
- ▶ Danger of flooding! If hooking the drain hose into a wash basin, check that the water can drain away fast enough to prevent the sink from overflowing. Secure the drain hose against slipping. The force of the water flowing out of the hose can dislodge it.
- ► Make sure that no foreign objects (e.g. nails, pins, coins, paper clips) find their way into the machine with the laundry. These may damage components of the machine (e.g. suds container, drum). Damaged components can, in turn, result in damage to the laundry.
- ► Take care to remove any detergent dispensing aids (e.g. detergent balls) before drying the laundry. These can melt during the drying programme and cause damage to the machine and the laundry.

- ► Risk of burning or scalding due to hot temperatures. The metal cap located on the inside of the door glass will be hot after drying. Open the door wide after drying. Do not touch the metal cap.
- ► Fabric softener and similar products must be used according to the instructions on the manufacturer's packaging.
- ▶ If the correct amount of detergent is dispensed, the washer-dryer should not need to be descaled. If, however, you do wish to descale your washer-dryer, only use special non-corrosive descaling agents. These are available from Miele. Strictly observe the instructions on the packaging.
- ▶ Be careful when opening the door following use of the steam function. There is a danger of burning due to escaping steam and the high temperature of the surface of the drum as well as the porthole glass. Stand back away from the machine and wait until the steam has dissipated.
- To prevent the risk of fire, the following textiles must **not** be dried in this washer-dryer:
  - Items which have not been washed.
  - Items, such as workwear, which have not been thoroughly cleaned and are still soiled with grease, oil or other deposits (such as cooking oils, cosmetics, lotions etc). If items have not been thoroughly cleaned, there is a danger that they might ignite when heated, even after they have been removed from the dryer at the end of the programme.
  - Items that have been soiled with flammable substances such as cooking oil, acetone, petrol, kerosene, spot removers, turpentine, waxes, wax removers and other chemicals (e.g. mops and floor cloths).
  - Items which have been splashed with hair lacquer, hair spray, nail varnish remover or similar substances.

When washing such heavily soiled items ensure that you use sufficient detergent and select a high temperature. If in doubt, wash the items several times.

- To prevent the risk of fire, the following textiles must never be dried in this washer-dryer:
  - Items which have been cleaned using chemicals (e.g. professional dry-cleaning agents).
  - Fabrics which contain a large proportion of rubber, foam rubber or rubber-like materials. For example, products made from latex foam rubber, shower caps, waterproof textiles, rubberised articles and items of clothing and pillows with foam rubber filling.
  - Fabrics which contain padding or fillings (e.g. pillows, jackets). If these were damaged the filling could come out with the risk of igniting in the dryer.
- ▶ Only use dyes specified by the manufacturer as being suitable for use in a domestic washer-dryer, and only use them in domestic quantities. Always observe the manufacturer's instructions carefully.
- Dye removers contain sulphur compounds which can cause damage such as corrosion. Do not use dye removers in this washerdryer.
- ▶ In many programmes, the heating phase is followed by a cooling down phase to ensure that the items are not too hot to handle when you remove them (this also reduces the risk of the laundry selfigniting). The programme is not finished until after the cooling down phase. It is advisable to remove all laundry as soon as the programme has finished.
- Do not switch the washer-dryer off before the end of the drying programme, unless all items are removed immediately and spread out to cool down.
- This washer-dryer must not be connected to a controllable socket, e.g. a timer or a peak-load switch-off device. There is a risk of the laundry igniting itself if a drying programme is cancelled before the cooling phase has finished.


- Fabrics that have been pre-treated in solvent-based cleaning agents must be thoroughly rinsed in clean water before being placed in the machine.
- Never use solvent based cleaning agents (e.g. one containing benzine) in this washer-dryer. This may result in damage to component parts and create toxic fumes. Risk of fire and explosion!
- ▶ If detergent has come into contact with the eyes, rinse out immediately with plenty of lukewarm water. If detergent has accidentally been ingested seek medical advice immediately. People with damaged or sensitive skin should avoid contact with the detergent.
- ► The maximum dry laundry weight is 9.0 kg for washing and 5.0 kg for drying. See the "Programme chart" for the maximum recommended loads for individual programmes.
- Fluff must not be allowed to accumulate in and around the tumble dryer.
- ▶ Oil-affected items can ignite spontaneously, especially when exposed to heat sources such as in a tumble dryer. The items become warm, causing an oxidation reaction in the oil. Oxidation creates heat. If the heat cannot escape, the items can become hot enough to catch fire. Piling, stacking or storing oil-affected items can prevent heat from escaping and so create a fire hazard.
- ▶ If it is unavoidable that fabrics contaminated with vegetable or cooking oil, or hair care products, are placed in a tumble dryer, they should first be washed in hot water with extra detergent this will reduce, but not eliminate, the hazard.
- Remove all items from pockets (e.g. lighters, matches).

## **Accessories**

- ► Only use original Miele accessories. If other parts are used, warranty, performance and product liability claims will be invalidated.
- Miele will guarantee to supply functional spare parts for a minimum of 10 years and up to 15 years following the discontinuation of your washer-dryer.

Miele cannot be held liable for damage caused by non-compliance with these Warning and Safety instructions.

# **Control panel**



① Sensor

Takes you back one level in the menu.

- 2 Touch display
- ③ Start/Stop sensor

Touching the *Start/Stop* sensor starts the selected programme or cancels a programme that has already started. The programme can be started as soon as the sensor is flashing on and off. The sensor lights up constantly once the programme has started.

Optical interface

 Targer via a tacknisis

For service technicians.

5 ( sensor

For switching the washer-dryer on and off. The washer-dryer switches off automatically to save energy. It is switched off 15 minutes after the end of the programme/Anti-crease phase, or after being switched on if no further selection is made.

# **Touch display and sensors**

The  $\hookrightarrow$  and Start/Stop sensors and the sensors in the display react to fingertip contact.

The touch display can be scratched by pointed or sharp objects, e.g. pens. Only touch the display with your fingers.

#### Main menu

After switching on the washer-dryer, the main menu will appear in the display.

You can access all important submenus from the main menu.

Touch the ☐ sensor at any time to return to the main menu. Values that have not yet been confirmed are not saved when you return to the main menu.



You can scroll to the next page of the main menu by swiping your finger across the display.



or



#### **Washing**

You can select various wash programmes.

# Drying

You can select various drying programmes.

# Washing + Drying

You can select programmes which include a continuous washing and drying sequence.

#### ☆ Favourites

You can save up to 12 of your own customised wash programmes (see "Favourite programmes").

# MobileStart

You can operate your washer-dryer remotely with MobileStart using the Miele App.

The Remote control setting must be switched on.

Touch the MobileStart sensor and follow the instructions in the display.

#### Washing/Drying assistant

The Washing and Drying assistant guides you step by step so that you can select the optimum wash programme and drying programme for your laundry (see "Washing and Drying assistant").

#### Maintenance

Maintenance options for the TwinDos system and the Rinse out fluff and Clean machine programmes are located in the Maintenance menu (see "Cleaning and care").


## ♦ Settings

You can alter the washer-dryer's electronics to suit different requirements in the Settings menu (see "Settings").

# Examples of how to operate the appliance

#### Selection lists

Washing menu (single selection)



You can scroll to the right or the left by swiping your finger across the screen. Place your finger on the touch display and swipe it in the direction you want.

The orange bar under the pictures shows that there are further options to choose from.

To select a wash programme, touch a programme name.

The display will change to the standard display for that programme.

#### Extras menu (multiple selection)



You can scroll to the right or the left by swiping your finger across the screen. Place your finger on the touch display and swipe it in the direction you want.

The orange bar under the pictures shows that there are further options to choose from.

To select *Extras*, touch one or more sensors with *Extras*.


Currently selected *Extras* are marked orange.

To deselect an *Extra*, simply touch the *Extra* sensor again.

Use the *OK* sensor to activate the selected *Extras*.

#### **Setting numerical values**

You can set numerical values in some menus.



Enter the numbers by swiping upwards or downwards. Place your finger on the number that you want to change and move your finger in the desired direction. Use the *OK* sensor to accept the set numerical value.

**Useful tip:** Briefly touching the numbers will bring up the numerical keypad. Once a valid number has been entered, the *OK* sensor will be highlighted green.

#### Pull-down menu

The pull-down menu can be used to display information, e.g. about a wash programme.



Touch the top edge of the screen in the middle and drag down with your finger.

#### Help display

Help appears along the bottom line of the display in the main menu and the programme selection menus.

- Touch the Help sensor to display the text.
- Touch the Close sensor to return to the previous screen.

## Exiting a menu

■ Touch the sensor to return to the previous screen.

Entries made before this which have not been confirmed with *OK* will not be saved.

## **Applications**

You can use this washer-dryer to:

- wash separately
   Maximum load (depending on programme) 9.0 kg.
- dry separately
   Maximum load (depending on programme) 5.0 kg.

or

wash and dry in a continuous sequence

Maximum load (depending on programme) 5.0 kg.

Damage resulting from incorrect installation and connection.

Installing and connecting the washer-dryer incorrectly will cause serious property damage.

Please observe the instructions in "Installation".

This washer-dryer has undergone a complete functional test at the factory and there will be some residual water in the drum from this process.


# Removing the protective foil and advertising stickers

- Remove:
- the protective foil from the door (if present).
- any advertising stickers from the front and the lid.


Please do not remove any labels (e.g. the data plate) which are visible when you open the door.

# Remove the detergent cartridges and the drain hose elbow from the drum

Two detergent cartridges for automatic detergent dispensing and an elbow piece for the drain hose are stored in the drum.



- Reach under the door grip and pull the door open.
- Take the two cartridges and the elbow piece out of the drum.



■ Shut the door with a gentle swing.

#### Miele@home

Your washer-dryer is equipped with an integrated Wi-Fi module.

To use this feature, you will need:

- a Wi-Fi network
- the Miele App
- a Miele user account. The user account can be created via the Miele App.

The Miele App will guide you as you connect your washer-dryer to your home Wi-Fi network.

Once your washer-dryer is connected to your Wi-Fi network, you can use the App to carry out the following activities, for example:

- Controlling your washer-dryer remotely
- Calling up information on the operating status of your washer-dryer
- Calling up information on the programme sequence of your washer-dryer

Connecting your washer-dryer to your Wi-Fi network will increase energy consumption, even when the washer-dryer is switched off.

Make sure there is sufficient signal strength for your Wi-Fi network at the washer-dryer installation site.

#### Availability of the Wi-Fi connection

The Wi-Fi connection shares a frequency range with other appliances (including microwave ovens and remote control toys). This may result in sporadic or even complete connection failures. Therefore, a constant availability of featured functions cannot be guaranteed.

#### Miele@home availability

The ability to use the Miele App depends on the availability of the Miele@home service in your country.

The Miele@home service is not available in every country.

For information about availability, please visit www.miele.com.

#### Miele App

You can download the Miele App from the Apple App Store<sup>®</sup> or the Google Play Store<sup>™</sup> free of charge (only functional in selected countries).



# Switching the washer-dryer on

■ Press the sensor.

The welcome screen will light up.

The display will guide you through the **6 steps** of the initial commissioning process.

## 1. Setting the language

You will be asked to select the language for the display. It is possible to change the language at any time via the Settings menu.



- Scroll to the left or the right until the language you want appears.
- Touch the sensor for the required language.

The selected language will be highlighted in orange and the display will change to the next setting.

# 2. Setting up Miele@home



■ To set up Miele@home now: touch the Continue sensor.

**Useful tip:** To postpone set-up until later: touch the Skip sensor. The following message will appear in the display:

it is possible to set up later in "Settings" / "Miele@home"..

Confirm with the OK sensor.

# Selecting a connection method



Select the connection method you wish to use.

You will then be guided by the display and the Miele App.

# 3. Setting the clock format


The time of day display can be in 12 h or 24 h clock format.

■ Select the clock format you want and confirm this with the *OK* sensor.

The display will then bring up the screen for setting the time of day.

#### Setting the time of day

This message only appears if the washer-dryer has not yet been connected to a Wi-Fi network. The time of day is set automatically if connection is established with a Wi-Fi network.



- Place your finger on the number that you want to change and move your finger in the desired direction.
- Confirm with the OK sensor

# 4. Removing the transit bars

Damage resulting from failure to remove the transit bars.

Failure to remove the transit bars can result in damage to the washer-dryer and to adjacent cabinetry or appliances.

Remove the transit bars as described in "Installation".

The following message appears in the display:

- Remove transit bars and observe
  "Warning and Safety instructions" and
  "Before using for the first time" in the
  operating instructions
- Confirm that the transit bars have been removed with the *OK* sensor.

The display will change to the next setting.

# 5. Setting up TwinDos



■ Touch the Continue sensor to set up TwinDos straight away.

**Useful tip:** To postpone set-up until later: touch the Skip sensor. The following message will then appear in the display:

it is possible to set up later in "Settings" / "TwinDos".

Confirm with the OK sensor.

## Setting up compartment ①

The procedure below describes the procedure for Miele UltraPhase 1 and Miele UltraPhase 2. The procedure for other detergents is similar.




■ Touch the Miele UltraPhase 1 sensor.

The following message appears in the display:

i Please enter the dosing recommendation of your detergent for a wash with normal soiling. Take note of your water hardness level

The dispensing quantity for UltraPhase 1 is preset for (water hardness level I).




■ Confirm the preset value with the *OK* sensor, or change the value.


UltraPhase 1				
Bo	Hardness level I	46 ml		
B	Hardness level II	58 ml		
B	Hardness level III	70 ml		

The following will appear in the display:


i Insert container 1



■ Remove the foil from the detergent cartridge.



■ Open the access panel for TwinDos.



■ Push the UltraPhase 1 detergent cartridge into compartment 1 until it locks into position.

The following message appears in the display:

i Now enter the settings for UltraPhase 2.

## Setting up compartment ②

The dispensing quantity for UltraPhase 2 is preset for (water hardness level I).




■ Confirm the preset value with the *OK* sensor, or change the value.


UltraPhase 2				
Bo	Hardness level I	36 ml		
B <sub>0</sub>	Hardness level II	45 ml		
B	Hardness level III	54 ml		

The following will appear in the display:

i Insert container 2



Remove the foil from the detergent cartridge.



■ Push the UltraPhase 2 detergent cartridge into compartment 2 until it locks into position.

The following message appears in the display:

- i "TwinDos" is set up. Changes can be made in "Settings" / "TwinDos".
- Confirm with the OK sensor.
- Close the TwinDos access panel.

The display will then change to the calibration programme.

# 6. Starting the calibration programme

It is important to calibrate the washerdryer to ensure optimum water and energy usage, as well as optimum washing and drying results.

To do this, the *Cottons* programme **must** be run <u>without</u> laundry and without detergent.

No other programmes can be started until calibration has been carried out.

The following message appears in the display:

- i Turn on the tap and run the Cottons 90°C programme without any laundry
- Confirm with the OK sensor.

The display will then change to the standard display for the *Cottons* programme.




- Turn on the tap.
- Touch the Start/Stop sensor.

The calibration programme will start. It will take approximately 2 hours.

At the end of the programme the following message will appear in the display:

i Set-up completed



■ Reach under the door grip and pull the door open.

**Useful tip:** For safety reasons, close the door when the machine is not in use. Otherwise there is a danger of objects being placed inadvertently in the drum. If these remain unnoticed and were washed in the next load, they could damage the laundry. An open door is also a danger to pets and children.

Switch the washer-dryer off with the (¹) sensor.

# **Environmentally friendly washing and drying**

# **Energy and water consumption**

- Use the maximum load size for the current programme. The energy and water consumption will then be the lowest in relation to the size of the load.
- Programmes that are more efficient with regard to energy and water consumption generally have a longer programme running time. By extending the programme running time, the wash temperature that is actually reached can be reduced while still providing the same wash results.

For example, the ECO 40-60 programme has a longer running time than the Cottons 40°C or 60°C programme. The ECO 40-60 programme, however, is more efficient in terms of energy and water consumption.

- Use the Express 20 programme for small, lightly soiled loads.
- Modern detergents make it possible to wash at lower temperatures (e.g. 20°C). Using lower temperature settings will save energy.
- To maintain the hygiene of the machine, carry out a hot wash (above 60°C) at regular intervals. The message Hygiene info: Select "Maintenance" and start the "Clean machine" programme. will appear in the display to remind you to carry out a hot wash.


## **Detergent**

- For precise dispensing, use automatic detergent dispensing.
- Adjust the dosage to the degree of soiling of the laundry.
- Do not exceed the amounts of detergent recommended by the manufacturer on the packaging.

# Information about subsequent tumble drying

To save energy when tumble drying, select the highest possible spin speed for the wash programme and for the thermospin.

# 1. Preparing the laundry



■ Empty all pockets.

Damage due to foreign objects. Foreign objects (e.g. nails, coins, paper clips etc.) can cause damage to garments and to components in the machine.

Check the laundry before washing and remove any foreign objects.

# Sorting the laundry

Sort the laundry by colour and by care label. Most garments have a textile care label in the collar or side seam.

**Useful tip:** Dark textiles often contain excess dye and should be washed separately several times before being included in a mixed load. Wash light and dark coloured items separately.

# **Pre-treating stains**

Badly soiled areas and stains should be cleaned as soon as possible, preferably whilst still fresh. Spillages should be carefully dabbed off using a soft, colourfast cloth. Do not rub. **Useful tip:** Stains (e.g. blood, egg, coffee, tea) can be pre-treated using some handy tricks which can be found under the "ABC of Stains" on the Miele website.

Damage due to solvent-based cleaning agents.

Cleaning agents containing benzine, stain remover, etc., can damage plastic parts.

When pre-treating garments, make sure that any plastic parts (e.g. buttons) do not come into contact with cleaning agent.

Risk of explosion due to solvent-based cleaning agents.

If solvent-based cleaning agents are used, an explosive mixture can form. Never use solvent-based cleaning agents in the washer-dryer.

# **General tips**

- Curtains: Remove lead weights first or place in a laundry bag.
- Wash light and coloured items separately.
- Remove or sew in any loose underwiring in bras or shirt collar stiffeners.
- Close any zips, attach velcro fasteners, fasten hooks and eyes etc. before washing.
- Fasten duvet covers and pillow cases to prevent small items from being rolled up inside them.

Do not wash items which are specified by the manufacturer as **not washable** on the care label ( symbol).

# Washing

# 2. Selecting a programme

#### Switching the washer-dryer on

■ Press the 🖰 sensor.

The interior drum lighting will come on.


The drum lighting will go out automatically after a few minutes.

**Useful tip:** To switch the drum lighting on again, open the pull-down menu from the overview menu and then touch the  $\cdot \circ$  sensor.

The main menu will then appear in the display.


#### Selecting a programme

Touch the Washing sensor.



- Scroll to the right of the display until the programme you want appears.
- Touch the sensor for that programme.

The display will then change to the standard menu for the programme.



There are 3 other ways to select a programme:

- Saved favourite programmes
- The Washing/Drying assistant
- Miele MobileStart

# 3. Selecting programme settings

#### Selecting the temperature

You can alter the preset temperature of the wash programme.

The temperatures reached inside the washer-dryer may differ from the selected temperatures. The combination of energy input and washing time achieves an optimum washing result.

- Touch the Temperature sensor.
- Select the desired temperature.

The display will change to the standard menu for that wash programme.

#### Selecting a spin speed

You can alter the preset spin speed of the wash programme.

- Touch the Spin speed sensor.
- Select the desired spin speed.

The display will change to the standard menu for that wash programme.

## **Activating TwinDos**

TwinDos dispensing is automatically activated for all programmes in which dispensing is possible.

#### 1. Switch TwinDos on or off

■ Touch the TwinDos sensor and select Off or On.

# 2. Select the detergent

When using Miele's 2-phase system you must set the colour of the laundry.

 Select Whites for loads of white items, or Colour for loads containing coloured items.

If you are using a different type of detergent, this must be selected.

■ Select compartment ① or ②.

**Useful tip:** Only those detergents that can be used with the programme are displayed.

#### 3. Select the degree of soiling

The display will ask you to enter the degree of soiling of the laundry.

- Select Light, Normal or Heavy.
- Confirm your selection with the OK sensor.

TwinDos is switched on.

The display will change to the standard menu for that wash programme.

See "Washing – 5. Adding detergent – TwinDos" for more information

# Washing

#### Selecting Extras

You can supplement the wash programmes with Extras.

- Touch the Extras sensor.
- Select one or more Extras.

Not all Extras can be combined. Extras that cannot be combined are greyed out and cannot be selected.

■ Confirm with the OK sensor.

The display will change to the standard menu for that wash programme.

See "Washing – Extras" for more information

#### Activating CapDosing

You can use CapDosing with a wash programme.

■ Touch the CapDosing sensor.

The types of capsules which can be used with the programme will appear in the display.

Select the type of capsule you want to use.

CapDosing is now active.

The display will then change to the standard menu for that wash programme.

See "Washing – 5. Adding detergent - CapDosing".

#### Selecting stains

In order to clean stained laundry more effectively, you can choose from a list of various types of stains. The wash programme will then adapt to the type of stain selected.

- Touch the Stains sensor.
- Select the type of stains in your load from the list.
- Confirm your selection with the OK sensor.

With some stains, helpful information will also appear in the display when they are selected.

■ Confirm the information with the *OK* sensor.

The display will then change to the standard menu


## Timer

You can use the Timer to set the finish time or the start time for a programme.

See "Timer/SmartStart" for further information.

# 4. Loading the drum

# Opening the door



■ Reach under the door grip and pull the door open.

Check the drum for pets or foreign objects before loading it with laundry.

Unfold the laundry and load loosely in the drum.


Mixing both large and small items gives better wash results and helps distribute the load evenly during spinning.

The most efficient use of energy and water is achieved when a full load is washed. However, do not overload as this reduces cleaning efficiency and causes creasing.


**Useful tip:** The maximum load size for the programme selected will appear in the pull-down menu.

The percentage of the maximum load size inside the drum and the amount of detergent to dispense if TwinDos is **not** being used are also shown in 25% increments.

#### Closing the door



Make sure that no items are caught between the door and the seal.



■ Shut the door with a gentle swing.

# Washing

# 5. Adding detergent

Detergent can be dispensed via TwinDos (A), via the detergent dispenser drawer (B) or with CapDosing (C).

## **A** TwinDos

The washer-dryer has the TwinDos system.

TwinDos must be activated (see "Before the first use").

# How UltraPhase 1 and UltraPhase 2 work

UltraPhase 1 is a liquid detergent which dissolves dirt and removes the most common stains. UltraPhase 2 is a bleaching agent and removes stubborn stains. For the best washing result, these two agents are dispensed at separate times during the wash process. UltraPhase 1 and UltraPhase 2 clean white and coloured fabrics thoroughly. UltraPhase 1 and UltraPhase 2 single-use cartridges are available from shop.miele.com or from Miele Experience centres.

# **Activating TwinDos dispensing**

TwinDos dispensing is automatically activated for all programmes in which dispensing is possible.

**Useful tip:** The detergent dispensing quantities are preset. If too much foam builds up, the dispensing quantity can be reduced via the ⋄ Settings menu, *Programme sequence*, *TwinDos*.

# Changing TwinDos dispensing

You can change the suggested colour composition of the laundry.

■ Touch the TwinDos sensor and select the colour composition of your laundry.


#### **Deactivating TwinDos dispensing**

- Touch the TwinDos sensor.
- Touch the Off sensor.

#### Replacing detergent cartridges

Make sure the washer-dryer is switched on before replacing the detergent cartridge. This will ensure that the counter is set to 0 and the fill level indicator is correct

■ Switch the washer-dryer on.



1) Press the yellow button above the detergent cartridge.

This releases the locking mechanism.

- ② Remove the empty detergent cartridge.
- Place a new detergent cartridge in the compartment.

#### Selecting the degree of soiling

The level of soiling in laundry is divided into three settings:

- 🖺 Light
  No visible soiling or stains
- Normal
   Visibly soiled and/or just a few slight stains
- Theavy
  Heavily soiled and/or stains clearly visible

The dispensing amount for TwinDos and the amount of water required for rinsing is preset for the Tomal level of soiling.

■ Touch the TwinDos sensor to select a different level of soiling.

The amount of detergent and water will be adjusted to suit the selected level of soiling.

Some programmes will not let you set the level of soiling. These programmes are designed for lightly soiled laundry only.

## Using other methods to remove stains

If you wish to use additional methods of stain removal, you have the following options:

- Using the Booster capsule and activating CapDosing
- Add the stain remover to the UU compartment in the detergent dispenser drawer.

## **B** Detergent dispenser drawer

Any detergent suitable for automatic front loading washing machines can be used with this appliance. Please observe the instructions for use and dosage on the detergent packaging.

Ensure that TwinDos dispensing is deactivated.


Add detergent in accordance with the value in the pull-down menu dosage display.

The percentage shown relates to the amount of detergent recommended by the manufacturer on the packaging.

- 40 % = Add slightly less than half the amount recommended
- 50 % = Add half the amount recommended
- 60 % = Add slightly more than half the amount recommended
- 75 % = Add three quarters of the amount recommended
- 100 % = Add the full amount recommended

Take the hardness level of your water into account.

#### Adding detergent



- Pull out the detergent dispenser drawer and add detergents to the compartments.
  - U Detergent for the pre-wash
  - Detergent for the main wash and soaking
- capsules

#### Using liquid detergent with a prewash


Liquid detergent cannot be used for the main wash if the pre-wash has been selected.

Use powder detergent for the main wash.

### Using detergent tablets or pods

Always put detergent tablets or pods directly in the drum with the laundry. They cannot be added via the detergent dispenser drawer.

#### Adding fabric softener



■ Add the fabric softener or the liquid starch to the 

starch to the 

compartment. Do not exceed the maximum level mark.

This will be automatically dispensed in the final rinse. At the end of the wash programme a small amount of water remains in the  $\otimes$  compartment.

Starch can make the siphon tube sticky. If starching frequently, thoroughly clean the detergent drawer, especially the siphon, regularly.

#### Tips on dosing

Adjust the detergent dosage to the level of soiling of the laundry and the size of the load. Reduce the amount of detergent with smaller load sizes (e.g. reduce the amount of detergent by 1/3 when washing a half load).

#### Too little detergent results in:

- laundry not getting properly clean and with time it may become grey and hard to the touch.
- a possible build-up of mould in the washer-dryer.
- grease not being completely removed from the laundry.
- possible limescale deposits on the heater elements.

#### Too much detergent results in:

- poor wash, rinse, and spin results.
- a higher water consumption as an extra rinse cycle is automatically activated.
- a greater burden on the environment.

See "Washing - Detergent" for further information about detergents and how much to dispense.

## © CapDosing

If you selected CapDosing when setting the programme, detergent will be dispensed via the capsule for this wash programme.

Only one capsule can be selected per wash programme.

Three different types of capsules are available:

- Second Second
- Additives (e.g. detergent enhancers)
- Detergent (for the main wash only)

Each capsule contains the correct amount for one wash cycle.

Caps are available from shop.miele.com, by contacting Miele directly, or at a Miele Experience Centre.


Capsules pose a health risk.

The ingredients of capsules can be hazardous to health if they are swallowed or come into contact with skin.


Keep capsules out of the reach of children.

#### Inserting a capsule


Open the detergent dispenser drawer.



■ Open the lid of the %/\( \square\) compartment.



■ Press the capsule in firmly.



■ Remove the empty capsule at the end of the wash programme.

For technical reasons, a small amount of water will remain in the capsule.

- Close the lid and press it firmly shut.
- Close the detergent dispenser drawer

The capsule is opened by the act of inserting it in the detergent dispenser drawer. The contents can run out of the capsule if you then remove it from the detergent drawer before it is used.

In this case, dispose of the capsule and do not re-use it.

The wash programme will dispense the contents of the capsule at the correct time.

When using CapDosing, water intake to the & compartment takes place solely via the capsule.

When using capsules, do not add fabric softener to the & compartment.

## 6. Starting the programme

The programme can be started when the *Start/Stop* sensor is flashing on and off.

■ Touch the Start/Stop sensor.

The door will lock and the programme will start.

The programme status will appear in the display.



The washer-dryer will keep you updated on the programme status and the time remaining for the programme to run.

If a Timer period has been selected, this will count down in the display until the programme starts.

The drum lighting switches off once the programme has started.

## Saving energy

After 10 minutes, the indicators will dim. The *Start/Stop* sensor flashes slowly.

You can reactivate the indicators:

Touch the Start/Stop sensor (this does not have any effect on a programme that is running).

## Adding laundry - AddLoad

Laundry can be added or removed if Add laundry is illuminated in the display.

■ Touch the Add laundry sensor.

The following will appear in the display:

: Please wait

The programme will stop and the door will unlock.

- Open the door.
- Add or remove laundry.
- Close the door.
- Touch the Start/Stop sensor.

The programme will continue.

Laundry cannot be added or removed if:

- The suds temperature is above 55°C
- The water inside the drum is above a certain level

# 7. End of the programme/ unloading laundry

At the end of the programme, the drum continues to turn at intervals for up to 30 minutes. The door will lock and the following will appear in the display: Finish/Anti-crease and Unlock with "Start/Stop".

■ Touch the Start/Stop sensor.

The door will unlock.

The door unlocks automatically at the end of the Anti-crease phase.

- Pull open the door.
- Remove the laundry.

Items left in the drum could discolour other items in the next wash or become discoloured themselves.
Remove all items from the drum.

- If applicable, remove the used capsule from the detergent dispenser drawer.
- Switch the washer-dryer off with the () sensor.

**Useful tip:** See "After each washing or drying programme".

### Spin cycle

Programme	rpm
ECO 40-60	1600
Cottons	1600
Minimum iron	1200
QuickPower	1600
Delicates	900
Shirts	900
Woollens	1200
Denim	900
Outerwear	800
Proofing	1000
Curtains	600
Express 20	1200
Sportswear	1200
Dark garments	1200
Trainers	600
Silks	600
Down Items	1200
Pillows	1200
Cottons hygiene	1600
Automatic plus	1400
First wash	1200
Drain/Spin	1600
Separate rinse	1600
Starch	1600
Cottons	1600

# Final spin speed in wash programmes

When a programme is selected, the optimum spin speed for this wash programme is shown in the display.

A faster spin speed can be selected for certain wash programmes.

The highest selectable spin speed is indicated in the table.

#### Omitting the final spin (Rinse hold)

■ Select the Rinse hold Extra.

The laundry is not spun after the final rinse and remains in the rinse water. This helps prevent creasing if the laundry is not going to be removed from the drum immediately after the end of the programme.

#### To start the final spin:

The wash programme is set to the optimum spin speed. You can change the spin speed.

- Touch the Change spin speed sensor.
- Select the desired spin speed.
- Start the final spin with the Start/Stop sensor.

#### **Ending the programme:**

- Touch the Change spin speed sensor.
- Select the spin speed 0 rpm (no spin).
- Touch the Start/Stop sensor.

The water will be pumped away.

#### Interim spin

There is a spin cycle after the main wash and between the rinses. A reduction in the final spin speed will also reduce the interim spin speed as appropriate.

# Deselecting the interim spin and the final spin

- Touch the Spin speed sensor.
- Select the spin speed 0 rpm (no spin).

After the last rinse cycle, the water will be pumped away and the Anti-crease phase will switch on.

In some programmes an additional rinse is introduced with this setting.

## **Programme chart**

ECO 40-60	Max. load 9.0 kg
Items	Normally soiled cotton garments.
Notes	- A laundry load consisting of mixed cottons that are intended for washing at 40°C or 60°C can be washed in the same wash cycle.

**Information for customers:** You cannot normally select any temperatures or Extras for the ECO 40-60 wash programme.

**Note for test institutes:** Energy labelling programme according to AS/NZS 2040.1 & AS/NZS 2040.2 (refer to www.energyrating.gov.au website for consumption data).

The detergent must be added via the detergent dispenser drawer.

The TwinDos system must be switched off during the tests.

Cottons	Cold to 90	°C	Max. load 9.0 kg
Items	Cottons, linens or cotton mix underwear, T-shirts etc.	fabrics, e.g. table line	en, towelling,
Notes	<ul> <li>Where particularly high lever select a temperature of 60°</li> </ul>		uired, please
Minimum i	ron Cold to 60	°C	Max. load 4.0 kg
Items	Synthetic, mixed fibre and ea	sy care cotton.	
Notes	Reduce the spin speed for ite	ms which crease eas	ily.
QuickPow	er 40°C to 60	°C	Max. load 4.0 kg
Items	Moderately soiled garments with a Cottons programme.	vhich are also suitabl	e for washing in
Notes	A special saturation process a laundry is cleaned particularly	•	
Delicates	Cold to 60	°C	Max. load 3.0 kg
Items	Delicate garments made from viscose.	synthetic fibre, mixe	d fibre, rayon and
Notes	For items which crease easily	, deselect the spin.	

Shirts	Cold to 60°C	Max. load 1.0 kg/2.0 kg	
Items	Shirts and blouses made of cotton and mix	ed fibre.	
Notes	- Pre-treat collars and cuffs if necessary.		
	- Turn shirts and blouses inside out, do up and cuffs inwards.	buttons and turn collars	
	- Wash silk shirts and blouses in the Silks	programme.	
	- If the <i>Pre-ironing</i> Extra is switched on, th is decreased to 1.0 kg.	e maximum load capacity	
Woollens t	<b>₩</b> Cold to 40°C	Max. load 2.0 kg	
Items	Machine-washable or hand-washable wool the care label does not specify a temperatusetting.		
Notes	Reduce the spin speed for fabrics that crea	ase easily.	
Denim	Cold to 60°C	Max. load 3.0 kg	
Items	Black and dark garments made from cottor denim.	n, mixed fibres and	
Notes	- Wash denim inside-out.		
	Dark textiles often contain excess dye an separately several times before being inc Wash light and coloured items separately	luded in a mixed load.	
	- Close any zips, do up buttons etc. before	e washing.	
Outerwear	Cold to 40°C	Max. load 2.5 kg	
Items	Functional textiles such as outdoor jackets membrane fabrics such as Gore-Tex <sup>®</sup> , SYN WINDSTOPPER <sup>®</sup> , etc.		
Notes	- Close any zips and Velcro fasteners befo	re washing.	
	- Do not use fabric softener.		
	If required, outdoor clothing can be reproprogramme. Reproofing after each wash recommended.		

Proofing		40 °C	Max. load 2.5 kg
Items	_	ofibre fabric, ski wear of fibres to provide a finish	r table linen made from n which is resistant to water
Notes	- The items shou proofing.	uld be freshly laundered	and spun or dried before
			eat-treated afterwards. This tumble dryer or ironing
Curtains		Cold to 40°C	Max. load 2.0 kg
Items	Curtains specified	d as machine-washable	by the manufacturer.
Notes	- Select the Pre-	wash option to remove	dust.
	- For curtains who deselect the sp	nich crease easily, redu oin.	ce the spin speed or
	- Remove weigh	ts from curtains.	
Express		Cold to 40°C	Max. load 3.5 kg
Items	Cotton garments soiled.	that have hardly been	worn or are only very lightly
Sportswea	r	Cold to 60°C	Max. load 3.0 kg
Items	Sportswear such fleece garments	as jersey shirts and leg	gings, and microfibre and
Notes	- Do not use fab	ric softener.	
	- Observe the in	structions on the care la	abel.
Dark garm	ents	Cold to 60°C	Max. load 3.0 kg
Items	Black and dark it	ems made of cotton or	mixed fibres
Notes	Wash inside out.		

Trainers	Cold to 40°C	Max. 2 pairs
Items	Sport shoes only (not leather shoes).	
Notes	- Observe the instructions on the care label.	
	- Do not use fabric softener.	
	- Coarse soiling should be brushed off first.	
	- Close Velcro fasteners.	
	<ul> <li>A pre-rinse without detergent is carried ou remove dust.</li> </ul>	t automatically to
Silks 👑	Cold to 30°C	Max. load 1.0 kg
Items	Silks and other hand-washable fabrics with r satin, lace and silk.	no wool content, e.g.
Notes	Place stockings and bras in a laundry bag.	
Down Item	s Cold to 60°C	Max. load 2.0 kg
Items	Jackets, sleeping bags, pillows and other do	wn-filled items
Notes	<ul> <li>Remove air from the items before washing build-up of foam. To do this, either push the laundry bag to compress them or tie the ite washable strap.</li> </ul>	ne items into a narrow
	- Observe the instructions on the care label.	
Pillows	Cold to 60°C 2	pillows (40 x 80 cm) or 1 pillow (80 x 80 cm)
Items	Synthetic filled washable pillows.	
Notes	<ul> <li>Remove air from the items before washing build-up of foam. To do this, either push the laundry bag to compress them or tie the ite washable strap.</li> </ul>	ne items into a narrow
	- Observe the instructions on the care label.	

Cottons hy	giene	60°C to 90°C	Max. load 9.0 kg
Items			for which special hygiene linen, encasing products.
Notes	- Observe the in	structions on the care lab	oel.
	- Temperature h programme.	olding times are longer th	nan in the Cottons
	AllergoWash E	of viruses and bacteria in extra and detergent dispendent of the extrance and confirmation of the extrance and confirmation of the extrance and bacteria.	nsing via TwinDos with
Automatic	plus	Cold to 40°C	Max. load 5.0 kg
Items	_	arments suitable for the orthe orthe orthe orthograms.	Cottons and Minimum iron
Notes	are adjusted auto	eters (e.g. water level, wa omatically in this program d wash result for each ite	
First wash		Cold to 40°C	Max. load 2.0 kg
Items	New items made	of cotton, towelling and	polyester fabric.
Notes	Use this progran items.	nme to wash any manufad	cturing residues out of new
Drain/Spin			Max. load 9.0 kg
Notes	- Drain only: Sel	ect 0 rpm for the spin sp	eed.
	- Make sure you	select the appropriate sp	pin speed.
Separate ri	inse		Max. load 9.0 kg
Items	For rinsing hand	-washed items.	
Notes	Reduce the spin	speed for items which cr	rease easily.
Starch			Max. load 9.0 kg
Items	For starching tab	ole cloths, serviettes and	workwear.
Notes	- Reduce the sp	in speed for items which	crease easily.
	- Laundry that is with fabric sof		e washed but not treated

Cottons <		Max. load 9.0 kg
Items	Moderately soiled cotton garments.	
Notes	<ul> <li>With 60°C, the wash temperature reached is wash performance is the same as with the C programme.</li> </ul>	

## Programme sequence

	Main	in wash Rins		ses	Spin cycle
	Water level	Wash rhythm	Water level	Rinses	
ECO 40-60	<u></u>	A	<b></b>	2-3 <sup>2</sup>	<b>✓</b>
Cottons	<u></u>	A	<u></u>	2-5 <sup>1,2,3</sup>	<b>\</b>
Minimum iron	<u></u>	<b>B</b>		2-4 <sup>2,3</sup>	<b>\</b>
QuickPower	<u></u>	A	<u></u>	2	<b>✓</b>
Delicates	<u></u>	©	<u></u>	2-4 <sup>2,3</sup>	<b>✓</b>
Shirts	<u></u>	<b>©</b>		3–4 <sup>3</sup>	<b>✓</b>
Woollens		E		2	<b>✓</b>
Denim	<b></b>	<b>B</b>	<u></u>	2-4 <sup>2,3</sup>	<b>✓</b>
Outerwear		©	<u></u>	3-4 <sup>3</sup>	<b>✓</b>
Proofing	-	B	<u></u>	1	<b>✓</b>
Curtains	<u></u>	©	<u></u>	3-43	<b>✓</b>
Express 20	<u></u>	A	<u></u>	1	<b>✓</b>
Sportswear	<u></u>	©	لسيا	2–3 <sup>3</sup>	<b>✓</b>
Dark garments	<b></b>	<b>B</b>	<u></u>	$3-5^{2,3}$	<b>✓</b>
Trainers <sup>4</sup>		<b>D</b>	<u></u>	2	<b>✓</b>
Silks		E		2	<b>✓</b>
Down items <sup>5</sup>	<u></u>	©	<u></u>	3–4 <sup>3</sup>	<b>✓</b>
Pillows <sup>5</sup>	<u></u>	©		3-43	<b>✓</b>
Cottons hygiene	<u></u>	A	<u></u>	3-5 <sup>2,3</sup>	<b>✓</b>
Automatic plus	<u></u>	(A)(B)	<u></u>	2-4 <sup>2,3</sup>	<b>✓</b>
First wash	لسيا	B	<u></u>	2-3 <sup>3</sup>	<b>✓</b>
Separate rinse	_	_		2	<b>✓</b>
Starch	<u></u>	B	-	-	<b>✓</b>

Please see the next page for a description of the symbols.

= low water level

= medium water level

= high water level

A = intensive rhythm

B = normal rhythm

© = sensitive rhythm

D = ultra sensitive rhythm

E = handwash rhythm

√ = carried out

= not carried out

This washer-dryer has fully electronic controls with automatic load recognition. It takes in the right amount of water required for the programme depending on the amount of laundry and its absorbency rate.

The programme sequences outlined are based on the standard programme with a full load.

The washer-dryer's display continually shows which stage of the programme has been reached.

# Special features in the programme sequence

#### Anti-crease

At the end of the programme, the drum continues to turn at intervals for up to 30 minutes to help prevent creasing. Exception: There is no Anti-crease phase in the *Woollens* and *Silks* programme.

The drum door can be opened at any time during the anti-crease phase.

- <sup>1</sup> If a temperature of 60°C or higher is selected, 2 rinses are carried out. If a temperature of less than 60°C is selected, 3 rinses are carried out.
- <sup>2</sup> An additional rinse is carried out if:
- there is too much foam in the drum
- the final spin speed is less than 700 rpm
- <sup>3</sup> An additional rinse is carried out if:
- the Extra rinse Extra has been selected
- <sup>4</sup> Pre-wash:
- A pre-wash is carried out automatically to remove dust.
- <sup>5</sup> Run-up to spin:
- A run-up to spin is carried out before the wash process begins to deflate down-filled items. Subsequent water intake for the main wash is through compartment II.

#### **PowerWash**

PowerWash is a washing technique developed by Miele which is activated in the following wash programmes:

- ECO 40–60 (with small and medium load sizes)
- Cottons (with small and medium load sizes)
- QuickPower
- Minimum iron
- Shirts
- Automatic plus
- Delicates

#### How it works

Conventional washing techniques wash with more water than the laundry can absorb. This total volume of water needs to be heated.

The PowerWash washing technique only uses slightly more water than the laundry can absorb. The water which has not been absorbed by the laundry heats up the drum and the laundry and is sprayed into the laundry over and over again. This reduces the amount of energy used.

#### Activation

PowerWash is activated **automatically** in the programmes listed above.

PowerWash is deactivated if:

- the selected final spin speed is less than 600 rpm
- CapDosing has been selected for the main wash (♦, △)

- the wash temperature is higher than 60 °C
- Extras such as Pre-wash or Water plus have been selected
- a large load size is being washed in the ECO 40-60 or Cottons programmes

#### Special features

#### - Drenching phase

The washer-dryer will spin a few times at the beginning of the wash programme. During the spin cycle, the water discharged is sprayed back into the laundry in order to achieve optimum moisture penetration.

The optimum water level is set at the end of the drenching phase. If necessary, the machine will pump water away and take in a little more fresh water.

#### - Noises during the heating phase

Unusual bubbling noises can occur while the laundry and the drum are being heated.

#### **Extras**

You can supplement the wash programmes with Extras.

Not all Extras can be selected with every programme.

#### **Selecting Extras**

- Touch the Extras sensor.
- Select one or more Extras.

Not all Extras can be combined. Extras that cannot be combined are greyed out and cannot be selected.

■ Confirm with the OK sensor.

The display will change to the standard menu for that wash programme.

#### **SingleWash**

For efficiently washing a very small load (< 1 kg) in a normal wash programme. The wash duration is reduced.

Please note the following advice:

- Use liquid detergent.
- Reduce the dosage to a maximum of 50% of the amount quoted for a ½ load.

#### Extra gentle

Drum rotation and wash duration are reduced. Lightly soiled fabrics are washed more gently.

#### **Pre-ironing**

In order to reduce creasing, the laundry undergoes a smoothing process at the end of the programme. For optimal smoothing reduce the maximum load by 50%. Small loads achieve a better result.

The garments must be suitable for drying in a tumble dryer  $\bigcirc$   $\bigcirc$  and suitable for ironing  $\longrightarrow$   $\bigcirc$ .

The spin speed is reduced for some programmes.

#### Quick

For light soiling with no visible staining.

The duration of the main wash is reduced.

#### Water plus

The water level in the main wash and the rinse cycles is increased. A second rinse cycle is carried out in the Separate rinse programme.

You can select other functions for the Water plus Extra. These are described in "Settings".

#### Pre-wash

For laundry with large amounts of dirt, e.g. dust and sand.

#### Soak

For heavily soiled fabrics with protein stains.

A soak duration of between 30 minutes and 5 hours in 30-minute increments can be selected. See "Settings" for more information.

The factory default setting is 30 minutes.

#### Intensive

For hard-wearing laundry that is very heavily soiled. Cleaning efficiency is increased through more intense mechanical action and the application of more heat energy.

#### **AllergoWash**

This option should be used where high standards of hygiene are required. More energy is used to lengthen the temperature holding times. More water is used to increase rinsing efficiency. The items must be suitable for drying in a tumble dryer  $\bigcirc$   $\bigcirc$  and suitable for ironing  $\longrightarrow$   $\bigcirc$ .

#### Extra quiet

This option reduces noise levels during the wash programme. Use this if you want to wash during quiet periods (for instance when children are sleeping). The machine will activate the *Rinse hold* option and not spin. The programme duration is longer.

#### Rinse hold

The laundry is not spun after the final rinse and remains in the rinse water. This helps prevent creasing if the laundry is not going to be removed from the drum immediately after the end of the programme.

#### Extra rinse

An additional rinse cycle can be activated to achieve a particularly good rinse result.

### **Detergent**

Any detergent suitable for automatic front loading washing machines can be used with this appliance. Follow the manufacturer's instructions and dosage recommendations on the packaging.

## The amount to dispense will depend on:

- the degree of soiling of the laundry
- the amount of laundry
- the water hardness

Check with your local water supplier if you do not know the water hardness level in your area.

#### Water softeners

A water softener can be used to cut down on the use of detergents in areas with water hardness levels II and III. Dispense according to the amount specified on the packaging. First add detergent and then the water softener.

You can then use the recommended amount of detergent for water hardness level I.

#### Water hardness levels

Hardness range	Hardness level in mmol/l	German scale in °d
Soft (I)	0 – 1.5	0 – 8.4
Medium (II)	1.5 – 2.5	8.4 – 14
Hard (III)	above 2.5	above 14

#### **Detergent dispensing aids**

Use dispensing aids (e.g. balls) if these are supplied with the detergent, particularly when using liquid detergent.

#### Refill packs of detergent

When purchasing detergent, buy refill packs wherever possible. This helps reduce the amount of waste packaging.

#### Fabric softeners, liquid starch, starch

<u>Fabric softeners</u> make garments soft to handle and help prevent static cling when tumble drying.

<u>Fabric shapers</u> are synthetic starches and give an even stiffer hold.

Starch stiffens and gives body to fabric.

# Using fabric softener, liquid starch or starch separately

Prepare the starch in accordance with the manufacturer's instructions on the packaging.

**Useful tip:** When adding fabric softener, activate the Water plus Extra.

# Dispensing via the detergent dispenser drawer

- Add liquid starch to the ⊗ compartment and powder or viscous starch to the ∪ compartment.
- Select the Separate rinse or Starch programme.
- Change the spin speed if necessary.
- If using a capsule, touch the CapDosing sensor and activate the Cap.
- Touch the Start/Stop sensor.

#### TwinDos dispensing

One of the automatic dispensing containers must be filled with fabric softener.

- Select the Separate rinse or Starch programme.
- Change the spin speed if necessary.
- Touch the TwinDos sensor.
- Touch the On sensor to activate TwinDos.
- Touch the Start/Stop sensor.

#### Colour run and dye removers/dyes

Damage due to colour run/dye removers.

Colour run and dye removers can cause corrosion in the washer-dryer. Do not use colour run or dye removers in this washer-dryer.


Dyes suitable for use in domestic washing machines can be used. However, please note that the salt used in the dyeing process can cause corrosion to stainless steel components in the machine if you use dye frequently. Always observe the manufacturer's instructions carefully.

When using the machine to dye fabric it is essential to select the *Water plus* Extra.

#### Miele detergents

Miele detergents have been specially designed for everyday use in Miele washing machines. See "Detergents and care products" for more information about these detergents.

	Miele UltraPhase 1	Miele capsules		es
	and 2		₩	
ECO 40-60	<b>✓</b>	-	<b>✓</b>	<b>✓</b>
Cottons	<b>✓</b>	-	<b>✓</b>	<b>✓</b>
Minimum iron	<b>✓</b>	-	<b>✓</b>	<b>✓</b>
QuickPower	<b>✓</b>	-	-	-
Delicates	<b>✓</b>	<b>✓</b>	<b>✓</b>	-
Shirts	<b>✓</b>	-	<b>✓</b>	<b>✓</b>
Woollens	-	<b>✓</b>	-	-
Denim	<b>✓</b>	-	<b>✓</b>	-
Outerwear	-	<b>✓</b>	-	-
Proofing	_	-	<b>✓</b>	-
Curtains	<b>✓</b>	-	-	<b>✓</b>
Express 20	<b>✓</b>	-	<b>✓</b>	-
Sportswear	-	<b>✓</b>	-	-
Dark garments	<b>✓</b>	-	<b>✓</b>	-
Trainers	<b>✓</b>	-	-	<b>✓</b>
Silks	_	<b>✓</b>	-	-
Down Items	-	<b>✓</b>	-	-
Pillows	_	<b>✓</b>	_	-
Cottons hygiene	<b>✓</b>	-	<b>✓</b>	<b>✓</b>
Automatic plus	✓	-	<b>✓</b>	<b>✓</b>
First wash	<b>✓</b>	-	<b>✓</b>	-
Separate rinse	_	-	<b>✓</b>	-



Specialist detergents (e.g. WoolCare)

not recommended

Fabric care (e.g. fabric softener)

Additive (e.g. booster)

The recommendations apply to the temperature ranges given in the section "Washing" in the Programme chart.

	Universal	Colour	Delicates and woollens	Special		
	detergent					
ECO 40-60	<b>✓</b>	✓	_	-		
Cottons	<b>&gt;</b>	<b>✓</b>	_	_		
Minimum iron	-	✓	_	-		
QuickPower	<b>&gt;</b>	<b>✓</b>	_	-		
Delicates	-	-	<b>✓</b>	-		
Shirts	<b>&gt;</b>	<b>✓</b>	_	-		
Woollens	-	-	<b>✓</b>	<b>✓</b>		
Denim	-	<b>√</b> ¹	-	<b>✓</b>		
Outerwear	-	-	<b>✓</b>	<b>✓</b>		
Proofing	-	-	-	<b>✓</b>		
Curtains	<b>\</b> <sup>2</sup>	-	-	<b>✓</b>		
Express 20	ı	<b>√</b> ¹	-	-		
Sportswear	-	-	<b>✓</b>	<b>✓</b>		
Dark garments	ı	<b>√</b> ¹	_	<b>✓</b>		
Trainers	-	<b>√</b> ¹	-	-		
Silks	_	_	<b>✓</b>	✓		
Down Items	-	-	<b>√</b> ¹	<b>✓</b>		
Pillows	_	_	<b>√</b> ¹	<b>✓</b>		
Cottons hygiene	<b>✓</b>	<b>✓</b>	-	-		
Automatic plus	_	<b>✓</b>	_	_		
First wash	-	<b>✓</b>	-	-		

<sup>√</sup> recommended

<sup>&</sup>lt;sup>1</sup> Liquid detergent

not recommended

<sup>&</sup>lt;sup>2</sup> Powder detergent

## Separate drying

The separate drying programme should be run if the load in the wash programme is greater than the maximum load permitted for drying, or if you only want to dry part of the load that was washed

## 1. Preparing the laundry

#### Sorting the laundry

Sort the laundry according to type of fibre/weave, size, garment care label symbol, and the drying level required.

This will help you to achieve an even drying result.

■ Before drying, check the drying symbol on the care label.

If there is no care label, the article should only be tumble dried in a programme specially designed for it.

#### Tips on drying

- Do not load the drum with items that are still soaking wet. Spin the laundry for at least 30 seconds after washing.
- Woollens and wool blends are susceptible to becoming matted or shrinking. Only use the Woollens programme for these textiles.
- Pure linen should only be tumble dried if it is specified as suitable on the care label. The surface of the fabric may otherwise become rough.

- Loopknit garments (e.g. T-Shirts, underwear) have a tendency to shrink after the first wash. Do not overdry these fabrics to prevent further shrinking. When buying loopknit garments, it is advisable to take their shrinkage potential into account.
- Starched laundry can be tumble dried. To achieve the usual finish, double the amount of starch should be used.
- New dark coloured garments should be washed and dried separately from light coloured garments. The colour of dark garments can run or fluff from garments of other colours may settle on them.
- Observe the maximum loads given for the drying programmes in the Programme chart.

The drying result and amount of creasing depend on the size of the load. The smaller the load in the dryer the better the result. Therefore, if you reduce the load, you will achieve a more even drying result with less creasing.

## 2. Selecting a programme

#### Switching the washer-dryer on

■ Press the 🖒 sensor.

The interior drum lighting will come on.


The drum lighting will go out automatically after a few minutes.

**Useful tip:** To switch the drum lighting on again, open the pull-down menu from the overview menu and then touch the  $\cdot \circ$  sensor.

The main menu will then appear in the display.


#### Selecting a programme

■ Touch the Drying sensor.



- Scroll to the right of the display until the programme you want appears.
- Touch the sensor for that programme.

The display will then change to the standard menu for the programme.



There are 3 other ways to select a programme:

- Saved favourite programmes
- The Washing/Drying assistant
- Miele MobileStart

# 3. Selecting programme settings

#### Selecting a thermospin spin speed

The preset spin speed for the thermospin can be changed if required.

- Touch the Spin speed sensor.
- Select the desired spin speed.

The display will change to the standard menu for that drying programme.

#### Selecting the drying level

The preset drying level for a programme can be changed if required.

- Touch the Drying level sensor.
- Select the desired drying level.

The display will then change to the standard menu for the programme.

### **Selecting Extras**

You can supplement programmes with Extras.

- Touch the Extras sensor.
- Select one or more Extras.

Not all Extras can be combined. Extras that cannot be combined are greyed out and cannot be selected.

■ Confirm with the *OK* sensor.

The display will then change to the standard menu for the programme.

See "Drying – Extras" for more information.

#### Timer

You can use the Timer to set the finish time or the start time for a programme.

See "Timer/SmartStart" for further information.

## 4. Loading the drum

#### Opening the door

■ Reach under the door grip and pull the door open.

Check the drum for pets or foreign objects before loading it with laundry.

Load the laundry loosely in the drum.

Overloading places a strain on the textiles and affects drying results. Observe the maximum loads listed in the Programme chart.

#### Closing the door

- Make sure that no items are caught between the door and the seal.
- Shut the door with a gentle swing.

Detergent dispensing aids, e.g. plastic dispenser balls, can melt during the drying programme and cause damage to the machine and the laundry.

These dispensing aids must be removed from the laundry before drying.

The mains water tap must be kept open for drying.

**Useful tip:** The maximum load size for the programme selected and the current load for the programme will appear in the pull-down menu in increments of 25%.


## 5. Starting the programme

The programme can be started when the *Start/Stop* sensor is flashing on and off.

■ Touch the *Start/Stop* sensor.

The door will lock and the programme will start.

The programme status will appear in the display.



The washer-dryer will keep you updated on the programme stage and the remaining programme running time.

If a Timer period has been selected, this will count down in the display until the programme starts.

The drum lighting switches off once the programme has started.

### Saving energy

After 10 minutes, the indicators will dim. The *Start/Stop* sensor flashes slowly.

You can reactivate the indicators:

■ Touch the Start/Stop sensor (this does not have any effect on a programme that is running).

## **Adding laundry**

Laundry can be added or removed if Add laundry is illuminated in the display.

■ Touch the Add laundry sensor.

The following will appear in the display:

: Please wait

The programme will stop and the door will unlock.

Risk of burning when touching hot laundry in the drum.
You could burn yourself.

- Open the door.
- Add or remove laundry.
- Close the door.
- Touch the Start/Stop sensor.

The programme will continue.

#### **Exceptions to adding laundry**

In some cases, e.g. during the cooling phase or in the *Proofing* programme, you cannot add laundry.

In exceptional cases, the door can be opened while the programme is running.

# 6. End of the programme/ unloading laundry

At the end of the programme, the drum continues to turn at intervals for up to 150 minutes. The door will lock and the following will appear in the display: Finish/Anti-crease and Unlock with "Start/Stop".

■ Touch the *Start/Stop* sensor.

The door will unlock.

If you unload the laundry during the Anti-crease phase, heat can build up. Spread the laundry out to cool it down.

The door unlocks automatically at the end of the Anti-crease phase.

- Pull open the door.
- Remove the laundry.

Items left in the dryer could be damaged by overdrying when the dryer is used the next time.

Remove all items from the drum.

**Useful tip:** See "After each washing or drying programme".

## **Programme chart**

<sup>&</sup>lt;sup>1</sup> For further information on *Timed drying*, see the end of the Programme chart.

ECO 40-60	Max. load 5.0 kg*		
Normal			
	Cotton textiles: T-shirts, underwear, baby clothes, workwear, jackets, covers, aprons, overalls, hand towels, bath towels, bathrobes and flannelette/bed linen.		
Energy labelling programme according to AS/NZS 2442.1 & AS/NZS 2442.2 (refeto http://www.energyrating.gov.au website for consumption data).			
Cottons	Max. load 5.0 kg*		
Normal plus,	Normal		
Items	Single and multi-layered cotton fabric such as towelling, T-shirts, underwear, baby clothes, workwear, jackets, covers, aprons, overalls, flannelette bed linen, towels and bath robes.		
Hand iron, M	Hand iron, Machine iron, Timed drying <sup>1</sup>		
Items	Cotton or linen fabric requiring further processing, e.g. table linen, bed linen, starched laundry.		
Notes	Roll up laundry that you want to machine iron to prevent it from drying out until you are ready for ironing.		
Minimum iron Max. loa			
Normal plus,	Normal, Hand iron, Timed drying <sup>1</sup>		
Items	Minimum iron items made of cotton, synthetic or mixed fibre, e.g. workwear, overalls, jumpers, dresses, trousers, table linen, tights.		
QuickPowe	er Max. load 4.0 kg*		
Normal plus, Normal, Hand iron, Timed drying <sup>1</sup>			
Items	Garments suitable for the Cottons programme.		
Notes	The programme running time for this programme is particularly short when washing and drying <b>moderately</b> soiled laundry in a continuous sequence.		

<sup>\*</sup> Weights are based on the weight of dry laundry.

Delicates	Delicates Max. load 1.5 kg	
Normal plus, Normal, Hand iron, Timed drying <sup>1</sup>		
Items	Delicate items with the  symbol on the care label made of synthetic fibres, easy care cotton or blended fabric, e.g. shirts, blouses, lingerie and evening wear with sequins and beading.	
Notes	Reducing the load will reduce creasing.	
Shirts	Max. load 1.0 kg*	
Normal plu	us, Normal, Hand iron, Timed drying <sup>1</sup>	
Items	Shirts and blouses.	
Notes	- Turn shirts and blouses inside out, do up buttons and turn collars and cuffs inwards.	
	- The laundry is dampened before the programme starts to help reduce creasing.	
Woollens	Max. load 2.0 kg*	
3 minutes		
Items	Woollen garments and textiles containing wool blends, e.g. pullovers, cardigans, stockings.	
Notes	<ul> <li>Wool and wool blend items are only fluffed up; they are not dried completely.</li> </ul>	
	- Remove garments as soon as the programme has finished.	
Denim	Max. load 3.0 kg*	
Normal plus, Normal, Hand iron, Timed drying <sup>1</sup>		
Items	All denim garments, e.g. jeans, jackets, skirts, shirts	

Freshen u	Freshen up Max. load 1.0 k	
Normal, Hand iron, Timed drying <sup>1</sup>		
Items	Clean dry garments and garments that have been worn briefly and are not soiled.	
Notes	The laundry is dampened before the programme starts to help reduce creasing.	
	- Normal: for garments that are required immediately.	
	- <b>Hand iron</b> : for garments that are to be ironed or hung out to dry completely on a coat hanger.	
Notes	Creasing <b>increases</b> the larger the load and the longer the drying time.	
Steam ca	re Max. load 2.0 kg*	
Hand iron		
Items	Reduces the amount of creasing in damp, freshly washed and spun cotton or linen garments.	
	The garments must be suitable for drying in a tumble dryer $\bigcirc$ $\bigcirc$ and suitable for ironing $\longrightarrow$ $\bigcirc$ .	
Notes	Remove garments as soon as the programme has finished and hang them up on a coat hanger.	
Notes	Not suitable for garments made of wool or wool blend fabric.	
Outerwea	mr Max. load 2.5 kg*	
Normal plus	s, Normal, Hand iron, Timed drying <sup>1</sup>	
Items	Outerwear which is suitable for drying in a tumble dryer.	
Proofing	Max. load 2.5 kg*	
Normal		
Items	For thermally fixing textiles which are suitable for tumble drying and have been treated with a proofing agent.	
Notes	- This programme includes a proofing fixing phase.	
	- Only use proofing agents which are stated by the manufacturer as being "suitable for use on membrane textiles". These agents contain fluorochemical compounds.	
	- Do not dry items which have been treated with proofing agents containing paraffin. Fire hazard!	

Express 20	0 Max. load 3.5 kg	
Normal plus, Normal, Hand iron, Timed drying <sup>1</sup>		
Items	Garments suitable for the Cottons programme.	
Notes	The programme duration is particularly short when washing and drying <b>lightly</b> soiled laundry in a continuous sequence.	
Sportswea	ar Max. load 3.0 kg	
Normal plus	, Normal, Hand iron, Timed drying <sup>1</sup>	
Items	Sportswear which is suitable for drying in a tumble dryer.	
Dark garm	nents Max. load 3.0 kg	
Normal plus	, Normal, Hand iron, Timed drying <sup>1</sup>	
Items	Black and dark garments made from cotton or mixed fibres	
Trainers	Max. 2 pai	
Timed drying	g <sup>1</sup>	
Items	Sport shoes that are specified as suitable for tumble drying by their manufacturer.	
Notes	Insoles should be removed and placed in the drum with the shoes.	
Notes	The drum does not rotate.	
Silks	Max. load 1.0 kg	
8 minutes		
Items	Silk garments which are suitable for drying in a tumble dryer, e.g. blouses and shirts.	
Notes	- For reduced creasing.	
	- Items are not dried completely.	
	- Remove garments as soon as the programme has finished.	
Down Items Max. load 2.0 kg		
Timed drying <sup>1</sup>		
Items	Jackets, sleeping bags, pillows and other down-filled items that are suitable for tumble drying.	
Notes	Check the items as you are drying them to find the optimal time.	

Pillows	2 pillows (40 x 80 cm) or 1 pillow (80 x 80 cm)
Timed drying	1
Items	Pillows with synthetic filling that are suitable for tumble drying.
Notes	Pillows can still feel damp after being dried. You can use this programme several times until the pillow feels dry.
Cottons hy	giene Max. load 5.0 kg*
Normal	
Items	Cottons and linen fabrics, which are in direct contact with the skin, e.g. underwear, nappies, towelling, bed linen, pillow and mattress covers.
Notes	The laundry will feel drier because of the longer temperature holding time.
Automatic	plus Max. load 4.0 kg*
Normal plus,	Normal, Hand iron, Timed drying <sup>1</sup>
Items	Mixed loads of garments suitable for the <i>Cottons</i> and <i>Minimum iron</i> programmes.
First wash	Max. load 2.0 kg*
Normal plus,	Normal, Hand iron, Timed drying <sup>1</sup>
Textiles	New cotton, towelling or polyester textiles.
Warm air	Max. load 5.0 kg*
Timed drying	1
Items	- Multi-layered items whose layers have different drying characteristics, e.g. jackets, pillows, sleeping bags and other voluminous items.
	- For drying and airing individual items.
Notes	Do not select the longest drying time to start with. Check the items as you are drying them to find the optimal time.
Cool air	Max. load 5.0 kg*
Timed drying <sup>1</sup>	
Items	Any items which only need airing.
	l .

Cottons <	Max. load 5.0 kg*
Normal	
Items	Cotton items such as those described under <i>Cottons Normal</i> with normal residual moisture.

#### <sup>1</sup> Timed drying

Timed drying is particularly suitable for small loads or when you want to dry individual items. The items are dried with warm air (a drying time between 20 minutes and 2 hours can be selected). The drying temperature is adjusted to match the programme selected. Do not select the longest drying time to start with. Check the items as you are drying them to find the optimal time.

### **Thermospin**

A thermospin is carried out in some drying programmes to reduce energy consumption.

Thermospin is not carried out if timed drying is selected.

The maximum spin speed for the thermospin is the maximum permitted spin speed for the appropriate wash programme.

The thermospin can be reduced to 800 rpm.

#### **Extras**

You can select Extras to augment drying programmes.

Not all Extras can be combined. Extras that cannot be combined are greyed out and cannot be selected.

#### **Pre-ironing**

In order to reduce creasing, the laundry undergoes a smoothing process at the end of the programme. The spin speed for the thermospin is reduced. For optimal smoothing reduce the maximum load by 50%.

The garments must be suitable for drying in a tumble dryer  $\bigcirc$   $\bigcirc$  and suitable for ironing  $\overrightarrow{\triangle}$ .

#### SingleDry

For efficiently drying a very small load size (< 1 kg) in a normal drying programme.

A drying time is preset. You can change the drying time.

Some items may still be damp after drying, depending on the type of laundry. Select a longer duration next time.

#### Gentle tumble

Delicate textiles such as acrylics are dried gently (care label symbol ①).

In some programmes the programme running time will increase when *Gentle tumble* is selected because of the lower temperature.

#### **Extra quiet**

If you want to dry clothes in quiet periods, the noise level of the washer-dryer can be reduced.

- The buzzer is deactivated.
- Thermospin is limited to a maximum of 800 rpm.

## **Washing and Drying**

# Washing and drying in one continuous sequence

It is advisable to wash and dry in a continuous sequence when the amount of laundry to be washed does not exceed the amount to be dried, and the amount to be dried does not exceed the permitted dry weight for the programme.

It is essential to read the sections "Washing" and "Drying".

## 1. Preparing the laundry

- Empty all pockets.
- Sort the laundry according to colour and type of fibre/weave.
- Check the symbols on the care labels.

## 2. Selecting a programme

- Touch the Washing + Drying sensor.
- Scroll to the right of the display until the programme you want appears.
- Touch the sensor for that programme.

The display will then change to the standard menu for the programme.

There are 3 other ways to select a programme:

- Saved favourite programmes
- The Washing/Drying assistant
- Miele MobileStart

### 3. Loading the drum

■ Open the door.

Check the drum for pets or foreign objects before loading it with laundry.

Unfold the laundry and load loosely into the drum.

Detergent dispensing aids, e.g. plastic dispenser balls, can melt during the drying programme and cause damage to the machine and the laundry.

These dispensing aids must be removed from the laundry before drying.

Close the door.

# 4. Selecting programme settings

Select the desired temperature, spin speed and drying level.

The minimum spin speed cannot be lower than 800 rpm.

For some programmes the spin speed cannot be changed.

To prevent laundry forming a ring against the drum wall, the spin speed is limited to a maximum of 1,200 rpm when washing and drying in a continuous sequence.

- Select TwinDos or CapDosing if desired.
- Select further Extras or stains as required.

With the thermospin the spin speed displayed for the wash cycle is used. If *Extra quiet* is selected the maximum spin speed used is 900 rpm.

Thermospin is not carried out if timed drying is selected.

■ Select a Timer if required.

## 5. Adding detergent

■ Dispense detergent with TwinDos, CapDosing or via the detergent drawer.

# 6. Starting/Ending the programme

■ Touch the flashing *Start/Stop* sensor.

The door will lock.

The programme will start.

The Anti-crease phase will start at the end of the programme.

The door remains locked during the Anti-crease phase.

■ Touch the Start/Stop sensor.

The door will unlock.

If you unload the laundry during the Anti-crease phase, heat can build up. Spread the laundry out to cool it down.

The door unlocks automatically at the end of the Anti-crease phase.

■ Pull the door open and unload the drum.

See "After each washing or drying programme".

## After each washing or drying programme

■ Open the drum door fully.


Risk of burning due to hot metal. The metal cap located on the inside of the door glass will be hot after drying.

Do not touch the metal cap.

Remove the laundry.

Laundry left in the drum could shrink, discolour or be damaged in the next washing or drying programme.

Check that all items have been removed from the drum.



- Check the folds in the door seal for any small articles, e.g. buttons, which might be lodged there.
- After drying, remove any fluff from around the door seal and the porthole glass.

**Useful tip:** For safety reasons, close the door when the machine is not in use. Otherwise there is a danger of objects being placed inadvertently in the drum. If these remain unnoticed and were washed in the next load, they could damage the laundry. An open door is also a danger to pets and children.

**Useful tip:** Leave the detergent dispenser drawer slightly open to allow it to dry.

Use the Rinse out fluff programme to prevent fluff from collecting in the drum and suds container, particularly after drying.

## Changing the programme sequence

# Changing the programme (safety lock)

It is not possible to change the programme, the temperature, the spin speed or the selected Extras after the programme has started. This prevents the appliance being operated unintentionally, e.g. by children.

If the washer-dryer is switched off during active programme operation, the standby function does not switch the washer-dryer off completely after 15 minutes. Safety functions continue to be active because there may still be water inside the drum

## Cancelling a programme

You can cancel a programme at any time after it has started.

■ Touch the Start/Stop sensor.

The following will appear in the display:

- i Cancel the programme?
- Select Yes.
- During washing

The suds will be pumped away and the programme is cancelled.

- During drying

The laundry will be cooled down before the door can be opened.

## Removing the laundry

- Wait until the symbol in the display goes out and the door is unlocked.
- Pull the door open and unload the drum.

#### Selecting another programme

- Close the door.
- Select the required programme.
- Add detergent to the detergent dispenser drawer, if necessary.
- Touch the Start/Stop sensor.

The programme will start.

## Interrupting a programme

- Switch the washer-dryer off with the () sensor.
- To continue the programme, switch the washer-dryer back on with the ⇔ sensor.

Danger of overheating due to hot laundry.

Hot laundry can ignite.

Never switch the washer-dryer off during a drying programme.

If you absolutely must interrupt the programme, remove all items immediately and spread them out to cool down.

## **Favourite programmes**

# Creating a favourite programme

You can save your own customised wash programmes under names of your choice.

#### Option 1

- Scroll through the main menu until Favourites appears.
- Touch the Favourites sensor.

The display will change to show the Favourites menu.

Touch the Create sensor.

The display will change to show the Create Favourites menu.

- Select Washing, Drying or Washing + Drying.
- Select the required programme.
- Select all the programme settings you want.
- Then select Save.
- Enter a name.

## Option 2

You can save a programme which has been selected as a Favourite programme before you start it.

- Before the programme starts, touch the Save sensor.
- Enter a name.

If 12 Favourites have already been saved, the Create or Save sensor will not be visible. Delete an existing Favourite if you wish to create a new one.

## **Entering a name**

It is best to select short, memorable names.

- Touch the letters or characters you want.
- Confirm with the Save sensor.

The programme will then be saved to the Favourites programme list.

# Changing a Favourite programme

You can rename, delete or move a Favourite programme.

- Select Favourites from the main menu.
- Touch the Favourite programme that you wish to change until the Context menu opens.
- Select Rename, Delete or Move.

## Washing/Drying assistant

The assistant helps you with washing and drying loads consisting of items with different care labels. The appliance will use the list of items to put together a suitable programme.

- Scroll through the main menu until Wash/Drying assistant appears.
- Touch the Wash/Drying assistant sensor.

The display will change to show the Purpose menu.

■ Select a goal, e.g. Washing or Washing + Drying.

A list of items will appear.



Touch the appropriate sensor for your item of laundry.

The item selected will be highlighted orange.

You can select several items. Articles that cannot be combined are not available for selection.

- Confirm with the OK sensor.
- Follow the instructions in the display.

A summary of the selected parameters will then appear in the display.

Confirm with the OK sensor or select Change if you would like to make any changes. The programme which has been tailored to your laundry is ready to start.

Helpful tips are sometimes displayed before the start of the programme.

**Useful tip:** You can add individual programme settings, e.g. Extras, before you start the programme.

## Timer/SmartStart

#### **Timer**

The Timer can be used to set the time at which a programme starts or finishes. The programme start can be delayed by up to 24 hours.

## **Setting the Timer**

- Touch the 🕘 Timer sensor.
- Select the Finish at or Start at option.
- Set the hours and the minutes and confirm your entry with the OK sensor.

## **Altering the Timer**

The selected timer can be changed before the programme starts.

- Touch the (i) or (ii) sensor.
- Change the time set and confirm with the OK sensor.

## **Deleting the Timer**

The selected timer can be deleted before the programme starts.

■ Touch the ⇒ or ⊜ sensor.

The selected time for the timer appears in the display.

- Touch the Delete sensor.
- Confirm with the OK sensor.

The selected time for the timer is now deleted.

## **Starting the Timer**

■ Touch the Start/Stop sensor.

The door will lock and the time remaining until the programme starts will appear in the display.

After the programme has started, the selected time for the timer can only be changed or cancelled by interrupting the programme.

The programme can be started immediately at any time.

■ Touch the Start immediately sensor.

# SmartStart (only functional in selected countries)

The SmartStart function lets you define a time period during which your washer-dryer will start automatically. The machine will start on receipt of a signal, e.g. from your energy supplier, that indicates that the electricity rate is particularly economical.

This function is active when the SmartGrid setting is switched on.

The timeframe can be defined between 1 minute and 24 hours. During this period, the washer-dryer waits for the signal from the energy supplier. If no signal is sent during the defined period, the washer-dryer starts the programme.

## Setting the timeframe

If you have activated SmartGrid in the settings, SmartStart by and SmartFinish by will appear in the display instead of Start at and Finish at when you touch the ① Timer sensor. See "Settings – SmartGrid" for more information.

The procedure for setting this is the same as for setting the time for the timer.

- Set the time you want and confirm with the *OK* sensor.
- Touch the *Start/Stop* sensor to start the programme with SmartStart.

The selected programme will start automatically, as soon as the energy provider has sent the signal, or the latest calculated start time has been reached.

The procedure for changing or deleting the *SmartStart* function is the same as described in "Changing the timer" and "Deleting the timer".

# Starting maintenance programmes

The washer-dryer has 3 maintenance programmes.

- Scroll through the main menu until Maintenance appears.
- Touch the Maintenance sensor.



#### Clean "TwinDos"

Clean "TwinDos" is a programme for cleaning the TwinDos system. The programme cleans the hoses inside the washer-dryer.

Damage resulting from dried laundry detergent.

If the system has not been used for a long time (more than 2 months), detergent in the hoses can become viscous or dry out. The hoses can become blocked and would then need to be cleaned by a service technician.

Clean the TwinDos system.

To clean the system, you need either a "TwinDos Care" cleaning cartridge or a TwinDos refill container, available from www.shop.miele.com.

#### Starting a programme

- Select Clean "TwinDos".
- Touch the sensor for the container you want to clean.
- Confirm Start Maintenance programme? with the Yes sensor.
- Follow the instructions in the display.

The hoses will now be cleaned and the TwinDos system can be used again at any time.

#### Cleaning the compartment

Detergent residue can cause clogging.

Use a damp cloth to clean the compartment interior when you change the cartridge or container.

#### Clean machine

With frequent washing at low temperatures there is a danger of a build-up of bacteria in the washer-dryer.

Cleaning the washer-dryer will significantly reduce bacteria, mould and biofilm and prevent the build-up of unpleasant odours.

Start the Clean machine programme at the latest when the *Hygiene info* message appears in the display.

**Useful tip:** Optimum results can be achieved by using the Miele IntenseClean machine cleaner. Alternatively, a universal powder detergent can be used.

#### Starting a programme

- Select Clean machine.
- Dispense the machine cleaner or universal detergent directly in the drum.
- Do not load any laundry. The drum must be empty for the cleaning process.
- Touch the Start/Stop sensor.

The programme will start.

#### Rinse out fluff

During drying, fluff is developed and can collect in the drum and suds container. Run the *Rinse out fluff* programme before the machine is used again so that fluff cannot be deposited on the next load or cause a blockage.

The *Rinse out fluff* programme must not be used for rinsing laundry. Ensure there are no items of laundry in the drum before starting the programme.

#### Starting a programme

■ Select Rinse out fluff.

Do not use detergent.

■ Touch the Start/Stop sensor.

Any fluff will be rinsed away within a few minutes.

- If necessary wipe any remaining fluff off the door seal and door glass.
- Switch the washer-dryer off.

# Cleaning the external casing and fascia panel

A Risk of electric shock.

The mains voltage is applied to the washer-dryer even if it is switched off.

Disconnect the machine from the electricity supply before cleaning or maintenance.

A Risk of damage due to ingress of water.

The pressure of a water jet can cause water to get into the washer-dryer, resulting in damage to components.

Do not spray the washer-dryer with a water jet.

\_\_\_\_\_\_ Damage caused by cleaning agents.

Solvent-based cleaning agents, abrasive cleaners, glass cleaners or multi-purpose cleaning agents can cause damage to plastic surfaces and other parts.


Do not use these cleaning agents.

- Clean the casing and control panel with a mild cleaning agent or soap and water and dry both with a soft cloth.
- The drum can be cleaned using a suitable stainless steel cleaning agent following the manufacturer's instructions on the packaging.

# Cleaning the detergent dispenser drawer


Washing at low temperatures and the use of liquid detergent can lead to a build-up of mould and bacteria in the detergent dispenser drawer.

Clean the entire drawer at regular intervals for hygiene reasons, even if you are using the TwinDos system exclusively.



- Pull out the detergent dispenser drawer until a resistance is felt. Press down the release button and at the same time pull the drawer right out of the machine.
- Clean the detergent drawer with warm water.

## Cleaning the siphon and the channel



- Pull the siphon out of the
   compartment and clean it under warm running water.
- Clean the siphon tube in the same way.
- Refit the siphon.




■ Clean the fabric softener channel using a brush and warm water.

Liquid starch results in clogging. If clogged, the siphon in the %/\(\subseteq\) compartment will not work and the compartment can overflow.

Clean the siphon particularly thoroughly after using liquid starch a few times.

## Cleaning the detergent dispenser drawer housing



- Use a bottle brush to remove detergent residues and limescale from the jets inside the detergent dispenser drawer housing.
- Replace the detergent dispenser drawer.

**Useful tip:** Leave the detergent dispenser drawer slightly open to allow it to dry.


## Cleaning the porthole glass

- Clean the inside of the porthole glass from time to time and the metal cap inside the porthole glass with a suitable mild cleaning agent or with soapy water.
- Dry both with a soft cloth.

## Cleaning the water inlet filter

The washer-dryer has a filter to protect the water inlet valve. The filter at the open end of the water inlet hose should be checked approximately every 6 months. Perform this check more often if there are frequent interruptions to the external water supply.

- First turn off the tap.
- Unscrew the water inlet hose from the tap.



- Remove the rubber seal **1** from the recess.
- Hold the free end of the water inlet hose upside down. The plastic filter 2 will fall out.
- Clean the plastic filter.
- Reassemble in reverse order.
- Turn on the tap and check that the connection is watertight. If water drips out, tighten the connection.

**Never** forget to put the filter back in place after cleaning.

With the help of the following guide, minor faults in the performance of the appliance, some of which may result from incorrect operation, can be remedied without contacting Miele. This will save you time and money because you won't need a service call.

Please note that a call-out charge will be applied to unnecessary service visits where the problem could have been rectified as described in these operating instructions.

## A programme cannot be started

Problem	Possible cause and remedy
The display remains dark and the ⊕ sensor does not light up.	<ul> <li>There is no power to the machine.</li> <li>Check whether the mains plug is plugged in and switched on.</li> <li>Check whether the circuit breaker has tripped.</li> </ul>
	The washer-dryer has switched off automatically to save energy.  ■ Switch the washer-dryer on with the 🖰 sensor.
You are asked to enter a code.	Access via a code has been activated.  Enter the code and confirm the entry. Deactivate the code if you do not wish this message to appear in the display the next time the machine is switched on.
The following appears in the display:  ① Door will not lock. Call Miele.	The door is not closed properly. The door lock could not engage.  Close the door again.  Start the programme again.  If the fault message appears again, contact Miele.

## Fault messages after a programme has been cancelled

Prob	olem	Possible cause and remedy
$\triangle$	Water intake fault. Turn on the tap.	The water inlet is blocked or restricted.  Check whether the tap is turned on properly.  Check whether the inlet hose is kinked.  Check whether there is sufficient water pressure.
		The filter in the water inlet is blocked.  ■ Clean the filter.
$\triangle$	Drainage fault. Clean drain filter and pump. Check the drain hose.	The water outlet is blocked or restricted. The drain hose has been fixed too high.  ■ Clean the drain filter and the drain pump.  ■ Check whether the maximum delivery height of 1 m has been exceeded.
$\triangle$	Waterproof system activated. Turn off the tap. Call Miele.	The water protection system has reacted.  Turn off the tap.  Call Miele.
$\triangle$	Fault F. If restart fails, call Miele.	<ul> <li>There is a fault.</li> <li>Disconnect the washer-dryer from the electricity supply. Switch off at the wall and withdraw the plug from the socket, or switch off the mains circuit breaker.</li> <li>Wait at least 2 minutes before reconnecting the washer-dryer to the electricity supply.</li> <li>Switch the washer-dryer back on.</li> <li>Restart the programme.</li> <li>If the fault message appears again, contact Miele.</li> </ul>

To switch off the fault message, switch the washer-dryer off with the  $\circlearrowleft$  sensor.

## Fault messages at the end of a programme

Mes	sage	Possible cause and remedy
i	Intensive flow: Clean the filter and jet nozzle or remove foreign objects from the pump housing	The pumps are dirty.  ■ Clean the pumps as described in the "Problem solving guide – Opening the door in the event of a blocked drain outlet and/or power cut".  ■ Restart the wash programme after cleaning.
		<ul> <li>The jet in the top of the door ring is blocked with fluff.</li> <li>Remove the fluff with your finger. Do not use any sharp or pointed tools to do this.</li> <li>Restart the wash programme after cleaning.</li> </ul>
		If the fault message appears again, contact Miele. The washer-dryer can still be used but with reduced functionality.
i	Check load	There is no laundry in the drum.
		The load is too small. The laundry is still damp because the residual moisture content in the laundry cannot be measured.  In the future use a <i>Timed drying</i> programme for small amounts of laundry.
		The amount of laundry exceeded the maximum load for the selected programme.  Observe the maximum loads listed in the Programme chart.
i	Start "Rinse out fluff" programme in the "Maintenance" menu	The Rinse out fluff programme has not been used for a long time.  ■ Start the Rinse out fluff programme as described in "Cleaning and care – Starting maintenance programmes".

To switch off the fault message, switch the washer-dryer off with the  $\odot$  sensor.

## Fault messages at the end of a programme

Mes	ssage	Possible cause and remedy
i Align the machine. Laundry not properly spun.	The smoothing process which the laundry undergoes at the end of the programme could not be carried out properly.  ■ Check whether the washer-dryer is aligned correctly as described in "Installation – Levelling the machine".  ■ Check whether the maximum delivery head of 1.0 m has been exceeded.	
		If the fault message appears again, contact Miele. The washer-dryer can still be used but with reduced functionality.
i	Hygiene info: Select "Maintenance" and start the "Clean machine" programme.	No drying programme or no wash programme using a temperature above 60°C has been run for a long time.  In order to prevent bacteria and unpleasant odours building up in the machine, run the Clean machine programme using the Miele machine cleaner or powder detergent.

To switch off the fault message, switch the washer-dryer off with the  $\odot$  sensor.

## **Problems with TwinDos**

Prol	blem	Possible cause and remedy
i	Fit a new cartridge or fill container ①	<ul> <li>The cartridge is empty.</li> <li>Replace the cartridge.</li> <li>Check whether the laundry is clean. There may not have been enough detergent.</li> <li>Wash the items again if necessary.</li> </ul>
i	Only a few more washes possible before a new cartridge is needed for compartment ①.	The detergent in the cartridge is running low. The remaining detergent is sufficient for another 4 to 8 wash programmes.  Order a new cartridge.
i	Use "TwinDos" or carry out "TwinDos" Maintenance in the "Maintenance" menu. See the operating instruction manual for more information.	TwinDos has not been used for a long time.  ■ Use TwinDos for one of your next loads.  ■ Carry out the TwinDos maintenance programme as described in "Cleaning and care – Starting maintenance programmes".
$\triangle$	"TwinDos"  Maintenance for compartment (1) must be started in the "Maintenance" menu. See the operating instruction manual for more information.	TwinDos has not been used for a long time. The detergent in the hoses may dry up.  ■ Carry out the TwinDos maintenance programme immediately as described in "Cleaning and care – Starting maintenance programmes".
The	The messages shown on this page are examples. They may differ depending on	

whether they refer to compartment ① or ②.

The messages will appear at the end of the programme and when the washer-dryer is switched on and need to be confirmed with the OK sensor.

## **Problems with TwinDos**

Problem	Possible cause and remedy
There are dark specks in the liquid detergent.	Mould has developed in the detergent.  ■ Pour the liquid detergent out of the container and then clean the container thoroughly.
No detergent and/or fabric softener was dispensed.	Automatic dispensing has not been activated.  ■ Touch the <i>TwinDos</i> sensor before running the next programme.
	Automatic dispensing will be activated.
	No detergent/fabric softener was dispensed although automatic dispensing was activated.  Try again.  If detergent is still not dispensed, call Miele.
A new detergent cartridge has been inserted, but the cartridge is identified as empty when the machine is switched on.	The washer-dryer was switched off when the detergent cartridge was replaced.  Switch the washer-dryer on.  Remove the detergent cartridge and then reinsert it into the compartment.  The counter is set to 0.

## General problems with the washer-dryer

Problem	Possible cause and remedy
The washer-dryer is not steady during a spin cycle.	The machine feet are not level.  Level the machine and adjust the feet correctly.
Unusual pumping noises.	This is not a fault. Slurping noises occur at the end of the pump sequence as a normal part of operation.
Spinning sounds during the drying process.	This is not a fault. The machine will spin even during a drying programme (thermospin).
The laundry has not been spun properly and the laundry is still wet.	The machine detected an imbalance during the final spin and reduced the spin speed automatically.  Include both large and small items in the load as this will give better distribution.
Large amounts of detergent residue remain in the detergent drawer.	The water pressure is too low.  Clean the filters in the water inlet.  It may be useful to select the Water plus option.
	Powder detergent used in conjunction with water softeners tends to become sticky.  Clean the detergent dispenser drawer and, in the future, add washing powder to the dispenser drawer first, and then add the water softener.
There is water in the fabric softener compartment next to the capsule.	CapDosing was not activated or an empty capsule was not removed at the end of the last wash programme.  Make sure that you remember to activate CapDosing the next time you insert a capsule.  Remove and dispose of the empty capsule at the end of each programme.
	The small pipe in the detergent dispenser drawer onto which the capsule is placed is blocked.  Clean the small pipe.

## General problems with the washer-dryer

Problem	Possible cause and remedy
Fabric softener is not completely dispensed or too much water remains in the $\Re$ compartment.	The siphon tube is not correctly positioned or clogged.  Clean the siphon (see "Cleaning and care - Cleaning the detergent dispenser drawer").
At the end of the programme there is still liquid in the capsule.	The small pipe in the detergent dispenser drawer onto which the capsule is placed is blocked.  Clean the small pipe.
	This is not a fault. For technical reasons a small amount of water will remain in the capsule.
The display is in a different language.	A different language has been selected in "Settings - Language ▶".  ■ Set the language you want.
	The flag symbol serves as a guide.
The display is dark.	The display has switched off automatically to save energy (Standby mode).  ■ Touch the Start/Stop sensor. This switches Standby off.
The programme duration remaining that is shown in the display fluctuates.	The countdown time adapts constantly to the current washing and drying situation.

## General problems with the washer-dryer

Problem	Possible cause and remedy
Foam comes out of the detergent dispenser drawer while the <i>Rinse out fluff</i> programme is running.	There is residual detergent from the last programme in the suds container.  Make sure you always dispense the correct amount of detergent. For precise dispensing, use automatic detergent dispensing.
There is foam in the drum at the end of the Rinse out fluff programme.	The Rinse out fluff programme also rinses out residual detergent from the suds container. This can lead to the formation of foam.  Run the Rinse out fluff programme regularly to prevent detergent residues from accumulating in the suds container.
There is still fluff in the drum after the end of the Rinse out fluff programme.	You have not run the <i>Rinse out fluff</i> programme for a long time.  ■ Remove the fluff from the drum.  ■ Run the <i>Rinse out fluff</i> programme on a regular basis.
The washer-dryer smells.	The Hygiene info was ignored. A programme using a temperature above 60°C has not been run for a long time.  ■ In order to prevent bacteria and unpleasant odours building up in the machine, run the Clean machine programme using the Miele machine cleaner or powder detergent.  The detergent dispenser drawer was left closed after
	washing.  Leave the detergent dispenser drawer slightly open to allow it to dry.

## An unsatisfactory wash result

Problem	Possible cause and remedy
White residues which look like powder detergent are seen on dark textiles after washing.	<ul> <li>The detergent contains compounds (zeolites) to aid water softening which are not soluble in water. These have ended up on the laundry.</li> <li>Try and brush off the residues with a soft brush once the laundry is dry.</li> <li>In the future, wash dark textiles with a detergent which contains no zeolites. Liquid detergents do not usually contain zeolites.</li> <li>Use the <i>Dark garments</i> programme.</li> </ul>
Liquid detergent does not give the required result.	Liquid detergents usually contain no bleaching agents. They do not remove fruit, coffee and tea stains.  Use the Miele 2-phase system.  The targeted addition of UltraPhase 2 during the wash process removes stains effectively.  Use a general purpose powder detergent containing a bleaching agent.
Grey, greasy particles cling to washed laundry.	<ul> <li>Insufficient amounts of detergent were used. The laundry was heavily soiled with grease (oils, ointments).</li> <li>Use more detergent or liquid detergent with this type of soiled laundry.</li> <li>Before washing the next load, run the Clean machine programme using the Miele machine cleaner or a powder detergent.</li> </ul>

## Unsatisfactory drying result


Problem	Possible cause and remedy
The laundry is too damp after drying and Check load appears in the display	<ul> <li>The load is too small. The electronics could not assess the residual moisture correctly.</li> <li>Start the programme again and instead of a drying level select a <i>Timed drying</i> programme.</li> <li>In the future use a <i>Timed drying</i> programme for small amounts of laundry.</li> </ul>
	During the spin cycle, the laundry formed a ring in the drum because the laundry was distributed unevenly.  The laundry formed a ring during the thermospin because it was too damp or because the spin speed was set too high.  Open the door and loosen the laundry.  Start the drying programme again with a lower spin speed, or select <i>Timed drying</i> instead of a drying level.
The laundry feels damp after drying.	The Pre-ironing Extra was selected. ■ Unload the laundry and place it on hangers to finish drying.
	Warm laundry can feel damp. ■ Spread the laundry out to cool it down.
The laundry is too damp or too dry after a drying cycle.	The desired residual moisture level is between two drying levels.  Change the level of drying as described in "Settings - Drying levels".
There is still water in the drum after drying.	There is a blockage in the water outlet.  Clean the drain filter and the drain pump as described in "Opening the door in the event of a blocked drain outlet and/or power cut" and check the height of the drainage point.

## The door will not open

Problem	Possible cause and remedy
The door cannot be opened while a programme is running.	The door is locked during a programme.  ■ Follow the instructions in "Washing – 6. Starting a programme".
	There is still water in the drum and the washer-dryer is unable to drain.  Clean the drain filter and the drain pump as described in "Opening the door in the event of a blocked drain outlet and/or power cut".
	The water level in the drum is too high.  Cancel the programme. The water will be pumped away.
At the end of the programme or after a programme cancellation: Extra cooling appears in the display.	For safety reasons, the door cannot be opened if the temperature in the drum exceeds 55°C during washing or 70°C during drying.  ■ Wait until the temperature in the drum has decreased and the message has gone out in the display.
The following appears in the display: The door lock is jammed. Call Miele.	The door lock has jammed.  ■ Call Miele.

# Opening the door in the event of a blocked drain outlet and/ or power cut

■ Switch the washer-dryer off.



■ Open the drain pump access panel.

#### **Blocked drain outlet**

If the drain outlet is blocked, a large quantity of water can remain in the washer-dryer.


Risk of scalding due to hot suds. Escaping suds will be hot if laundry has been washed at high temperatures.

Drain the suds carefully.

## Procedure for draining the machine


Remove the drain filter, though not completely.

Place a suitable container under the access panel, e.g. a universal oven tray.




- Slowly unscrew the filters until water runs out. Be careful not to release too much water at once. If the flow of water is too strong, some water can seep into the machine base and activate the water protection float switch. This will prevent the machine from functioning.
- To interrupt the flow of water, tighten the filters again.

Once the flow of water ceases:




■ Remove the filters completely.

#### Cleaning the drain filters



- Clean the filters thoroughly.
- Remove any foreign objects (e.g. buttons, coins) and clean the interior. Turn the impellers by hand to check that they rotate freely.



Replace the filters correctly (on the right and left) and tighten them.

A Risk of damage from leaking water.

Water will escape from the washerdryer if you forget to replace the drain filters.


Replace the drain filters correctly and tighten them securely.

### Opening the door

Danger of injury due to rotating drum!

Reaching into a moving drum is extremely dangerous. Danger of injury!

Always make sure that the drum is stationary before reaching in to remove laundry.



- Use a screwdriver to unlock the door of the appliance as shown.
- Pull open the door.

#### Contact in case of fault


In the event of any faults which you cannot remedy yourself, please contact Miele.

You can book a Miele customer service call-out online at www.miele.com.au/service or www.miele.co.nz/service.

Contact information for Miele can be found at the end of this booklet.

Please quote the model and serial number of your appliance when contacting Miele. This information can be found on the data plate.

The data plate is found above the porthole glass when the door is opened.



## Warranty


The manufacturer's warranty for this appliance is 2 years.

For further information, please refer to your warranty booklet.

## **Optional accessories**

Optional accessories for this washerdryer are available from Miele.


#### Front view



- ① Water inlet hose (waterproof metal, braided)
- ② Electrical connection
- ③ Flexible drain hose (with detachable swivel elbow)
- 4 Control panel

- 5 Detergent dispenser drawer
- 6 Door
- Access to drain filters, drain pump and emergency release
- 8 Access panel for TwinDos containers
- 9 4 height-adjustable feet

## **Rear view**



- 1 Protruding lid for holding when moving the machine
- 2 Drain hose
- 3 Water inlet hose

- 4 Safety caps for transit bars
- 5 Transport clips for water inlet hoses and drain hoses
- 6 Electrical connection

#### Installation surface

A concrete floor is the most suitable installation surface. It is far less prone to vibration during the spin cycle than wooden floorboards or a carpeted surface.

#### Please note:

- The washer-dryer must be level and securely positioned.
- To avoid vibrations during spinning the washer-dryer must not be installed on soft floor coverings.

If installing on a wooden joist floor, please note:

- Check for the presence of pipes and cables first.
- Use a plywood base underneath the washer-dryer (at least 59 x 60 x 3 cm). The base must span several joists and be bolted to the joists and not only to the floorboards.

**Useful tip:** If possible, install the washer-dryer in a corner of the room, as this is usually the most stable part of the floor.

# Carrying the washer-dryer to its installation site

Danger of injury due to unsecured lid.


Make sure the fixings at the back of the lid are secure. They may become brittle due to external circumstances. There is a danger of the lid being pulled off when carrying the appliance.

Before carrying the machine, check that the lid is secure where it protrudes at the back of the machine.


Carry the washer-dryer by the front feet and by the lid where it protrudes at the back of the appliance.

## Removing the transit bars

## Removing the left transit bar




■ Push the flap outwards and turn the transit bar 90° using the enclosed spanner.




■ Then pull the transit bar out.

## Removing the right transit bar




■ Push the flap outwards and turn the transit bar 90° using the enclosed spanner.



■ Then pull the transit bar out.

#### **Covering the holes**

Pisk of injury from sharp edges!
There is a risk of injury from reaching into holes that are not covered.
The holes for the transit bars must be covered after the transit bars have been removed.



■ Press the flaps firmly shut until they click into place.


## Refitting the transit bars

Risk of damage from incorrect transport.

The washer-dryer may become damaged if moved without the transit bars in place.

Keep the transit bars in a safe place. Fit them again if the washer-dryer is to be moved (e.g. when moving house).

## Opening the flaps



Push against the catch with a pointed object, e.g. a narrow screwdriver.

The flap will open.

## Fitting the transit bars

 Install the transit bars in reverse order to their removal.

**Useful tip:** If you lift the drum slightly, the transit bars can be pushed in more easily.

## Levelling the washer-dryer


The washer-dryer must stand perfectly level on all four feet to ensure safe and proper operation.

Incorrect installation may increase electricity and water consumption and may cause the machine to move about.


The appliance must not be installed behind a lockable door, a sliding door or a door with a hinge on the opposite side to that of the appliance, in such a way that a full opening of the appliance door is restricted.

#### Screwing out and adjusting the feet

The 4 adjustable feet are used to level the washer-dryer. All four feet are screwed in when the appliance is delivered.



Using the spanner supplied, turn counter nut 2 in a clockwise direction. Then turn counter nut 2 together with foot 1 to unscrew.



- Use a spirit level to check the washer-dryer is standing level.
- Hold foot 1 securely with a pipe wrench. Turn counter nut 2 again using the spanner supplied until it sits firmly up against the housing.

Risk of damage from incorrectly aligned washer-dryer.

There is a danger of the washerdryer moving about if the feet are not secured.

Turn all 4 counter nuts for the feet until they sit firmly up against the casing. Please also check this for the feet which did not need adjustment.

# The Miele water protection system

The water protection system protects all parts of the washer-dryer from water damage.

The system consists of three main components:

- the inlet hose
- the electronic unit, and the drainage and overflow protection
- the drain hose

#### Inlet hose

 Protects the safety valve from bursting

The inlet hose can withstand pressure of more than 14,000 kPa.

- Protective sleeve

The inlet hose has a protective sleeve which is made from metal braiding as a "second skin" to protect the hose against damage.

#### **Electronic unit and machine housing**

- Sump

Any leaking water is collected in a sump in the base of the machine. A float switches off the water inlet valves. Further water intake is blocked. The water inside the suds container is pumped out.

- Overflow protection

This prevents the machine from taking in too much water and overflowing. If the water level exceeds a certain level, the drain pump switches on and pumps the excess water away.

#### **Drain hose**

The drain hose is protected by a ventilation system which prevents the machine from being emptied completely.

#### Water intake

Health risk and risk of damage due to contaminated incoming water. The quality of the water used must correspond to the drinking water specification of the country in which the appliance is being operated. Always connect the appliance to potable water.

The washer-dryer must be connected to a mains water supply in accordance with current local and national safety regulations.

The water inlet pressure must be at least 100 kPa and must not exceed an overpressure of 1000 kPa. If the pressure exceeds 1000 kPa, a pressure reducing valve must be installed.

Connection to the mains water supply should incorporate a water tap with a ¾" threaded union. If no tap is available, only a qualified installer may connect the washer-dryer to the mains water supply.

The connection point is subject to mains water pressure.

You should turn on the tap slowly and check for leaks. Correct the position of the seal and screw thread if water escapes.

The washer-dryer is **not** suitable for connection to a hot water supply.

#### Maintenance

Only use a genuine Miele hose that has been pressure tested to withstand at least 14,000 kPa should you ever need a replacement.

The dirt filter in the union nut at the open end of the water inlet hose protects the water intake valve.

This filter must not be removed.

## **Drainage**

The suds are drained through a drain pump with a 1 m delivery head. For the water to drain freely, the hose must be installed free of kinks. The elbow piece supplied hooks onto the end of the hose. If required, the hose can be extended to a length of up to 5 m. The necessary parts can be purchased from Miele

For a delivery head of more than 1 m (up to a max. of 1.8 m) a replacement drain pump will need to be fitted. Please contact Miele for advice. In this case the hose can be extended to a maximum of 2.5 m. The necessary parts can be purchased from Miele.


#### **Drain hose connection options**

1. Directed into a sink or basin.

#### Please note:

- Hook the hose over the edge and secure it.
- Make sure that the water can drain away freely without hindrance.
   Otherwise there is a risk of water overflowing or of some of the drained water being sucked back into the machine.
- 2. Connected securely to a plastic drain pipe with a rubber nipple (there is no need to use a siphon).
- 3. Connected securely to a floor drain (gully).
- 4. Connected securely to a standpipe.

#### Connecting to a washbasin



- 1 Adapter
- Washbasin nut
- 3 Hose clip
- 4 End of the hose
- Fit the adapter ① to the sink drain outlet using the nut ②.
- Attach the end of the hose ④ to the adapter ①.
- Use a screwdriver to tighten the hose clip ③ up close to the nut.

## **Electrical connection**

The washer-dryer is supplied with a mains cable with moulded plug ready for connection to a 230V electricity supply. The voltage, rated load and plug rating are given on the data plate. Please ensure these match the household mains supply.

The socket must be easily accessible after the washer-dryer has been installed. If the switch is not accessible after installation an additional means of disconnection must be provided for all poles.

Risk of fire from overheating. Connecting the washer-dryer to a multi-socket adapter or to an extension lead can overload the cable.

For safety reasons, do not use an extension lead or multi-socket adapter.

All electrical work must be carried out by a suitably qualified and competent person, in strict accordance with national and local safety regulations. For extra safety, it is advisable to install a residual current device (RCD) with a trip current of 30 mA. Ensure power is not supplied to the appliance until after the installation has been completed. Connection should be made via a suitable switched socket.

If the connection cable is damaged, it must only be replaced with a specific connection cable of the same type (available from Miele) in order to avoid a hazard. For safety reasons, such

replacement may only be carried out by a suitably qualified and competent technician or by Miele.

The data plate indicates the nominal power consumption and the appropriate fuse rating. Compare the specifications on the data plate with those of the mains electricity supply.

If in any doubt, consult a qualified electrician.

Temporary or permanent operation with a self-sufficient or non-mains synchronous energy supply system (e.g. isolated networks, back-up systems) is possible. A requirement for the operation is that the energy supply system complies with all current local and national requirements that apply to stand-alone, solar and/or battery systems".

The protective measures provided in the domestic installation and in this Miele product must also be assured in their function and operation in isolated operation or in non-mains synchronous operation, or replaced with equivalent measures in the installation.

The machine must not be used with socalled energy-saving devices either. These reduce the amount of energy supplied to the machine, causing it to overheat.

## **Technical data**

Height	850 mm
Width	596 mm
Depth	714 mm
Depth with door open	1132 mm
Weight	Approx. 102 kg
Capacity, washing Capacity, drying	9.0 kg dry laundry 5.0 kg dry laundry
Supply voltage	see data plate
Rated load	see data plate
Fuse rating	see data plate
Minimum water flow pressure	100 kPa (1 bar)
Maximum water flow pressure	1,000 kPa (10 bar)
Water inlet hose length	1.55 m
Drain hose length	1.50 m
Mains connection cable length	2.00 m
Drain pump head height max.	1.00 m
Drain pump length max.	5.00 m
LEDs	Class 1
Test certifications awarded	see data plate
Frequency band	2.4000 GHz – 2.4835 GHz
Maximum transmission power	< 100 mW

						loubiood	
Programmes	Load	Energy	Water	Duration	Temperature	moisture	Spin speed
	- Kg	kWh	Litres	h:min	ô	%	rpm
Washing							
Cottons 60	9.0	1.45	99	2:29	99	20	1600
20	0.6	0.45	75	2:39	20	20	1600
Minimum iron 30	4.0	0.34	52	1:59	30	30	1200
Express <sup>2</sup> 40	3.5	0.33	30	0:20	26	09	1200
Woollens 30	2.0	0.23	35	0:39	ı	ı	ı
QuickPower 40	4.0	0.58	40	0:49	ı	1	ı
Drying							
Cottons	5.0	2.45	22	2:30	ı	1	ı
Minimum iron	4.0	1.44	14	1:33	ı	ı	ı

Maximum laundry temperature reached in main wash.

<sup>2</sup> Q*uick* Extra activated

TwinDos dispensing must be deactivated when carrying out comparison tests.

# Information for customers:

Consumption data can vary from the nominal values listed depending on water pressure, water hardness, water inlet temperature, room temperature, type and volume of load, fluctuations in the electricity supply and any Extras selected.

## **Garment care label symbols**

Washing				
The figure quoted in the bucket is the maximum temperature at which the garment can be washed.				
95	Normal agitation			
60	Reduced agitation			
30	Much reduced agitation			
Tall I	Hand wash			
M	Do not wash			

# Programme selection examples

Programme	Garment care label symbols
ECO 40-60	40 60
Cottons	95 70 60 50 40 30
Minimum iron	95 60 50 40 30
Delicates	40 30
Woollens	Tab

Drying		
$\odot$	Normal temperature	
$\odot$	Low temperature	
	Do not tumble dry	

Ironing			
<b>=</b>	Approx. 200 °C		
<b>a</b>	Approx. 150 °C		
æ	Approx. 110 °C		
	Ironing with steam can cause irreversible damage.		
×	Ironing prohibited		

Professional cleaning				
F	Dry clean only. The letters			
P	indicate the type of cleaning agent required.			
w	Wet cleaning			
$\otimes$	Dry cleaning prohibited			

Bleaching			
Δ	Any oxidation bleach can be used		
<b>A</b>	Use oxygen bleach only		
$\Diamond$	Do not bleach		

Default settings can be altered to adapt the washer-dryer to different requirements. Settings can be altered at any time.


## Calling up settings

- Switch the washer-dryer on.
- Scroll through the main menu until Settings appears.
- Touch the Settings sensor.

The display will change to show the Settings menu.

## Selecting settings

The settings are grouped into different areas.



- Select the required area.
- Scroll through the list until the setting you want appears.
- Touch the sensor to select the setting you require.

## Changing a setting

- Change the value displayed and confirm with *OK* ...
- ... or touch an option to select it.

An option which is selected will be highlighted orange.

The option is saved. The display will then switch to the Settings menu, or go back to the previous menu level.

## Closing the Settings menu

■ Touch the sensor.

The display will go back to the previous menu level.

■ Touch the sensor.

The display will change to the main menu.

## Controls / Display

## Language 🏲

The display can be set to appear in one of several different languages.

The flag after the word Language acts as a guide in case a language which is not understood is set.

The language selected is saved.

#### Code

The code prevents the washer-dryer being used without your knowledge.

## **Options**

Activate

The factory default code is 125 and can be activated. When the code has been activated, you have to enter the code after switching the washerdryer on. Otherwise the washerdryer cannot be operated.

- Deactivate

For using the washer-dryer without entering the code. This only appears if the code has been activated previously.

- Change

You can enter any code.

If you forget the code, the washerdryer will have to be unlocked by a Miele service technician.

Important! Make a note of your new code.

## Memory

The washer-dryer will save the last settings selected for a programme (temperature, spin speed and some of the Extras) after the programme has started.

The next time the programme is chosen these saved settings will appear in the display.

Factory default setting: Memory is switched off.

## **Clock display**

If the clock format has been set, the time of day can be set.

## Clock format

- 24 h clock (factory default setting)
- 12 h clock

## <u>Time</u>

- The time can be set.

#### Volume

The volume for various sounds can be changed.

- Finish tone
- Keypad tone
- Welcome tone

It can be set to one of seven different settings or switched off altogether.

## **Display brightness**

The brightness of the display can be altered.

It can be set to one of seven different settings.

## Temperature unit

The temperature can be displayed as degrees Celsius (°C) or Fahrenheit (°F).

Factory default setting: Celsius (°C).

## Programme sequence

#### **TwinDos**

You can set and check the type of detergent and dispensing quantities.

## Select detergent

If you wish to use your own detergent with the TwinDos function instead of UltraPhase 1 and 2, you will need separate TwinDos refill containers (optional accessories).

UltraPhase 1 and 2 can only be dispensed as a package. If a different detergent is selected, the setting for the other compartment is automatically deleted.

The following detergents can be used:

- Miele UltraPhase 1
- Miele UltraPhase 2
- Universal detergent
- Colour detergent
- Delicates detergent
- Delicates/Woollens
- Fabric softener

Follow the manufacturer's instructions on dosage given on the packaging.

The dosage amount required for the agent being used must be set. Follow the instructions in the display on how to do so.

**Useful tip:** If you select No agent, the respective TwinDos compartment will be deactivated.

## Change dosage

The values set for dispensing detergent from compartments ① and ② can be checked and corrected.

## Soiling

You can specify the default setting for the degree of soiling.

- Light
- Normal (factory default)
- Heavy

## Water plus level

There are 4 different water levels which can be selected by activating the *Water plus* Extra.

## **Options**

- Normal (factory default setting)
- Plus A
- Plus ۵۵
- Plus ۵۵۵

## Maximum rinse level

The water level in the rinse can be permanently set to the highest value.

This function is important for allergy sufferers as it achieves excellent rinse results. The water consumption will be increased.

Factory default setting: the maximum rinse level setting is switched off.

#### Soak duration

You can set a duration for the soak process of between 30 minutes and 6 hours.

A duration can be selected in 30-minute increments. When the *Soak* Extra is selected, the laundry will be soaked for the duration selected.

A duration of 0:30 h is set as standard.

## Longer pre-wash Cottons

If you require a longer pre-wash, you can extend the standard pre-wash time of 25 minutes.

## **Options**

- Normal (factory default setting)
   25-minute pre-wash.
- + 6 min
  - 31-minute pre-wash.
- + 9 min
  - 34-minute pre-wash.
- + 12 min
  - 37-minute pre-wash.

#### Gentle action

With Gentle action activated, drum agitation is reduced. In this way, lightly soiled items can be washed more gently.

Gentle action can be activated for the *Cottons* and the *Minimum iron* programmes.

If Gentle action is activated, each wash phase in the programme selected will be run with the Gentle action wash rhythm.

Factory default setting: Gentle action is switched off

## Comp laundry protection

The maximum final spin speed can be limited to prevent laundry forming a ring around the drum.

The Comp laundry protection setting is only effective with continuous washing and drying.

## **Options**

- Off
- 900 (factory default setting)
- 1000
- 1100
- 1200

## **Drying levels**

You can adjust the drying levels in the Cottons, Minimum iron and Automatic plus programmes if needed.

It can be set to one of seven different settings.

#### Extended cool down

The cooling down phase which takes place before the end of a programme can be extended if required. This cools the garments down even more. The cooling down phase can only be extended if a drying level has been selected. Extended cool down is not active for timed drying.

The extended cool down time can be set between 0 min (factory default setting) and 18 min.

### Network

#### Miele@home

Control the networking of your washer-dryer with your Wi-Fi network.

## **Options**

- Set up

This message only appears if the washer-dryer has not yet been connected to a Wi-Fi network.

Please refer to "Before the first use" for instructions on how to set up the connection.

- Deactivate

The setting is only visible if Miele@home is activated.

Miele@home remains set up, the Wi-Fi function is switched off.

- Activate

The setting is only visible if Miele@home is deactivated.

The Wi-Fi function is reactivated.

Connection status

The setting is only visible if Miele@home is activated.

The Wi-Fi reception quality, network name and IP address are displayed.

- Set up again

The setting is only visible if Miele@home is set up.

Resets the Wi-Fi login (network) to immediately re-establish a new connection.

- Reset

The setting is only visible if Miele@home is set up.

The Wi-Fi function is deactivated and the Wi-Fi connection will be reset to the factory default.

The network configuration should be reset whenever the washer-dryer is being disposed of or sold, or if a used washer-dryer is being put into operation. This is the only way to ensure that all personal data has been removed and, in the case of the latter, the previous owner will no longer be able to access the appliance.

A new connection set-up has to be carried out in order to use Miele@home again.

#### Remote control

The Remote control setting (available depending on country) is only visible if the Miele@home setting is set up and activated.

If the Miele App has been installed on your mobile device, you can check the status of your washer-dryer from anywhere and start it remotely.

You can also operate your washerdryer remotely with the *MobileStart* programme.

You can switch off the Remote control setting if you do not want to operate the washer-dryer with your mobile device.

If Remote control is not switched on the App can cause the programme to be cancelled.

Use the Timer sensor to set a time by when you want to start the washer-dryer (see "Timer/SmartStart").

The washer-dryer will then start within the specified timeframe when it receives your signal.

If it has not received a start signal by the latest start time set, the washerdryer will start automatically.

Remote control is switched off by default.

#### **SmartGrid**

The SmartGrid setting (available depending on country) is only visible if the Miele@home setting is set up and activated.

This function can be used for starting your washer-dryer automatically at a time when energy costs are more economical.

Activating SmartGrid gives the *Timer* sensor a new function.

Set SmartStart by using the Timer sensor (see "Timer/SmartStart"). The washer-dryer will then start within the timeframe specified when it receives a signal from the energy supplier. If a signal has not been received from the energy supplier by the latest start time set, the washer-dryer will start automatically.

The SmartGrid function is switched off in the factory default setting.

## **Remote Update**

The Remote Update menu option is only displayed and can only be selected if the requirements for using Miele@home have been met (see "Before the first use – Miele@home").

The RemoteUpdate function is used for updating the software in your washerdryer. If an update is available for your washer-dryer, it will automatically download it. Updates will not be installed automatically. They must be initiated manually.

If you do not install an update, you can continue to use your washer-dryer in the usual way. However, Miele recommends installing updates.

## **Activating/Deactivating**

The RemoteUpdate function is activated as standard. Available updates will be downloaded automatically but will only be installed if you initiate the installation manually.

Deactivate RemoteUpdate if you do not want any updates to be downloaded automatically.

## Running a RemoteUpdate

Information about the content and scope of an update is provided in the Miele App.

A message will appear in your washerdryer display if a software update is available.

You can install the update immediately or postpone this until later. When the washer-dryer is switched on again, you will be reminded about the update.

Deactivate RemoteUpdate if you do not want to install the update.

The update may take several minutes.

#### Please note:

- You will only receive a message when an update is available.
- Once an update has been installed, it cannot be undone.
- Do not switch off the washer-dryer during an update. Otherwise, the update will be aborted and will not be installed.
- Some software updates can only be carried out by a Miele service technician.

## **Appliance parameters**

# Copyright and licences for operating and control software

For the purpose of operating and controlling the appliance, Miele uses proprietary or third-party software that is not covered by open source licensing terms. These items of software/software components are protected by copyright. The copyright powers of Miele and third parties must be respected.

In addition, the appliance contains software components which are distributed under open source licensing terms. You can access these open source components along with the associated copyright notices, copies of the valid licensing terms and any further information in the appliance under the menu option Settings | Appliance parameters | Legal information | Open source licences. The liability and warranty arrangements for the open source licences displayed at this location only apply in relation to the respective rights holders.

# Copyright and licences for the communication module

For the purpose of operating and controlling the communication module, Miele uses proprietary or third-party software that is not covered by open source licensing terms. These items of software/software components are protected by copyright. The copyright powers of Miele and third parties must be respected.

In addition, the communication module contains software components which are distributed under open source licensing terms. The open source components contained in the appliance along with the corresponding copyright notices, copies of the licensing terms valid at the time, and any further information can be accessed locally via IP using a web browser (http://<IP address>/Licenses). The liability and warranty arrangements for the open source licences displayed in this location only apply in relation to the respective rights holders.

## **Installation requirements**

## Low water pressure

If the water pressure is below 100 kPa (1 bar), the washer-dryer will stop the programme and a water intake fault message will appear.

If the on-site water pressure cannot be increased and the water pressure is constantly low, activating this setting will prevent the programme from being cancelled

Factory default setting: Low water pressure is switched off.

## **Suds cooling**

Additional water flows into the drum at the end of the main wash to cool the suds down. Hot suds can damage plastic drainage pipes.

Suds cooling takes place when a Cottons programme with a temperature of 70°C or higher is selected.

Activate suds cooling:

- to prevent the danger of scalding if the drain hose is hooked over the edge of a sink or laundry tub.
- where the drainage pipes are rated less than 70°C.

Factory default setting: Suds cooling is switched off.

## **Temperature reduction**

At high altitudes water has a lower boiling point. Miele recommends activating the reduced temperature setting at altitudes of 2000 m or above to prevent water from boiling. The maximum temperature is reduced to 80°C even if a higher temperature is selected.

Factory default setting: the reduce temperature setting is switched off.

## **Detergents and care products**

Detergent, fabric care, additives and machine care products are available for this machine. All the products have been designed for Miele appliances.

These and many other useful products can be ordered via the internet at shop.miele.com (depending on country) or from Miele (see end of this booklet for contact details).

## **Detergent**

## Miele UltraPhase 1 and 2

- 2-component detergent for whites and colours
- For bright colours and brilliant white laundry
- Excellent stain removal even at low temperatures

#### Miele UltraPhase 1 and 2 Sensitive

- 2-component detergent for whites and colours
- No fragrances or colourants especially kind to the skin
- Excellent stain removal even at low temperatures

## UltraWhite (powder detergent)

- Best results at 20/30/40/60/95°C
- Radiant white laundry thanks to powerful formula with active oxygen
- Excellent stain removal even at low temperatures

## UltraColor (liquid detergent)

- Best wash results at 20/30/40/60°C
- With colour-protection formula for brilliant colours
- Excellent stain removal even at low temperatures
- Also available as a powder detergent

## WoolCare delicates detergent (liquid detergent)

- For wool, silks and delicates
- Special care complex based on wheat protein and with colourprotection formula
- Best wash results at 20/30/40°C

## UltraDark (liquid detergent)

- For black and dark textiles
- With special colour-protection formula
- Anti-pilling effect protects your garments from discolouration
- Excellent stain removal even at low temperatures

## Sensitive Skin (powder detergent)

- High quality detergent formulated for people with sensitive skin
- Contains no dyes and preservatives
- Most suitable for white or light coloured textiles

## **Detergents and care products**

## Specialist detergents

These specialist detergents are available as convenient single-use capsules.

## **Caps Sport**

- For synthetic fabrics
- Neutralises odours thanks to built-in odour absorber
- Prevents static charge in clothes
- Retains the shape and breathability of synthetic fabrics

## Caps DownCare

- For down-filled items
- Retains the elasticity and breathability of downs
- Lanolin for effective cleaning and gentle care
- Feathers do not stick together and stay fluffy

## **Caps WoolCare**

- Woollens and delicates detergent
- Special care complex with wheat proteins
- Fibre protection technology to prevent felting
- Colour protection formula for gentle cleaning

## Caps CottonRepair

- Special detergent for cotton fabrics
- Visibly renews fabric with just one wash
- Special Miele formula with Novozymes technology
- Removes pilling and renews colour intensity and brightness
- Depending on fabric do not use more than 1–2 times per year

## **Detergents and care products**

## 

These fabric care products are available as convenient single-use capsules.

## **Caps Fabric Softener**

- Fabric softener for freshly scented laundry
- Pure and thorough cleanliness with a fresh scent
- For cuddly soft laundry
- Prevents static charge in clothes

## Additive

The additive is available as a convenient single-use capsule.

## Caps Booster

- Highly effective stain remover
- Enzyme technology to help remove stubborn stains
- Suitable for whites and colours
- For excellent wash results even at low temperatures

## Machine care products

#### **TwinDosCare**

- Cleaning agent for the TwinDos dispensing system
- Use before a longer downtime (at least 2 months)
- Use before changing to a different product

## **Descaling agent**

- Removes heavy limescale deposits
- Mild and gentle with natural citric acid
- Gentle on heater elements, drum and other components

#### IntenseClean

- For hygienic cleanliness in washing machines
- Removes grease, bacteria and unpleasant odours
- Effective thorough cleaning

## Miele Australia Pty. Ltd.

ACN 005 635 398 ABN 96 005 635 398

## Miele Head Office Melbourne:

Level 4, 141 Camberwell Road Hawthorn East, VIC 3123

## Miele Experience Centre Doncaster:

1136/7 Doncaster Shopping Centre 619 Doncaster Rd, Doncaster, VIC 3108

## Miele Experience Centre South Melbourne:

206-210 Coventry Street South Melbourne, VIC 3205

## Miele Experience Centre and Office Sydney:

3 Skyline Place Frenchs Forest, NSW 2086

## Miele Experience Centre and Office Brisbane:

Tenancy 4C, 63 Skyring Terrace Newstead, QLD 4006

## Miele Experience Centre Gold Coast:

131 Ferry Road Southport, QLD 4215

## Miele Experience Centre and Office Adelaide:

83-85 Sir Donald Bradman Drive Hilton, SA 5033

## Miele Experience Centre and Office Perth:

205-207 Stirling Highway Claremont, WA 6010

## 1300 464 353 (1300 4 MIELE)

www.miele.com.au

#### Miele New Zealand Limited

IRD 98 463 631

# Miele Experience Centre and Head Office Auckland:

8 College Hill Freemans Bay, Auckland 1011

# Miele Experience Centre Wellington:

183 Featherston Street Wellington 6011

## 0800 464 353 (0800 4 MIELE) www.miele.co.nz

Miele Global Headquarters Germany Miele & Cie. KG

Carl-Miele-Straße 29 33332 Gütersloh Federal Republic of Germany



WTW 870 WPM