

Operating instructions

Coffee maker



To avoid the risk of accidents or damage to the appliance, it is **essential** to read these instructions before it is installed and used for the first time.

Packaging material / Disposal of old machine

Packaging material

The packaging material used protects the machine during transportation. Please retain the original box and polystyrene pieces so that you can pack the machine securely, should you need to transport it in the future.

The original packaging should also be kept in case the machine ever needs to be returned to Miele for servicing.

Disposing of your old appliance

Electrical and electronic appliances often contain valuable materials. They also contain specific materials, compounds and components, which were essential for their correct function and safety. These could be hazardous to human health and to the environment if disposed of with your domestic waste or if handled incorrectly. Please do not, therefore, dispose of your old appliance with your household waste.



Please dispose of it at your local community waste collection / recycling centre for electrical and electronic appliances. You are also responsible for deleting any personal data that may be stored on the appliance prior to disposal. Please ensure that your old appliance poses no risk to children while being stored prior to disposal.

Contents

Packaging material / Disposal of old machine	2
Warning and Safety instructions	7
Guide to the appliance	17
Accessories	19
Operating principles	20
Touch display	20
Operating actions	20
Symbols in the display	22
Before using for the first time	23
Before using for the first time	23
Switching on for the first time	23
Filling the water container	26
Filling the coffee bean container	27
Switching on and off	28
Spout adjustment	29
Cup heating	30
Making coffee	31
Making a coffee drink	31
Cancelling preparation	32
DoubleShot	32
Double portion 	32
Coffee pot - Preparing several cups of coffee	33
Drinks made with ready ground coffee	33
Making coffee with milk	35
Milk flask	36
Using milk cartons or bottles	37
Preparing drinks with milk	37
Making tea	38
Making tea	39
Teapot - Preparing several cups of tea	39
Preparing hot water	40
Grinder setting	41

Contents

Drink parameters	42
Amount of coffee	42
Brewing temperature	43
Pre-brewing ground coffee.....	43
Portion size	44
Resetting drink settings	45
User profiles	46
Calling up User profiles	46
Creating a User profile.....	46
Selecting a User profile	46
Processing User profiles	46
User profiles: creating and processing drinks	48
User profiles: making drinks	49
Expert mode	50
Settings	51
Calling up the Settings menu	51
Changing and saving settings	51
Overview of available settings.....	52
Language.....	54
Time of day.....	54
Timer	55
Expert mode	56
Eco mode	56
Descaling.....	56
Lighting.....	57
Info (display information)	57
Locking the coffee machine (System lock )	57
Water hardness	58
Display brightness.....	58
Volume.....	58
Cup heating	58
Spout adjustment	58
Service.....	58
Evaporating the coffee machine.....	58
Demo mode.....	58
Factory default.....	59

Contents

Cleaning and care	60
Cleaning intervals - Quick guide	60
Unsuitable cleaning agents	61
Cleaning by hand or in the dishwasher	62
Drip tray and waste container	63
Drip tray cover	64
Water container	64
Water container filter	65
Central spout with cappuccinatore	66
Cup sensor	68
Stainless steel milk flask	68
Milk pipework	69
Coffee bean container	69
Ground coffee drawer	70
Remove the brew unit and wash by hand	70
Cleaning the housing	72
Maintenance programmes	72
Opening the "Maintenance" menu	72
Rinsing the appliance	73
Rinsing the milk pipework	73
Cleaning the milk pipework	74
Degreasing the brew unit	75
Water hardness	76
Automatic descaling	77
How does automatic descaling work?	77
The Miele descaling cartridge	78
Fitting and removing a descaling cartridge	78
Switching automatic descaling on and off	80
Please note before and during automatic descaling:	81
Setting the start time	81
Making drinks during automatic descaling (activation phase)	82
Manual descaling	83
Problem solving guide	86
Messages in the display	86
Unusual performance of the coffee machine	89
Faults with automatic descaling	93
Unsatisfactory results	94
Transporting the machine	96
Evaporating the coffee machine	96

Contents

Packing.....	97
After sales service and warranty	98
Saving energy	99
Electrical connection	100
Installation.....	101
Appliance dimensions	102
Technical data.....	103

Warning and Safety instructions

This coffee machine conforms to current safety requirements. Improper use of the appliance can, however, present a risk of both personal injury and material damage.

To avoid the risk of accidents and damage to the appliance, please read these instructions carefully before installation and before using it for the first time. They contain important notes on the installation, safety, operation and care of the appliance. Miele cannot be held liable for damage caused by non-compliance with these Warning and Safety instructions.

Keep the instructions in a safe place and pass them along to any future owner.

Warning and Safety instructions

Correct application

- ▶ This appliance is designed for domestic use and for use in similar environments by guests in hotel or motel rooms, bed & breakfasts and other typical living quarters. This does not include common/shared facilities or commercial facilities within hotels, motels or bed & breakfasts.
- ▶ The machine is intended only for the preparation of drinks such as espresso, cappuccino, latte macchiato, tea etc. Any other usage is at the owner's risk.
- ▶ The coffee machine is not suitable for outdoor use.
- ▶ This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning its use by a person responsible for their safety, and are able to recognise the dangers of misuse.

Safety with children

 Caution! Danger of burning and scalding on the dispensing spouts.

Children's skin is far more sensitive to high temperatures than that of adults.

Ensure children do not touch hot surfaces of the coffee machine or place parts of their body under the dispensing spouts.

- ▶ Install the coffee machine out of reach of children.
- ▶ Young children must be kept away from the machine and the mains connection cable and plug/socket.
- ▶ Older children may only use the coffee machine unsupervised if they have been shown how to use it safely and recognise and understand the consequences of incorrect operation.
- ▶ Children should be supervised when they are near the coffee machine. Do not allow them to play with it or to use the controls.
- ▶ Young children must not be allowed to clean the coffee machine. Older children may only clean it under the supervision of an adult.
- ▶ Remember that coffee and espresso are not suitable drinks for children.
- ▶ Risk of suffocation!
Children may be able to wrap themselves in packing material or pull it over their head with the risk of suffocation. Keep children away from any packing material.

Warning and Safety instructions

Technical safety

- ▶ A damaged coffee machine is dangerous. Check it for any visible damage before setting it up. Never attempt to use a damaged coffee machine.
- ▶ Before connecting the appliance to the mains supply, make sure that the rating on the data plate corresponds to the voltage and frequency of the household supply. This data must correspond in order to avoid the risk of damage to the appliance. Consult a qualified electrician if in any doubt.
- ▶ The electrical safety of this appliance can only be guaranteed when continuity is complete between it and an effective earthing system. It is most important that this basic safety requirement is present and tested regularly and, where there is any doubt, the household wiring system should be inspected by a qualified electrician.
- ▶ Reliable and safe operation of the coffee machine can only be guaranteed if it is connected to the mains electrical supply.
- ▶ Do not connect the machine to the mains electricity supply by a multi-socket adapter or an extension lead. These do not guarantee the safety of the appliance (e.g. danger of overheating).
- ▶ This appliance must not be installed and operated in mobile installations (e.g. on a ship).
- ▶ Unplug the coffee machine from the power supply immediately if you notice any damage or smell scorching, for example.
- ▶ Ensure that the mains connection cable cannot be pinched or damaged by any sharp edges.
- ▶ The mains connection cable should not hang down. Someone could trip over it with the risk of injury and the machine could be damaged.

Warning and Safety instructions

- ▶ Only use the coffee machine in rooms where the ambient temperature is between +16 °C and +38 °C.
- ▶ Do not place the coffee machine near a window in direct sunshine or right next to an appliance that gives off heat. These would subject the machine to ambient temperatures outside its permitted operating range.
- ▶ Danger of overheating! Ensure that there is sufficient ventilation around the coffee machine. Do not cover it with tea towels etc. whilst it is in use.
- ▶ If the coffee machine is installed behind a kitchen furniture door, it may only be used with the furniture door open. This will prevent the formation of heat and humidity and subsequent damage to the appliance and/or furniture unit. Do not close the furniture door while the coffee machine is in use. Ensure the coffee machine has cooled down completely before closing the furniture door.
- ▶ Protect the coffee machine from water and water spray. Do not immerse the machine in water.
- ▶ Repairs and other work by unqualified persons to the machine and the connection cable could be dangerous. The manufacturer cannot be held liable for unauthorised work. Repairs may only be carried out by a Miele authorised service technician.
- ▶ The manufacturer's warranty will be invalidated if the appliance is not repaired by a Miele approved service technician.
- ▶ Faulty components must only be replaced by genuine Miele original spare parts. The manufacturer can only guarantee the safety of the appliance when Miele replacement parts are used.

Warning and Safety instructions

- ▶ Before any repair work is carried out, the appliance must be completely disconnected from the electricity supply. The appliance is only completely isolated from the electricity supply when:
 - it is switched off at the wall socket and the plug is withdrawn from the socket. Do not pull the mains connection cable but the mains plug to disconnect your appliance from the mains electricity supply.
 - the mains circuit breaker is switched off.
- ▶ Never open the outer casing of the machine. Tampering with electrical connections or components and mechanical parts is highly dangerous to the user and can cause operational faults or electric shock.
- ▶ Disconnect the coffee machine from the power supply if it is not going to be used for a while, e.g. while on holiday.
- ▶ Use only Miele original spare parts. If spare parts or accessories from other manufacturers are used, the warranty will be invalidated, and Miele cannot accept liability.

Correct use

 Danger of burning and scalding on the dispensing spouts!
The liquids and steam dispensed are very hot.

Keep well away from the area underneath the spouts when hot liquids and steam are being dispensed.

Heating surfaces have residual heat after use. Do not touch hot components.

Hot liquid or steam could spatter from the spouts. Ensure that the central spout is clean and fitted correctly.

Water in the drip tray can also be very hot. Take care when emptying it.

► Please note the following regarding water:

- Fill the water container only with fresh, cold tap water. Hot or warm water or other liquids could damage the coffee machine.
- Change the water every day to prevent a build-up of bacteria.
- Do not use mineral water. Mineral water will cause serious limescale deposits to build up in your machine and damage it.
- Do not use water from reverse osmosis units. The machine could be damaged.

► Only fill the bean container with roasted espresso or coffee beans. Do not fill the bean container with coffee beans which have been treated, e.g flavoured or caramelised, or with ground coffee.

► Do not fill the bean container with any type of liquid.

► Do not use green (unroasted) coffee beans or mixtures of coffee beans which contain green coffee beans. Green coffee beans are very hard and still contain a certain amount of residual moisture. These can damage the coffee machine grinder as soon as grinding begins.

► Do not use coffee beans which have been treated with caramel, sugar or other substances. Sugar will damage the coffee machine.

Warning and Safety instructions

- ▶ Only add ground coffee or cleaning tablets to the ground coffee chute.
- ▶ Do not use any caramelised ready ground coffee. The sugar in the coffee will stick to and block the brew unit of the coffee machine. The cleaning tablets for degreasing the brew unit will not remove this type of deposit.
- ▶ Only use milk without additives. Additives in milk usually contain sugar and this will stick to the milk pipework.
- ▶ If using cow's milk, only use pasteurised milk to prevent a build-up of bacteria in the appliance.
- ▶ When making tea, please follow the instructions on the packaging.
- ▶ Do not place any alcohol mixtures which are alight underneath the central spout. The flames could ignite plastic components and cause them to melt.
- ▶ Do not use naked flames, e.g. a candle, on or near the coffee machine. The coffee machine could catch fire with the risk of the fire spreading.
- ▶ The machine must not be used for cleaning objects.

Cleaning and care


- ▶ Disconnect the coffee machine from the power supply before cleaning.
- ▶ Clean the coffee machine and the milk flask daily, particularly before using for the first time (see "Cleaning and care").
- ▶ All parts of the milk system need to be cleaned thoroughly and regularly. Milk contains bacteria which proliferate rapidly with inadequate cleaning.
- ▶ Do not clean the machine with a steam cleaner or immerse it in water as this will damage the machine. Steam or water could reach the electrical components and cause a short circuit.
- ▶ Avoid spillage on appliance connectors.
- ▶ If you use hard water ($> 20 \text{ }^{\circ}\text{dH} / 3.6 \text{ mmol/l}$) or if the coffee machine is used intensively, it may be necessary to descale the machine manually in addition to automatic descaling.
- ▶ If you are descaling the coffee machine manually, carry out descaling regularly depending on the hardness level of your water. Descale the machine more frequently if you use very hard water. Miele cannot be held liable for damage arising from insufficient descaling, the use of incorrect descaling agents or the use of descaling agents which are not of the appropriate concentration.
- ▶ Degrease the brew unit regularly with Miele cleaning tablets. Depending on the natural oil content of the coffee used, the brew unit can become blocked quite quickly.
- ▶ Used coffee grounds should be disposed of with the organic rubbish or on the compost heap. Do not empty them down the sink, as they could block it.

Warning and Safety instructions

The following applies to appliances with stainless steel surfaces:


- ▶ Do not adhere stickers, adhesive tape or any other adhesive materials to the stainless steel surfaces.
- ▶ Stainless steel scratches very easily and even magnets can cause damage to the surface.

Guide to the appliance



- ① On/Off sensor ①
- ② "Back" ↺ sensor
- ③ Touch display
- ④ Cup heating
- ⑤ Water container
- ⑥ Coffee bean container
- ⑦ Park position for milk pipework
- ⑧ Grinder setting
- ⑨ Ground coffee drawer with integrated coffee scoop
- ⑩ Brew unit
- ⑪ Height-adjustable central spout with lighting and integrated hot water spout
- ⑫ Master switch
- ⑬ Drip tray with lid and waste container
- ⑭ Lower panel with drip tray cover
- ⑮ Stainless steel milk flask

Guide to the appliance



⑯ Cover

⑰ Descaling cartridge holder

⑱ Adapter

⑯ Miele descaling cartridge

These products and other useful accessories can be ordered via the Miele webshop or directly from Miele (see back cover for contact details).

Accessories supplied

- **Stainless steel milk flask MB-CM**
For keeping milk cool for longer (capacity 0.5 l)
- **Miele descaling cartridge**
For automatic descaling
- **Cleaning tablets**
For degreasing the brew unit
- **Descaling tablets**
For descaling the water pipework
- **Test strips**
For determining the water hardness level
- **Cleaning brush**
For cleaning the milk pipework

Optional accessories

Miele also offers a range of optional accessories, as well as cleaning and conditioning products for your coffee machine.

- **Original Miele all purpose microfibre cloth**
For removing finger marks and light soiling
- **Cleaning agent for milk pipework**
For cleaning the milk system
- **Cleaning tablets**
For degreasing the brew unit
- **Miele descaling cartridge**
For automatic descaling
- **Descaling tabs**
For manual descaling

Operating principles

Touch display

The display can be scratched by pointed or sharp objects, e.g. pens. Only touch the touch display with your fingertips.

Touching the display with your finger creates a tiny charge which releases an electrical impulse. This impulse is recognised by the touch display. The touch display does not react to contact with objects.

It is possible for the touch display to fail to react to finger contact if your fingers are cold.

The touch display is divided into three sections:



The top row shows you where you are in a menu. The time of day is shown on the right-hand side.

The middle row shows the current menu and options. The most popular drinks are depicted with symbols in the Drinks menu. See "Symbols in the display" for an explanation of the symbols.

You can scroll to the right or left using the < and > arrows at the bottom. Context-dependent functions and menus can be found to the left and right of the arrow sensors.

Operating actions

You can only select options which are highlighted in light grey.

Each time you touch a possible option the relevant field lights up partially or completely **orange**.

Selecting or calling up a menu

■ Touch the field you want with your finger.

Scrolling through menus

You can scroll left or right using the < and > arrow sensors.

■ Touch the arrow sensor for the direction you want to go.

Exiting a menu ("Back" ↲ sensor)

■ Touch the ↲ sensor to return to the previous screen.

All selected entries which have not been confirmed with OK will not be saved.

Entering numbers

Use the numerical keypad to enter numbers, e.g. if you want to set a timer duration. The numerical keypad will appear automatically in the relevant menus.



- Touch the numbers you want.

Once you have entered a valid number, OK will light up green.

- Touch OK.

You can delete one character at a time using the arrow sensor.

Entering letters

Profile names or the names for your own drinks are entered using a keyboard.

It is best to select short names (max. 8 characters).

Further letters or symbols can be accessed using the < and > arrow sensors. Numbers can be found by touching the 123 sensor.



- Select the letters or characters you want.

- Touch Save.

Operating principles

Symbols in the display

The following symbols may also appear in the display in addition to the text and drinks symbols:

Symbol	Explanation
=====	Some settings, e.g. display brightness and buzzer/keypad volume, are selected using a bar chart.
i	This symbol indicates that there is additional information and advice about using the coffee machine. Select OK to confirm the information.
	The system lock has been activated.
	This appears while the appliance is being descaled. (This symbol can also be found on the water container: fill up to this mark).


Drinks menu symbols

	Ristretto
	Espresso
	Coffee
	Cappuccino
	Latte macchiato
	Caffè latte

Before using for the first time

Before using for the first time


- Remove any protective foil and stickers from the machine. Exception: Please do not remove any labels (e.g. the data plate which are visible when you pull out the lower panel).



- Remove the protective foil from the drip tray and place the drip tray into the lower panel.
- Place the coffee machine on a flat surface that is not sensitive to water (see "Installation").

Clean the appliance thoroughly before filling it with water and coffee beans (see "Cleaning and care").


- Insert the plug of the coffee machine into the socket.
- Remove the water container and fill it with fresh, cold tap water. Only fill the water container up to the "max." marker and then push it back into the machine.
- Take the lid off the coffee bean container, fill it with roasted coffee beans and replace the lid.



Useful tip: The milk tube can be stored behind the appliance door when not in use.

Switching on for the first time

Switch the master switch on the right-hand side of the machine to the "I" position.



When you connect the machine to the mains power, the following message will appear in the display: Miele - Willkommen.

When you switch the coffee machine on for the first time, you will be prompted to set the following:

- Language and country
- Date
- Time of day

Before using for the first time

- Time of day display
- Touch the On/Off sensor ①.

Setting the language

- Select the language and touch OK.
- Select the country and touch OK.

The setting is now saved.

Setting the date

- Enter the current date and touch OK.

The setting is now saved.

Setting the time of day

- Enter the current time of day and touch OK.

The setting is now saved.

Time of day display

You can choose one of the following options:

- On: The time and date are always visible in the display when the appliance is switched off.
- Off: The display is dark when the machine is switched off.
- Night dimming: The date and the time are only displayed between the hours of 5:00 and 23:00.
- Select the time of day display and touch OK.

Depending on the setting selected, the coffee machine may use more energy. A message will appear in the display to inform you of this.

Select descaling method

Select one of the following descaling methods:

- Automatic descaling:
The coffee machine will be descaled automatically. For this method the Miele descaling cartridge has to be fitted. The Descale the machine maintenance programme does not have to be carried out.
- Manual descaling:
You have to carry out the Descale the machine maintenance programme yourself. You will be prompted when to run the descaling programme. The frequency will depend on the water hardness range set for your machine.
- Select the required option and touch OK.

If you have selected Automatic descaling and not yet fitted a Miele descaling cartridge, you will be prompted to do so.

Fitting the descaling cartridge

Observe the instructions given in "Automatic descaling – the Miele descaling cartridge".

- Remove the cover from the back of the coffee machine. Pull the cartridge holder forwards and insert the descaling cartridge.
- Push the holder back into position and refit the cover.

The descaling cartridge will fill with water the next time the machine is switched off.

Before using for the first time

A message will then appear regarding the current start time set for automatic descaling.

- Touch OK.

The coffee machine is now successfully set up for use.

- Fill the water container with fresh, cold tap water.

After setting the machine up you can make your first drinks. Coffee beans can be ground up to five times, as the coffee machine checks whether there is sufficient ground coffee to make an aromatic cup of coffee, and will grind more beans as necessary.


Filling the water container

 Change the water **every day** to prevent a build-up of bacteria.

Only use cold, fresh tap water to fill the water container.

Hot or warm water or other liquids can damage the coffee machine.

Do not use mineral water. Mineral water will cause serious limescale deposits to build up in your machine and damage it.



- Open the lid on the left-hand side of the coffee machine.
- Pull the water container up by the handle to remove it.
- Fill the water container with fresh, cold tap water up to the "max." mark.
- Replace the water container and close the lid.

If the water container sits a little too high or at an angle, check that it is fitted correctly or whether the surface that it sits on is soiled. If the water container is not sitting correctly, the drain valve will not be sealed.

If necessary clean the surface that the water container sits on.

Filling the coffee bean container

Fill the coffee bean container with roasted coffee or espresso beans if you want to use freshly ground coffee beans for each cup of espresso or coffee.

Alternatively, you can make coffee or espresso with ready ground coffee (see "Drinks made with ready ground coffee").

Important! Risk of damage to the grinder.

Only put roasted coffee or espresso beans in the container. Anything else, including ground coffee, will damage the grinder.

Do not fill the bean container with any type of liquid.

Important! Sugar damages the coffee machine.

Do not use coffee beans that have been treated with sugar, caramel, or other substances and do not put liquids containing sugar in the coffee bean container.

Do not use green (unroasted) coffee beans or mixtures of coffee beans which contain green coffee beans.

Green coffee beans are very hard and still contain a certain amount of residual moisture. These can damage the coffee machine grinder as soon as grinding begins.

Useful tip: You can use a nut or seed grinder to grind green coffee beans. These types of grinder generally have a rotating stainless steel blade. You can then add the ground green coffee **portion by portion** to the ground coffee chute and make the desired coffee drink (see "Making drinks with ready ground coffee").



- Take the lid off the coffee bean container.
- Fill the container with roasted coffee beans.
- Refit the lid.

Useful tip: Only add enough beans to last for a few days. Contact with air causes coffee beans to lose their aroma.

Switching on and off

Switching the coffee machine on

- Touch the On/Off sensor ①.

The appliance will begin rinsing after the heating-up phase. Hot water will run out of the central spout.

You can now prepare drinks.

If the coffee machine is already at operating temperature, rinsing will not take place.

Switching the coffee machine off

- Touch the On/Off sensor ①.

If coffee has been dispensed, the coffee machine will rinse the coffee pipework automatically before switching off.

Switching off for longer periods of time


If the coffee machine is not going to be used for a longer period of time, e.g. if you are going on holiday:

- Empty the drip tray, the waste container and the water container.
- Clean all parts thoroughly, including the brew unit.
- Switch the machine off with the master switch and at the wall socket.

The time of day set will be saved for a maximum of ten days and after that must be reset. Timer settings, profiles and other settings will be kept.

The height of the central spout **cannot** be manually adjusted.

Before making the drink, the central spout moves to the optimum height for the cups or glasses used.



You can switch off spout adjustment. The central spout will then remain in the upper position while the drinks are being made. When a maintenance programme is being carried out, the central spout will move to the height of the cleaning containers or into a maintenance position.

When the coffee machine is switched off, the components of the central spout can be dismantled and cleaned at any time. The central spout will be in the middle position when switched off.

Useful tip: To move the central spout into the maintenance position, touch  for three seconds.

Switching the spout adjustment on and off

The Drinks menu is visible in the display.

- Touch .
- Touch Settings .
- Select Spout adjustment with the  arrow sensor.
- Select the required option to switch spout adjustment on or off.
- Touch OK.

The setting is now saved.

Cup heating

Cups should always be pre-heated to allow the flavour of the coffee to develop and be retained.


The smaller the volume of the coffee/espresso and the thicker the cup, the more important it is to pre-heat the cup.

You can pre-heat cups or glasses on the cup heating surface on the top of the coffee machine.

The cup heating function must first be switched on.

The cup heating surface will be heated continually until the coffee machine is turned off.

Pre-heating cups



- Arrange the cups or glasses on the cup heating surface on the top of the coffee machine.

Switching cup heating on or off

The Drinks menu is visible in the display.

- Touch .
- Select Settings.
- Select Cup heating with the  arrow sensor.
- Select the required setting to switch cup heating on or off.
- Touch OK.

The setting is now saved.

The following drinks without milk can be made:

- **Ristretto** ☐ is a concentrated, strong espresso. It is made with the same quantity of ground coffee as for an espresso, but with very little water.
- **Espresso** ☐ is a strong, aromatic coffee with a thick hazelnut brown coloured layer of froth - known as the **crema** - on top.
When making espresso, use espresso roasted coffee beans.
- **Coffee** ☐ differs from espresso by the increased amount of water and the roast of the beans.
Use coffee beans of the correct roast to make coffee.
- **Long coffee** is a coffee with considerably more water.
- **Long black** is made with hot water and two shots of espresso.
- **Caffè Americano** consists of equal proportions of espresso and hot water. The espresso is made first, then the hot water is dispensed.



The dispensing spouts present a danger of burning or scalding.

The liquids and steam dispensed are very hot.

Keep well away from the area underneath the spouts when hot liquids and steam are being dispensed.

Do not touch hot components.

Making a coffee drink

Further drinks can be displayed and selected using the > arrow sensor.

The Drinks menu is visible in the display.



■ Place a cup under the central spout.

■ Touch the symbol or name of the coffee you want to make.

The drink will be dispensed from the central spout into the cup.

To ensure that any coffee residues from the factory testing process are removed from the brewing system, please throw away the first two cups of coffee when using the coffee machine for the first time.

Making coffee

Cancelling preparation

- Touch Stop or Cancel.

DoubleShot

Select the DoubleShot function if you would like a particularly strong and aromatic coffee. With this function more beans are ground and brewed half way through the brewing process. Because the brewing duration is shorter, fewer unwanted aromas and bitter agents are released.

DoubleShot will appear when drinks are being made. This function is available for all drinks except "Ristretto" and "Long black".

Making a DoubleShot of coffee

The Drinks menu is visible in the display.

- Place a cup under the central spout.
- Select the type of coffee you want.

Dispensing will start and the following will appear at the bottom of the display:



- Touch DoubleShot.

Two portions of coffee beans will be ground and brewed.

Double portion

You can also dispense two portions of a drink at once into one cup or into two cups at the same time.

To fill two cups at the same time:



- Place one cup under each of the coffee spouts.
- Touch .
- Select a drink.

Two portions of the drink will be dispensed.

Coffee pot - Preparing several cups of coffee

You can make several cups of coffee one after the other automatically with the Coffee pot function (max. 1 litre), e.g. to fill a coffee pot. Up to eight cups can be made in this way.

The Drinks menu is shown in the display.

You can use the Coffee pot function twice in a row. After this, the coffee machine needs to cool down for one hour in order to avoid it being damaged.

- Place a sufficiently large container under the central spout.
- Select Coffee pot with the > arrow sensor.
- Select the number of cups you want (3 to 8).
- Follow the instructions in the display.

Each cup of coffee will be brewed and dispensed individually. The display will inform you about the progress.

You can interrupt preparation at any time:

- Touch Cancel.


Drinks made with ready ground coffee

You can make coffee using ready ground coffee. This gives you the option of making a cup of decaffeinated coffee, for example, even though the coffee bean container is filled with roasted coffee beans.

To do this, fill the ground coffee drawer with ground coffee. The coffee machine will use all the ground coffee which has been added to the drawer to make the next coffee.

Only **one** portion of coffee or espresso can be made at a time.


Adding ready ground coffee



The coffee scoop is integrated into the ground coffee drawer.

- Open the door.
- Turn the handle (see arrow) to the left to remove the ground coffee drawer.

Making coffee



- Fill the coffee scoop with ground coffee. Push the ground coffee drawer horizontally into the ground coffee chute.

Place a maximum of **two** level scoops of coffee in the ground coffee chute.

- Turn the handle to the right to fill the brew unit with the ground coffee and to close the ground coffee chute.
- Close the door.

Use ground coffee? **appears in the display.**

Making drinks with ready ground coffee

If you want to make a drink with ready ground coffee:

- Touch Yes.

You can now select which type of drink you would like to make with ready ground coffee.

- Place a cup under the central spout.
- Select a drink.

The coffee machine will now prepare the desired drink.

If you **do not** want to use ground coffee to make the drink:

- Touch No.

The ground coffee will be directed into the waste container.

Making coffee with milk

The following drinks with milk can be made:

- **Cappuccino** ☕ consists of approx. 2/3 milk froth and 1/3 espresso.
- **Latte macchiato** ☕ consists of 1/3 each of hot milk, milk froth and espresso.
- **Caffè latte** ☕ consists of coffee and hot milk.
- **Cappuccino italiano** has the same proportion of milk froth and espresso as a cappuccino, but the espresso is added first and then the milk froth.
- **Espresso macchiato** is an espresso with a small amount of milk froth on top.
Select a cup which can hold at least 100 ml for this drink.
- **Flat white** is an espresso with milk froth.
- **Café au lait** is an espresso with slightly hotter milk.

Hot milk or milk froth can also be made separately.

Useful tip: Using cold cow's milk (< 10 °C) with a protein content of at least 3% will produce the perfect milk froth.

You can select milk with a fat content according to preference. With whole milk (at least 3.5% fat), the milk froth will be slightly creamier.



Caution! Danger of burning and scalding from the central spout.

Liquids and steam dispensed from the spouts will be very hot.

Do not use milk with additives. Most additives contain sugar which will adhere to the milk pipework and damage the machine.

As soon as you select a drink containing milk the machine will start to heat up. The milk will be drawn up into the central spout where it is heated by steam and also frothed for drinks requiring milk froth.

If you have not made any milk drinks for a while, rinse the milk system thoroughly before making the first drink to ensure any bacteria is flushed out.

Making coffee with milk

Milk flask

The stainless steel flask keeps milk cool for longer. Good milk froth can only be made with cold milk (< 10 °C).



- Connect the stainless steel suction tube to the inside of the lid. Make sure that the slanted end is pointing downwards as shown.
- Fill the milk flask up to max. 2 cm below the rim. Seal the milk flask with the lid.
- Connect the stainless steel angled end of the milk tube to the top of the lid until it clicks into place.



- Place a container with sufficient milk beside the coffee machine. Connect the other end of the milk tube to the central spout.


If the central spout is in the uppermost position, it will be difficult to connect the milk pipework.

To bring the central spout into the maintenance position:


- Touch for three seconds.
- Touch OK to leave the maintenance position.

Making coffee with milk

Using milk cartons or bottles



The milk tube for cartons and other suitable containers is located behind the service panel.



- Connect the milk tube to the aperture in the central spout.
- Place a container with sufficient milk in it beside the coffee machine.
- Place the end of the milk tube in the container. Make sure that it is sufficiently immersed in the milk.

Preparing drinks with milk

The milk pipework must be connected to the central spout and submerged in sufficient cold milk.

Start in the Drinks menu.

- Place a suitable cup underneath the central spout.

- Select a drink.

The drink will be dispensed from the central spout into the cup.

Making tea

 Danger of burning and scalding on the hot water spout.

Keep well away from the area underneath the hot water spout when hot liquids and steam are being dispensed.

Heating surfaces have residual heat after use. Do not touch hot components.

This machine is not intended for commercial or scientific purposes. Temperatures given are approximate and can vary according to ambient conditions.

The amount of tea and the brewing time will vary depending on the type of tea. Always follow the recommendations of the manufacturer on the packaging or of the retailer. The amount of hot water used can be adjusted depending on the type of tea and the size of the cup (see "Portion size").

Useful tip: Store the tea in a cool, dark place in tightly sealed containers. It is best to buy smaller amounts to prevent loss of aroma.

To make tea, you can select from the following options:

- **Green tea** approx. 80 °C
- **Herbal tea** approx. 90 °C
- **Fruit tea** approx. 90 °C
- **Black tea** approx. 90 °C

The type of tea determines the preset temperature.

The respective dispensing temperatures are recommended by Miele for making black tea, green tea, herbal or fruit tea.

Follow the instructions for making tea on the tea packaging.

The taste of the tea will be affected by the type of water used. Water should be as soft as possible to allow the aroma to develop.

Whether you use loose tea leaves, blended tea or tea bags depends on your own personal preferences.

Making tea

The hot water spout is located to the right of the central spout.

Use the arrow sensor $>$ to display and select the types of tea. Different types of tea can be found in the drinks menu under Hot water.

The Drinks menu is visible in the display.

- Pour loose tea into a tea filter or similar or take a tea bag from the packet.
- Place the tea filter or the tea bag in the tea cup.



- Place the cup under the hot water spout.
- Select the type of tea you want from the display.

Hot water will be dispensed into the cup.

- Remove the tea filter or tea bag when the desired brewing time has elapsed.

Teapot - Preparing several cups of tea

You can make several cups of tea one after the other automatically with the Tea pot function (max. 1 litre), e.g. to fill a tea pot. Up to eight cups can be made in this way.

The Drinks menu is shown in the display.

- Place the tea or teabag in a suitably sized teapot.
- Place the teapot under the hot water spout.
- Select Tea pot with the $>$ arrow sensor.
- Select the type of tea you want.
- Select the number of cups you want (3 to 8).
- Follow the instructions in the display.

The teapot will be filled. The display will inform you about the progress.

You can interrupt preparation at any time:


- Touch Cancel.

Preparing hot water

 Danger of burning and scalding on the hot water spout!

Water coming out of the spout is very hot.

The Drinks menu is shown in the display.



- Place a suitable cup or glass underneath the hot water spout.
- Select Hot water with the $>$ arrow sensor.

Dispensing will start.

To cancel preparation:

- Touch Stop or Cancel.

When the beans are ground correctly, the coffee or espresso will flow evenly into the cup with a good crema. The crema should have an even nutbrown colour.

The grinder setting you select will be used for all coffee drinks.

There are various ways to tell whether the coffee grinder is set correctly.

The coffee has been **too coarsely** ground if:

- Espresso or coffee flows into the cup too quickly.
- The crema is very pale and uneven.

Set a finer grinder setting.

The coffee has been **too finely** ground if:

- Espresso or coffee only trickles into the cup.
- The crema is dark brown.


Set a coarser grinder setting.

To avoid damaging the grinder, please note the following:

Only adjust the grinder one setting at a time.

Grind the coffee beans again if you want to adjust the grinder to the next setting.

- Open the door.



- Push the slide control at most one setting to the left (for finer grinding) or one setting to the right (for coarser grinding).

- Close the door.

- Dispense a coffee.

Then you can adjust the grinder setting with the slide control again.

The altered grinder setting will not be used until after the second coffee has been dispensed.

Drink parameters

You can set the amount of coffee, the brewing temperature and pre-brewing for each coffee drink individually. To do this, first select the drink and then adjust the drink parameters.

The Drinks menu is shown in the display.

- Select Process with the > arrow sensor.
- Touch Change drink.
- Select a drink.

Now you can

- adjust the portion size (see "Portion size")
- or set drink parameters.

- Touch Drink parameters.
- Select Amount of coffee, Brew temperature or Pre-brewing.
- Select the setting you want and touch OK.

The overview of drink parameters will appear in the display.

- Touch OK again to save your changed settings.

Amount of coffee

The coffee machine can grind and brew 6-14 g of coffee beans per cup. The greater the quantity, the stronger the coffee.

There are various ways to tell whether the amount of coffee is set correctly.

The amount of coffee is **too low** if:

- Espresso or coffee flows into the cup too quickly.
- The crema is very pale and uneven.
- The espresso or coffee lacks body.

Increase the amount of coffee so that more ground coffee is brewed.

The amount of coffee is **too high** if:

- Espresso or coffee only trickles into the cup.
- The crema is dark brown.
- The espresso or coffee tastes bitter.

Decrease the amount of coffee so that less ground coffee is brewed.

Useful tip: If the coffee is too strong for you or it tastes bitter, try a different type of bean.

Brewing temperature

The ideal brewing temperature will depend on

- the type of coffee being used
- whether an espresso or a coffee is being made, and
- the altitude of the region.

Useful tip: Not all types of coffee tolerate high temperatures. Several types are sensitive to high temperatures, resulting in an impaired crema and taste.

The coffee machine has five brewing temperatures.

Pre-brewing ground coffee

When the pre-brewing function is switched on, the freshly ground coffee is first moistened with a little hot water. Then the remaining water is forced through the moistened coffee at high pressure. This helps release the flavour of the coffee.

You can set pre-brewing for a normal length of time or an extra long length of time. Alternatively, you can switch off the "Pre-brewing" function.

The machine is supplied with the "Pre-brewing" function switched off.

Portion size

The flavour of the coffee produced depends not only on the type of coffee, but also on the amount of water used. You can programme the amount of water for all coffee drinks and hot water to suit the size of your cups and the type of coffee you are using. This does not alter the amount of coffee used.

For coffee drinks with milk you can also set the amount of milk or milk froth to suit your personal taste. Additionally, you can set the portion sizes for hot milk and milk froth alone.

A maximum portion size can be programmed for each type of drink. The coffee machine halts preparation of the coffee once this portion size has been reached. The maximum possible portion size is then saved by the appliance for this type of drink.

The changed portion size is always saved in the current user profile. The name of the current user profile is shown in the top left of the display.

If the water container becomes empty during the preparation of a drink, the programming of the portion size will be cancelled. The portion size will **not** be saved.

If you have selected a drink with milk or tea, portion programming will start immediately. Portion size does not need to be opened separately.

The drink will be made and Save will appear in the display as soon as the minimum dispensing amount is reached.

- When the cup is filled up to the level you want, touch Save.

If you want to change the portion size for coffee drinks made with milk or hot water, the ingredients (components) which make up the drink will be saved one after the other while the drink is being made.

The combination programmed in and the total portion size will now be dispensed every time that particular drink is selected.

The Drinks menu is visible in the display.

- Place the cup you want under the central spout or hot water spout.
- Select Process with the > arrow sensor.
- Touch Change drink.
- Select the drink and then touch Portion size.

You can reset portion sizes and parameters individually or for all drinks back to their factory default setting.

The Drinks menu is visible in the display.

- Select Process with the > arrow sensor.

Resetting a drink

- Touch Reset drink.
- Select a drink.

Reset drink to default settings? appears in the display.

- Confirm with Yes.

Resetting all drinks

- Touch Reset all drinks.

Reset all drinks to default settings? appears in the display.

- Confirm with Yes.

User profiles

In addition to the Miele profile, you can enter up to 10 individual profiles to cater for different tastes and preferences.

The portion quantities and parameters for coffee and milk drinks, hot water and tea can be adjusted in each profile.

The name of the current User profile is shown in the top left of the display.

Calling up User profiles

The Drinks menu is visible in the display.

- Touch Profiles.

You can now create a User profile.

Creating a User profile

- Touch Create profile.

The editor will open in the display.

- Enter the name you want (max. 8 characters) and then touch Save.

Selecting a User profile

- Select the User profile you want.

The name of the current User profile is shown in the top left of the display.

Processing User profiles

When you have created at least one profile, you can choose from the following options under Process:

- **Change name** if you want to alter the name of a profile.
- **Delete profile** if you want to delete a profile.
- **Change profile** to set whether the coffee machine automatically always reverts to the Miele standard profile or retains the last selected profile.
- Select Process with the > arrow sensor.

Changing a User profile

You can set up the coffee machine so that after each use it automatically reverts back to the Miele standard profile, or it retains the last selected User profile.

- Touch Change profile.

You now have the following options:

- **Manual:** The selected User profile remains active until you select another User profile.
- **After each use:** The machine will change back to the Miele standard profile automatically after a drink is dispensed.
- **When switched on:** Each time the machine is switched on it will automatically select the Miele standard profile regardless of which User profile was set before the machine was last switched off.

- Select the required option and touch OK.

Changing a name

- Touch Change name.
- Select the User profile you want.
- Change the name as you wish and then touch Save.

The changed profile name is saved.

Deleting a profile

- Touch Delete profile.
- Touch the profile you want and then touch OK.

The profile will be deleted.

User profiles: creating and processing drinks

You can save frequently made drinks in a profile with your own individual settings (see "User profiles").

You can also change the names of the drinks and delete any unwanted drinks from the profile. A profile can contain a maximum of ten drinks.

The Drinks menu will appear. First open the profile you want:

- Touch Profiles.
- Select the User profile you want.

The name of the current User profile is shown in the top left of the display.

Creating a drink

You can create new drinks based on existing drinks.

- Touch Create drink.
- Now select a drink.
- Change the drink parameters and portion size for this drink as you wish (see "Drink parameters: Amount of coffee, brew temperature and pre-brewing" and "Portion size").

Drink preparation will begin and you can save the portions of each component as desired.

- Enter a name for the new drink (maximum 8 characters) and touch Save.

The new drink will appear in the current User profile.

Changing a drink: Changing the portion size(s), drink parameters and names

The desired profile with the newly created drinks will appear in the display.

- Select Process drink with the > arrow sensor.
- Touch Change drink.
- Select a drink.

You can now either change the portion size(s), drink parameters or the names as described.

Deleting a drink

The desired profile with drinks will appear in the display.

- Select Process drink with the > arrow sensor.
- Touch Delete drink.
- Select the drink you want and touch OK.

The entry will be deleted.

User profiles: making drinks

The Drinks menu is visible in the display.

- Touch Profiles.
- Select the User profile you want.

The name of the profile selected will be shown in the top left of the display. Now you can make the drink you want.

- Place a suitable cup underneath the central spout.
- Select a drink.

The drink will be dispensed from the central spout into the cup.

Expert mode

In Expert mode you can change the amount of coffee and portion size while the drink is being made. The setting will **not** be saved and will only apply for the current drink.

Switching Expert mode on and off

The Drinks menu is visible in the display.

- Touch ↺.
- Select Settings ▾ and then Expert mode.
- To switch Expert mode either on or off, select the option you want.
- Touch OK.

If Expert mode was switched on, you can now change the amount of coffee and/or the portion size while the drink is being dispensed.

Expert mode: changing the amount of coffee and portion size


The Drinks menu is visible in the display.

The parameters can only be changed when the respective ingredient is being processed while the drink is being made.

Changing the amount of coffee

- Select the type of coffee you want.

Dispensing will start. You can now change the amount of coffee while the beans are being ground.



- Touch the segments and adjust the indicator (small triangle) as you wish.

When you touch the segments, Adjust will appear.

Changing portion size

- Select a drink.

Dispensing will start. You can adjust the portion size while it is being dispensed, e.g. change the amount of hot milk, milk froth and espresso for Latte macchiato.

- Touch the segments and adjust the indicator (small triangle) as you wish.

You can use the Settings menu to customise the coffee machine to suit your individual requirements.

Calling up the Settings menu

The Drinks menu is visible in the display.

- Touch ↺.
- Select Settings .

You can now check or make alterations to settings.

The settings which are currently selected will be marked in colour.

Touching ↺ takes you back to the previous menu.

Changing and saving settings

The Settings  menu is visible in the display.

- Select the option you want to change.
- Select the setting you want and confirm with OK.

The setting is now saved.

Settings

Overview of available settings

The factory default for each option is indicated by *.

Menu option	Available settings
Language 	deutsch and other languages Country
Time	Show – Off* / On / Night dimming Clock format – 12 h (am/pm) / 24 h* Set
Date	
Timer	Timer 1 – Set : Switch on at / Switch off after (00:30)* / Switch off at – Days of the week: Monday / Tuesday / Wednesday / Thursday / Friday / Saturday / Sunday – Activate : Switch on at (Yes / No*) / Switch off at (Yes / No*) Timer 2 – Set : Switch on at / Switch off at – Days of the week: Monday / Tuesday / Wednesday / Thursday / Friday / Saturday / Sunday – Activate : Switch on at (Yes / No*) / Switch off at (Yes / No*)
Expert mode	On / Off*
Eco mode	On* / Off

Menu option	Available settings
Descaling	Descaling method <ul style="list-style-type: none">– Automatic descaling / Manual descaling Start time
Lighting	Machine switched on <ul style="list-style-type: none">– Set the brightness Machine switched off <ul style="list-style-type: none">– Brightness / Switch off after
Info	Number of drinks <ul style="list-style-type: none">– Total no. of drinks / Total no. of coffee drinks / Total no. of tea drinks / Ristretto / Espresso / ... No. of drinks until <ul style="list-style-type: none">– Descaling / Degrease the brew unit
System lock	On / Off*
Water hardness	Soft Medium Hard* Very hard
Brightness	Set the brightness
Volume	Audible tone Keypad tone
Cup heating	On / Off*
Spout adjustment	On / Off*
Service	Evaporate (Yes / No) Demo mode (On / Off*)
Factory default	Reset <ul style="list-style-type: none">Do not reset

Settings

Language

You can select a language and country for all display texts.

Useful tip: If you select the wrong language by mistake, you can find the "Language" option by following the flag symbol .

Time of day

You can set the display for when the time of day appears after switching off the appliance, the clock format and the time.

Display (time display)

You can choose one of the following options:

- On: The time and date are always visible in the display when the appliance is switched off.
- Off: The time and date are not visible in the display when the appliance is switched off.
- Night dimming: The time and date are displayed from 5:00 to 23:00.

Depending on the setting selected, the coffee machine may use more energy. A message will appear in the display to inform you of this.

Clock format

You can select:

- 24-hour display (24 h)
- 12-hour display (12 h (am/pm))

Setting the time of day

Set the hours and then the minutes.

The time must be entered with four digits.

Timer

There are two timers with the following timer functions:

The coffee machine

- switches on at a particular time, e.g. in the morning for breakfast (Switch on at).
- switches off at a particular time (Switch off at).
- switches off after a particular length of time if none of the sensors has been touched or a drink has not been made (Switch off after; Timer 1 only).

You can allocate the timer functions to individual days of the week.

For Switch on at and Switch off at, the timer must be activated and at least one day of the week allocated.

Selecting a timer

You can select:

- Timer 1: Switch on at, Switch off at, Switch off after
- Timer 2: Switch on at, Switch off at

Switch on at

The coffee machine will **not** switch on at the required time if you have activated the system lock. The timer settings are deactivated.

If the coffee machine has switched itself on **three times** via the Switch on at timer function and no drinks have been dispensed, the machine will not switch itself on again automatically. This prevents the coffee machine from switching itself on unnecessarily, for example, whilst you are away on holiday.

The programmed times will, however, remain in memory and will be reactivated after manually switching the machine on again.

Switch off at

In the event of a longer absence the programmed times will remain in memory and will be reactivated after manually switching the machine on again (see "Switch on at").

Settings

Switch off after

The Switch off after timer function is only available in Timer 1.

If none of the sensors has been pressed or no drink has been prepared, the coffee machine will switch itself off after 30 minutes to save energy.

You can change this pre-setting to a time of between 15 minutes and 9 hours.

Allocating days of the week

Select the day of the week you want. The selected day of the week will be marked by .

When all required days of the week are marked:

- Touch OK.

Activating and deactivating the timer

For the time display, you have selected On or Night dimming:

If the timer for Switch on at has been activated, the symbol  and the desired switch-on time appear in the display 23:59 hours ahead of time.

When the system lock is activated, the Switch on at option for the timer cannot be selected.

Select the required timer function. The selected timer function will be marked by .

- Touch OK.

Expert mode

See "Expert mode" for more information about Expert mode.

Eco mode

Eco mode is an energy-saving mode.

If Eco mode is switched on, the coffee machine heats up anew before each drink preparation. Preparation times are slightly longer.

When Eco mode is switched off, the machine uses considerably more energy. The coffee machine heats up for the first drink preparation after switching on. After that the appliance remains heated up and drinks can be prepared with very little waiting time.

The coffee machine will indicate that the energy consumption has been altered.

Descaling

Information about automatic and manual descaling can be found in the relevant chapters.

If Manual descaling has been chosen, Start time will not be shown.

Lighting

The following options are available:

- The machine is switched on: set the brightness.
- The machine is switched off: set the brightness and set the time the lighting should switch off.

Set the brightness of the display

First select:

- Appliance switched on
- Appliance switched off

Setting the switching off time for the lighting (Switch off after)

You can set how long the lighting should remain on after switching off the coffee machine.

When the coffee machine is switched on, it remains lit up for a certain length of time after the last action. This time cannot be adjusted.

Info (display information)

In the Info option you can choose to display the number of prepared portions for each type of drink.

You can also see how many portions can be dispensed before the machine needs to be descaled (if Manual descaling has been selected) or before the brew unit needs to be degreased (No. of drinks until).

To return to the previous display:

- Touch ↺.

Locking the coffee machine (System lock

You can lock the coffee machine to prevent it being used without your knowledge, for example by children.

Activating and deactivating the system lock

When the system lock is activated, the Switch on at option for the timer is deactivated. The coffee machine will **not** switch on at the time set.

Overriding the system lock

If you touch the On/Off  sensor,  will appear.

- Touch  as long as a relevant instruction appears in the display.

As soon as you switch the coffee machine off, the system lock will be activated again and the coffee machine is locked once more.

Settings

Water hardness

Information regarding water hardness is given in the "Water hardness" section of this booklet.

Display brightness

You can set the display brightness using the bar chart.

Volume

You can set the volume of buzzer and keypad tones using the bar chart.

Cup heating

See "Cup heating" for more information.

Spout adjustment

You can find information on adjusting the height of the spout in the "Spout adjustment" section of this booklet.

Service

Evaporating the coffee machine

The coffee machine should be evaporated before it is stored for a long period of time or transported any distance (see "Transporting the machine").

Demo mode

Do not activate this function for domestic use.

The appliance can be presented in Miele Experience Centres or retail stores with the Demo mode function. The lighting will come on but drinks cannot be dispensed and other actions cannot be carried out.

Factory default

You can reset the settings back to the ones which were set when the coffee machine was delivered - the factory default settings.

The number of drinks and the appliance status (No. of portions until appliance needs descaling, ... brew unit needs degreasing) cannot be reset.

Please refer to the "Overview of available settings" chart for the factory settings which are indicated by *.

The following settings will **not** be reset:

- Language
- Date and time
- Descaling method (the start time resets to 22:00 h).

Cleaning and care

 Clean the coffee machine regularly to avoid a build-up of bacteria.

Cleaning intervals - Quick guide

Recommended frequency	What do I have to clean / maintain?
Daily (at the end of the day)	Water container Waste container Drip tray and drip tray cover Stainless steel milk flask Cup sensor
Once a week (more often if heavily soiled)	Central spout Brew unit Area underneath the brew unit and the drip tray Housing
Once a month	Coffee bean container Ground coffee chute and ground coffee drawer Water container filter (or as required)
When prompted	Milk pipework Brew unit (degrease with the cleaning tablets) Descale the machine (if set to "Manual descaling")

Useful tip: If you selected Automatic descaling as your method of descaling, you can carry out your daily cleaning routine, for example of the water container, drip tray or waste container during the activation phase. Set an appropriate start time for automatic descaling to take place (see "Automatic descaling – Setting the start time").

 Danger of burning and scalding on hot components or by hot liquids. Always allow the coffee machine to cool down before cleaning it. Caution: Water in the drip tray can be very hot.

 Do not use a steam cleaner to clean this machine. Steam could reach the electrical components and cause a short circuit.

It is important to clean the machine regularly as the used coffee grounds will soon go mouldy. Milk residue can spoil and the milk pipework can become blocked.

Unsuitable cleaning agents

All surfaces are susceptible to scratching. Scratches on glass can in some circumstances lead to breakage. Contact with unsuitable cleaning agents can alter or discolour the external surfaces. To protect the machine and surrounding surfaces from damage, make sure you wipe up any spillages or splashes of descaling agent immediately.

To avoid damaging the surfaces of your appliance, do not use:

- cleaning agents containing soda, ammonia, acids or chlorides
- solvent-based cleaning agents
- cleaning agents containing descaling agents
- stainless steel cleaning agents
- dishwasher cleaner
- glass cleaning agents
- oven cleaner
- abrasive cleaning agents, e.g. powder cleaners and cream cleaners
- hard, abrasive brushes or sponges, e.g. pot scourers, brushes or sponges which have been previously used with abrasive cleaning agents
- dirt erasers
- sharp metal scrapers
- steel wool or stainless steel wire scourers.

Cleaning and care

Cleaning by hand or in the dishwasher

Please note that the brew unit is **not** dishwasher-safe.

Clean the brew unit by hand only under warm running water. **Do not use washing-up liquid or any other cleaning agent.**

Most of the parts that are **not** dishwasher-safe have a pictogram on them.



The following must be cleaned **by hand only**:

- Stainless steel central spout cover
- Cup sensor
- Brew unit
- Bean container lid
- Stainless steel milk flask
- Lower panel

The maximum temperature of the dishwashing programme selected must not exceed 55 °C.

Some components of the coffee machine are dishwasher safe. However, cleaning these in the dishwasher frequently can cause them to become discoloured due to regular contact with food residues (e.g. tomatoes) in the dishwasher. The surface of these components can also become damaged.

The following components are **dishwasher safe**:

- Drip tray and lid
- Drip tray cover
- Waste container
- Water container
- Central spout (without stainless steel cover)

Drip tray and waste container


Danger of burning!

If the pipework has just been rinsed, wait a while before removing the drip tray as the water used for rinsing will still run out of the coffee spouts.

Clean the drip tray and waste container **every day** to avoid unpleasant smells and mildew.

The waste container is located in the drip tray. Water from rinsing also collects in the waste container.


A prompt will appear in the display when the drip tray and/or the waste container is full and needs to be emptied. Empty the drip tray **and** the waste container.



- Pull the drip tray carefully out of the machine. Take the lid ① off.
- Empty the drip tray **and** the waste container.
- Remove the drip tray cover ② and the lower panel ③.

Clean the lower panel by hand only using hot water, a little washing up liquid and a soft cloth.
All other parts are dishwasher-safe.

- Clean all parts thoroughly.



- Clean the metal contact discs and the space between them carefully. Dry everything thoroughly.

The discs will not be able to detect that the drip tray is full if they are damp or dirty.
Check this area once a week, if necessary.


- Clean the inside of the machine underneath the drip tray.
- Replace the waste container, the lid and the lower panel on the drip tray, **before** pushing it back into the coffee machine.

Make sure that the drip tray is pushed right into the coffee machine as far as it will go.

Cleaning and care

Drip tray cover

- Remove the drip tray cover.
- The drip tray cover can be cleaned in the dishwasher, or by hand using warm water, a little washing up liquid, and a soft cloth.
- Dry the drip tray.



- Refit the drip tray. Make sure that the drip tray cover is correctly fitted (see picture).

Water container

Change the water every day to prevent a build-up of bacteria.


Make sure that the valve, the underside of the water container and the surface the water container sits on are clean. Otherwise the water container will not sit correctly.

- Remove the water container.
- The water container can be cleaned in the dishwasher, or by hand using warm water and a little washing-up liquid. After cleaning, dry the water container.
- Carefully clean and dry the surface the water container sits on, particularly the slots.
- Push the water container back into the appliance.

Please note that the automatic descaling programme will only work if the water container has been filled and correctly fitted in the machine.


Water container filter

If the machine has been set for Automatic descaling, the filter in the water container should be cleaned once a month.



The water container filter is located underneath the water container.

- Open the lid on the left-hand side and remove the water container.



- Unscrew the cap. Remove the seal and the filter.
- Clean all parts by carefully rinsing them under running water.

- First refit the filter (with the cross facing upwards) and then the seal (with the opening of the seal facing downwards). Finally screw the cap back on tightly.
- Push the water container back into the appliance.

Cleaning and care

Central spout with cappuccinatore

With the exception of the stainless steel cover, all parts of the central spout should be cleaned in the dishwasher at least **once a week**. This will remove coffee and milk deposits effectively.


Clean the stainless steel central spout cover **by hand only** using warm water and a little washing-up liquid, applied with a soft cloth.

The Drinks menu is visible in the display.


If the central spout is in the uppermost position, it cannot be dismantled. The central spout must be moved into the maintenance position to do this.

■ Touch  for 3 seconds.


The central spout will move into the maintenance position.



■ Pull the stainless steel cover forwards and off.




■ Pull the dispensing unit off towards you.



■ Twist the upper section ① with the holder for the milk pipework and pull it off. Then pull the Y-shaped piece ② off. Remove the dispensing spouts ③.

■ Clean all parts thoroughly.



- Clean the surfaces of the central spout with a damp cloth.

If necessary, clean the milk pipework under running water with the brush supplied:

- Insert the brush in the tube and move it back and forth as far as it will go until all milk residue has been removed.

Refit the components of the central spout:

- Reassemble the dispensing unit. Push the spout nozzles ③ firmly back onto the dispensing unit.

Make sure that all parts are tightly connected to one another.

- Push the dispensing unit back into the central spout and refit the stainless steel cover.
- Touch OK.


Useful tip: If the coffee machine is switched off, the central spout components can be removed and cleaned at any time.

Cleaning and care

Cup sensor

The cup sensor is located underneath the central spout.

Clean the cup sensor daily by hand with warm water and a little washing-up liquid.



- Push the two locking catches together (see arrows).

The cup sensor will be released.

- Clean the cup sensor.

To refit it:

- Push the cup sensor from underneath into the holder on the central spout.

Stainless steel milk flask

The milk flask should be taken apart and cleaned every day.

- Clean all parts **by hand only** using hot water, a little washing-up liquid and a soft cloth. Use the cleaning brush supplied to remove milk residue from the milk pipework if necessary.
- Rinse all parts carefully under running water.

Residual washing-up liquid can affect the taste of milk from the machine and the quality of the milk froth.

- Dry all parts afterwards.
- Reassemble the milk flask.

Milk pipework

 Ensure that all components in which milk is transported are cleaned on a regular basis. Milk naturally contains bacteria that rapidly multiply if the milk pipework is not cleaned properly. Soiling in the appliance may be dangerous to health.

The milk pipework must be cleaned at least once a week. A message in the display will prompt you when this needs to be done.

- Confirm the message with OK.

When you confirm the message Clean the milk pipework with OK, the internal counter for the cleaning interval will be reset. You will **not** be reminded again.

There are two options for cleaning the milk pipework:

- You can remove and dismantle the central spout with its integrated cappuccinatore and either wash it in the dishwasher or by hand with warm water and a little washing-up liquid (see "Central spout with integrated cappuccinatore").
- Or you can clean the milk pipework using the Clean the milk pipework maintenance programme together with the Miele Cleaning agent for milk pipework (see "Maintenance programmes - Rinsing the milk pipework").

Useful tip: In addition to your weekly cleaning routine we recommend carrying out the alternative cleaning procedure once a month. For example if you manually clean the machine once a week, then you should run the maintenance programme once a month. This combination will ensure that the milk pipework is cleaned optimally.

Coffee bean container

Danger of injury on the grinder!

Disconnect the coffee machine from the power supply before cleaning.

Coffee beans contain oils which can deposit on the walls of the bean container and hinder the flow of the beans. Therefore, clean the bean container regularly with a soft cloth.

Useful tip: Use a vacuum cleaner to remove any coffee residues from the bean container.

Useful tip: Only open one bean container at a time. This ensures that each container is filled with only one type of coffee beans.

- Take the lid off the coffee bean container.
- Remove any coffee beans.
- Clean the bean container with a dry, soft cloth.

The bean container can now be refilled.

- Refit the lid.


Useful tip: If required, you can clean the lid of the bean container **by hand** with warm water and a little washing-up liquid. Dry the lid thoroughly before refitting it on the bean container.

Cleaning and care

Ground coffee drawer

Clean the ground coffee drawer and chute for ground coffee regularly, e.g. when you degrease the brew unit.

- Open the door.



- Turn the handle (see arrow) to the left to remove the ground coffee drawer.
- The ground coffee drawer can be cleaned in the dishwasher, or by hand using warm water and a little washing-up liquid. After cleaning, dry the ground coffee drawer.
- Remove any ground coffee residues from the ground coffee chute with a soft, dry cloth.
- Refit the ground coffee chute. Turn the handle to the right to close the ground coffee chute.
- Close the door.

Remove the brew unit and wash by hand




Danger of injury!

Disconnect the coffee machine from the power supply before cleaning.

Clean the brew unit **by hand** only using warm water. **Do not use washing-up liquid.** The moving parts of the brew unit are lubricated. Washing-up liquid will damage the brew unit.

Clean the brew unit once a week.

- Open the door.





- Press the button under the handle of the brew unit ① and, whilst doing so, turn the handle to the left ②.
- Carefully pull the brew unit out of the coffee machine.

If you cannot remove the brew unit or can only do so with difficulty, the brew unit is not in the correct position (See "Problem solving guide").

When you have removed the brew unit, do **not** change the position of the handle on the brew unit.

- Clean the brew unit **by hand under warm running water** without using washing-up liquid.



- Wipe any remaining coffee off the two filters. One filter is located in the funnel and the other to the left of the funnel.
- Dry the funnel to prevent ground coffee sticking to it the next time a coffee is prepared.
- Carefully clean the inside of the coffee machine.

Make sure you regularly remove any damp ground coffee residues to prevent the build-up of mould.

Useful tip: Use your vacuum cleaner to remove dry ground coffee residues.

To replace the brew unit, proceed in the reverse order:

- Push the brew unit back into the coffee machine, making sure it is straight.

Cleaning and care

Cleaning the housing

Remove any soiling immediately. If soiling is not removed promptly, it could cause the surface to alter or discolour.

Make sure that water cannot get behind the display.

The surfaces of the coffee machine are susceptible to scratching.

Contact with unsuitable cleaning agents can alter or discolour the surfaces.

To protect the machine and surrounding surfaces from damage, make sure you wipe up any spillages or splashes of descaling agent immediately.

- Switch the coffee machine off.
- Clean the front with a soft sponge and a solution of warm water and a little washing-up liquid. Dry all parts with a soft cloth.

Useful tip: You can also clean the appliance front with the Miele all purpose microfibre cloth.

Maintenance programmes

The coffee machine has the following maintenance programmes:

- Rinsing the appliance
- Rinsing the milk pipework
- Cleaning the milk pipework
- Degreasing the brew unit
- Descaling the machine

Carry out the relevant maintenance programme when the prompt to do so appears in the display. Please see the following pages for more information.

Opening the "Maintenance" menu

The Drinks menu is visible in the display.

- Touch ↲.
- Select Maintenance.

You can now select a maintenance programme.

Rinsing the appliance

After a coffee has been dispensed, the machine is rinsed before it switches off. This removes any residual coffee grounds.

You can also rinse the milk pipework manually.

The Drinks menu is visible in the display.

- Touch ↲.
- Select Maintenance and then Rinse the machine.

You may also be prompted to insert the end of the milk pipe into the drip tray.

Rinsing the milk pipework


Milk residue can clog up the milk pipes. If a drink has been made using milk, the coffee machine will prompt you to rinse the pipework when you switch the machine off.

You can also rinse the milk pipework manually.

The Drinks menu is visible in the display.

Useful tip: Place a suitable container underneath the central spout.

- Touch ↲.
- Select Maintenance and then Rinse the milk pipework.



- Place the end of the milk tube into the aperture in the drip tray cover.
- Confirm with OK.

The milk pipework will now be rinsed.

Cleaning and care

Cleaning the milk pipework

We recommend using the Miele Cleaning agent for milk pipework for cleaning the milk pipework. This has been specially developed for use with Miele coffee machines and prevents subsequent damage.

The milk pipework cleaning agent is available to order via the Miele webshop or directly from Miele (see back cover for contact details).

The Clean the milk pipework maintenance programme lasts for approx. 10 minutes.

The Drinks menu is visible in the display.

- Touch .

The cleaning process cannot be cancelled once it has started. The process has to be completed through to the end.

- Select Maintenance and then Clean the milk pipework.

The process will start.

- Follow the instructions in the display.

Insert milk pipe in cleaning agent appears in the display.

Making a cleaning solution:

- Dissolve the powder in a container with 200 ml of lukewarm water. Stir the solution with a spoon until it has fully dissolved.

Carrying out the cleaning process:



- Place the container next to the machine and hang the milk pipe in the solution. Make sure it is placed sufficiently far into the cleaning solution.
- Touch OK.
- Follow the further instructions given in the display.

The cleaning process is finished when rinsing has finished.

Degreasing the brew unit

Depending on the natural oil content of the coffee used, the brew unit can become blocked quite quickly. It must be degreased regularly in order to ensure aromatic coffee and trouble-free operation of the coffee machine.

We recommend using Miele cleaning tablets to clean the brew unit. These have been specially developed for use with Miele coffee machines and prevent subsequent damage.

Miele cleaning tablets can be ordered via the Miele webshop or directly from Miele (see back cover for contact details).

The maintenance programme for degreasing the brew unit lasts for approx. 12 minutes.

After 200 portions have been dispensed, Degrease the brew unit will appear in the display.

- Touch OK.

This message will not go out until the brew unit has been degreased.

Carrying out the "Degrease the brew unit" process

The Drinks menu is visible in the display.


- Touch ↲.

The degreasing process cannot be cancelled once it has started. The process has to be completed through to the end.

- Select Maintenance and then Degrease the brew unit.
- Follow the instructions in the display.

When Place a cleaning tablet in the ground coffee drawer and then close it **appears** in the display:

- Open the door.
- Turn the handle to the left to remove the ground coffee drawer.
- Clean the ground coffee drawer if necessary.



- Place the cleaning tablet in the integrated coffee scoop and push the ground coffee drawer into the ground coffee chute. Turn the handle to the right to close the ground coffee chute.
- Close the door.
- Follow the further instructions given in the display.

The brew unit is now degreased.

Water hardness

If the descaling method has been set to Manual descaling, the coffee machine will need to be set for the local water hardness level. A prompt to run the descaling programme will then appear in the display at the right time.

The water hardness level indicates how much calcium is dissolved in the water. The higher the calcium content, the harder the water, and the harder the water, the more often the coffee machine will need to be descaled.

The coffee machine measures the amount of water and steam used. Depending on the level of water hardness set, more or fewer drinks can be dispensed before the appliance needs to be descaled.


The machine has four programmable levels:

Water hardness	Water hardness level in your area	Setting (water hardness level)
0 - 8.4 °dH (0 - 1.5 mmol/l)	Soft	Soft 1
8.4 - 14 °dH (1.5 - 2.5 mmol/l)	Medium	Medium 2
14 - 21 °dH (2.5 - 3.7 mmol/l)	Hard	Hard 3
> 21 °dH (> 3.7 mmol/l)	Hard	Very hard 4

The machine is programmed ex-works to hardness level 3.

Measuring water hardness

You can measure the water hardness yourself using the enclosed test strip. Alternatively, your local water authority will be able to tell you the hardness of water in your area.



- Dip the test strip in your drinking water for approximately one second, then shake off any excess water. The result will be evident after about a minute.

Setting the water hardness level

The Drinks menu is visible in the display.

- Touch
- Select Settings
- Select Water hardness with the arrow sensor.
- Select the hardness level you want and then touch OK.

The setting is now saved.

With automatic descaling you do not have to do anything:

- The coffee machine does not have to be set to the local water hardness range.
- The descaling maintenance programme does not need to be run.

The Miele descaling cartridge will last for 7 to 12 months of automatic descaling, depending on how often the coffee machine is used.

How does automatic descaling work?

A Miele descaling cartridge is fitted at the back of the coffee machine. The descaling cartridge contains a descaling agent that is mixed with water to make a descaling solution. This descaling solution is used to fill the pipework in the coffee machine every day and then works for approx. 4 hours. Ideally this should be at night. The machine should remain switched off whilst this process is running: the pipework is not rinsed during this period. The descaling solution is thoroughly rinsed through the pipework after the four hour activation period - or the next morning. The machine can then be used as normal for making drinks.

The automatic descaling programme does not run on days when no drinks have been made. The automatic descaling programme will therefore not run if, for instance, you are on holiday.

Automatic descaling

The Miele descaling cartridge

Only use the Miele descaling cartridge for the automatic descaling programme. These have been developed specifically for use in this coffee machine.

Replacement cartridges are available to order via the Miele webshop or directly from Miele (see back cover for contact details).

Please note that the Miele descaling cartridge has a lifespan of approx. one year after it has been placed in the machine and filled with water for the first time.

Do not fill the descaling cartridge with other fluids or substances.

Please note that the automatic descaling programme will not work with a depleted or empty cartridge or **without** a cartridge. The coffee machine cannot be used for making drinks until a new one has been fitted.

Should this happen, select Manual descaling as your descaling method.

The descaling cartridge can be removed if, for instance, you need to move the coffee machine. Please note:

- Once filled with water, the descaling cartridge has a max. shelf life of three weeks outside of the machine.
- It should be transported with care and upright. Shaking the cartridge or turning it upside down will reduce its descaling ability, or cause the float to become jammed.
- The cartridge should be stored upright, in a dark place and at room temperature (16 - 38 °C).


Useful tip: When replacing the descaling cartridge we recommend running the manual descaling programme once as this will thoroughly clean the filter in the water container.

Fitting and removing a descaling cartridge


Select Automatic descaling as the method of descaling.

Switch the machine on. The machine will then register if there is a descaling cartridge present.

Automatic descaling




- Slide the cover at the back of the coffee machine downwards.



- Pull the cartridge holder ① forwards.

If there is a cartridge already fitted:

- Remove the cartridge ②.



- Seal the cartridge with the cap.

The cap is located on the cartridge.
Release it by snapping it off.

- Dispose of the empty cartridge with your household waste.

Automatic descaling

To fit a descaling cartridge:

- Insert the cartridge ② and push it upwards as far as it will go.
- Push the cartridge holder ① back and then close the cover.
- Follow the instructions in the display.

The next time the coffee machine is switched off, the descaling cartridge will fill with water when the rinsing process takes place. You will hear the cartridge being rinsed with water at frequent intervals.

Switching automatic descaling on and off

The descaling method is selected when you set the machine up for first use. It is, however, possible to switch the Automatic descaling method on or off in the **Settings**  menu.

The **Drinks** menu is visible in the display.

- Touch .
- Select **Settings**  and then **Descaling**.
- Select **Descaling method**.

You can now select the descaling method:

- Automatic descaling
- Manual descaling

- Select your chosen descaling method and then touch **OK**.

Please note that if you change the descaling method to automatic descaling, you will need to run the manual descaling programme once to remove any limescale deposits from the pipework.

Please note before and during automatic descaling:

The coffee machine must be ready for use at the start time, that is, shortly before the pipework is filled with the descaling solution. This means:

- The coffee machine is connected to the electrical supply. The master switch is in the "I" position.
- The drip tray, brew unit and central spout are inserted.
- The water container is inserted and is filled with water at least up to the  descaling mark.
- Carry out the instructions which appear in the display before switching off, e.g. Empty the drip tray or Fill and refit the water container.
- If you have made drinks with milk, the milk pipework must be pushed into the drip tray and when the machine is switched off, the message about this in the display must be confirmed with OK.
- At the set start time the coffee machine pipework will be filled with descaling solution (this takes approx. 1 minute). Do **not** disconnect the coffee machine from the electrical supply during this time.

When the pipework has been filled with descaling solution, you can remove parts of the appliance or disconnect it from the electrical supply.

Setting the start time

You can set the daily start time for automatic descaling as you wish. The coffee machine must be switched off for the duration of the activation phase (approx. four hours). For this reason, it is best to set an evening start time.

The Drinks menu is visible in the display.

- Touch .
- Select Settings  and then Descaling.
- Select Start time.
- Set the start time you want and touch OK.

The start time is saved. From now on automatic descaling will commence at the desired time each day.

Automatic descaling

Making drinks during automatic descaling (activation phase)

You can cancel automatic descaling during the activation phase and postpone the start time if necessary.

You can cancel automatic descaling **once** to continue making drinks. If automatic descaling is cancelled twice in a row, the machine needs to be descaled immediately after being switched on the next time, unless you select manual descaling.

- Touch the On/Off sensor ①.

The time left in hours is shown in the display.

Cancelling automatic descaling

- Touch Cancel.

The descaling solution is rinsed out of the pipework. You can now make drinks.

Delaying the start time

- Touch Start time.

Cancel the automatic descaling process and change the start time? **appears in the display.**

- Touch Yes.
- Set the new start time and touch OK.

The new start time is saved. The descaling solution is rinsed out of the pipework. From now on automatic descaling will start at the new time.

Important! When descaling the machine, cover delicate surfaces and natural flooring to prevent damage from splashes of descaling solution. Ensure that any splashes of descaling solution are wiped up immediately.

Limescale builds up in the coffee machine through use. How often the appliance needs to be descaled will depend on the water hardness level in your area. The machine should be descaled regularly to ensure that it functions correctly.

The appliance will guide you through the descaling process. Various messages will appear in the display, e.g. you will be prompted to empty the drip tray or fill the water container.

If you have chosen the Manual descaling descaling method, you must carry out the maintenance programme regularly.

The descaling process is **essential** and takes approx. 12 minutes.

The coffee machine prompts you when it needs to be descaled. Number of drinks until the machine must be descaled: 50 will appear in the display. The remaining number of drinks that can be made before descaling will show in the display after each drink.

- Confirm this message with OK.

When the number of remaining portions reaches 0, the coffee machine will lock out.

Descale the machine appears in the display.

You can switch the coffee machine off if you do not want to carry out the descaling programme at this point. You cannot make any drinks until the machine has been descaled.

Descaling after prompt appears in the display

Descale the machine appears in the display.

The descaling programme cannot be cancelled once you have touched OK. The programme has to be completed through to the end.

- Touch OK.

The process will start.

- Follow the instructions in the display.

When Fill the water container to the  symbol with descaling agent and lukewarm water and place it in the machine appears in the display, proceed as follows.

Manual descaling


Creating the descaling solution

We recommend using Miele Descaling Tablets for optimum results. These have been specially developed for use with Miele coffee machines and prevent subsequent damage.

Other descaling agents, which contain other acids besides citric acid and/or other undesirable substances, such as chlorides for example, could damage the coffee machine. Moreover, the descaling effect required cannot be guaranteed if the descaling solution is not of the appropriate concentration.

Miele Descaling Tablets are available to order via the Miele webshop or directly from Miele (see the end of this booklet for contact details).

You will need **one** descaling tablet to descale the machine.



Follow the instructions for the mixing ratio carefully. It is important that you do not fill the water container with too much or too little water. Otherwise the descaling process will be cancelled prematurely.

Carrying out descaling

- Push the water container back into the machine.
- Follow the further instructions given in the display.

When **Rinse** the water container and fill it to the  symbol with fresh tap water **appears** in the display:

- Remove the water container and rinse it thoroughly with clean water. Ensure that **no** descaling solution residue remains in the water container. Fill the water container to the  symbol with fresh tap water.

The descaling process is complete at the end of the rinsing process. You can now prepare drinks again.

To protect the machine and surrounding surfaces from damage, make sure you wipe up any spillages or splashes of descaling agent immediately.

- Fill the water container to the marker  with lukewarm water.
- Place **one** descaling tablet in the water.

Descaling when not prompted by a message

The Drinks menu is visible in the display.

- Touch ↵.

The descaling programme cannot be cancelled once you have touched OK. The programme has to be completed through to the end.

- Select Maintenance and then Descale the machine.

The descaling programme will begin.

Problem solving guide

Most problems that occur during daily use can be easily corrected. With the help of the following guide, you will be able to find the causes of problems and rectify them.



Important! Never open the casing of the appliance.

Unauthorised or incorrect repairs could cause personal injury or damage to the appliance.

Repairs should only be carried out by technicians approved by Miele.

If you can't remedy the problem yourself, please call Miele. Please note that a call-out charge will be applied to unnecessary service visits where the problem could have been rectified as described in these operating instructions.

Messages in the display


Error messages must be confirmed with OK, otherwise the message may reappear in the display even though the problem has been remedied.

Follow the instructions which appear in the display to remedy the problem.

If the fault message appears again in the display, contact Miele.

Problem	Possible cause and remedy
F1, F2, F80, F82	There is a fault inside the appliance. ■ Switch the machine off with the On/Off (1) sensor. Wait for 1 hour before switching it back on again.
F41, F42, F74, F77, F225, F226, F235, F236	There is a fault inside the appliance. ■ Switch the machine off with the On/Off (1) sensor. Wait for approx. 2 minutes before switching it back on again.

Problem solving guide

Problem	Possible cause and remedy
F73 or Check the brew unit	<p>The brew unit cannot be positioned correctly.</p> <ul style="list-style-type: none">■ Switch the machine off with the On/Off ① sensor.■ Remove and clean the brew unit (see "Cleaning and care – Brew unit").  <ul style="list-style-type: none">■ Push the coffee ejector of the brew unit into the correct position (see diagram).■ Do not fit the brew unit. Close the appliance door and switch the machine on with the On/Off ① sensor. <p>This will initialise the brew unit motor and put it back into the start position.</p> <ul style="list-style-type: none">■ When Insert the brew unit appears in the display, open the appliance door and put the brew unit back in the machine. Then close the door.
F233	<p>The cup sensor is not inserted or is incorrectly inserted.</p> <ul style="list-style-type: none">■ Confirm the message with OK.■ Switch the machine off with the On/Off ① sensor.■ Insert the cup sensor.■ Switch the machine on with the On/Off ① sensor.


Problem solving guide

Problem	Possible cause and remedy
Too much ground coffee	<p>There is too much ready ground coffee in the ground coffee chute.</p> <p>If more than two level scoops of ground coffee is added to the coffee chute, the brew unit cannot process the coffee. The ground coffee will be directed into the waste container and the fault message will appear in the display.</p> <ul style="list-style-type: none">■ Switch the machine off with the On/Off ① sensor.■ Remove and clean the brew unit (see "Cleaning and care – Brew unit").■ Remove the ground coffee inside the coffee machine, e.g. with a vacuum cleaner.■ Use the integrated scoop to dispense the ground coffee.

Unusual performance of the coffee machine

Problem	Possible cause and remedy
The lighting remains off after the coffee machine is switched on.	<p>The lighting has been switched off.</p> <ul style="list-style-type: none"> ■ Switch the lighting on (see "Settings - Lighting"). <p>The lamp needs to be replaced.</p> <ul style="list-style-type: none"> ■ Call Miele.
The display remains dark when the coffee machine is switched on using the On/Off ① sensor.	<p>The On/Off ① sensor was not touched for long enough.</p> <ul style="list-style-type: none"> ■ Touch the On/Off ① sensor for at least 3 seconds. <p>The master switch is pointing to "0".</p> <ul style="list-style-type: none"> ■ Set the master switch to the "I" position. <p>The plug is not correctly inserted into the socket.</p> <ul style="list-style-type: none"> ■ Insert the plug into the socket correctly. <p>The mains fuse has tripped because the coffee machine, mains voltage or another appliance is defective.</p> <ul style="list-style-type: none"> ■ Switch off at the wall socket and remove the plug. ■ Contact a qualified electrician or Miele.
The coffee machine switches off suddenly.	<p>The switch-off time programmed using the timer has been reached.</p> <ul style="list-style-type: none"> ■ If required, you can select a new switch-off time. <p>The plug is not correctly inserted into the socket.</p> <ul style="list-style-type: none"> ■ Insert the plug into the socket correctly.
The coffee machine is switched on. The lighting switches off suddenly.	<p>This is not a fault. The lighting switches off automatically if the coffee machine is not used for some time. The automatic switch-off time cannot be changed.</p>
The sensors do not react to touch. The appliance cannot be operated.	<p>There is a fault inside the appliance.</p> <ul style="list-style-type: none"> ■ Set the master switch to the "0" position. ■ Disconnect the electricity supply by switching off at the wall socket and withdrawing the plug, or switching off the mains circuit breaker.

Problem solving guide

Problem	Possible cause and remedy
The coffee machine does not switch itself on, although the Switch on at setting has been activated for the timer.	<p>The system lock has been activated.</p> <ul style="list-style-type: none">■ You need to deactivate the system lock (see "Settings - System lock"). <p>A day of the week has not been selected.</p> <ul style="list-style-type: none">■ Check the timer settings and change these if necessary (see "Settings - Timer"). <p>The machine was not used after being switched on automatically three times in succession.</p> <ul style="list-style-type: none">■ Switch the machine on and dispense a drink.
Fill and refit the water container appears in the display even though the water container is full and in the machine.	<p>The water container is not in the correct position.</p> <ul style="list-style-type: none">■ Remove the water container and push it back in again.■ Clean the surface underneath the water container if necessary. <p>You have selected Manual descaling. The water container was not correctly filled and replaced for descaling.</p> <ul style="list-style-type: none">■ Fill the water container to the descaling symbol  and restart the descaling programme. <p>You have selected Automatic descaling:</p>  <p>The water container filter is blocked.</p> <ul style="list-style-type: none">■ Remove and clean the water container filter (see "Cleaning the water container filter").

Problem solving guide

Problem	Possible cause and remedy
<p>Fill and refit the water container appears after switching on even though the container is filled and fitted in the machine. The appliance does not rinse.</p>	<p>You have selected Manual descaling: the coffee machine needs descaling.</p> <ul style="list-style-type: none"> ■ Switch the machine off with the On/Off (1) sensor. Wait approx. 1 hour. ■ Then switch the machine on again. As soon as Heating-up phase appears in the display, touch Mainten. and then select Descale the machine. ■ Descale the coffee machine.
<p>Insert the drip tray and the waste container appears in the display, even though both have been inserted.</p> <p>Although the drip tray has been emptied, Empty the drip tray and the waste container appears in the display.</p>	<p>The drip tray is not correctly fitted and is therefore not detected.</p> <ul style="list-style-type: none"> ■ Empty the drip tray and the waste container if necessary. ■ Reassemble all parts and push the drip tray back in the coffee machine until it clicks.
<p>The waste container is full, although the drip tray and waste container have been emptied following each reminder.</p>	<p>This is not a fault. The drip tray has probably been removed without the waste container being emptied. Removing the drip tray resets the internal counter for emptying the waste container.</p> <ul style="list-style-type: none"> ■ Always empty the waste container if you remove the drip tray.
<p>The central spout moves up a little and then stops.</p>	<p>The stainless steel cover of the central spout was not fitted properly, e.g. is tilting forwards slightly.</p> <ul style="list-style-type: none"> ■ Refit the cover, making sure it is seated correctly.
<p>Coffee is not flowing out of the central spout, or is only being dispensed via one spout.</p>	<p>The central spout has a blockage.</p> <ul style="list-style-type: none"> ■ Rinse the coffee pipework (see "Cleaning and care - Rinsing the appliance"). <p>If there is still no coffee coming out, or coffee is only coming out of one side:</p> <ul style="list-style-type: none"> ■ Dismantle the central spout and clean all parts carefully (see "Cleaning and care - Central spout with integrated cappuccinatore"). ■ Make sure all parts are reassembled correctly.

Problem solving guide

Problem	Possible cause and remedy
Neither milk nor milk froth comes out of the central spout.	<p>The milk pipework is blocked.</p> <ul style="list-style-type: none">■ Clean the central spout, taking particular care to clean the cappuccinatore and milk pipes thoroughly with the cleaning brush.
Although the coffee machine has been switched off using the On/Off sensor ①, the machine is making rinsing noises at short intervals.	<p>This is not a fault. You have inserted a new descaling cartridge which is gradually being filled with water.</p>
The display lights up but the coffee machine does not heat up and no drinks are made. The coffee machine cannot be turned off with the On/Off ① sensor.	<p>The Demo mode of the coffee machine for Miele Experience Centres or Chartered Agents has been activated.</p> <ul style="list-style-type: none">■ Deactivate the Demo mode.

Faults with automatic descaling

Problem	Possible cause and remedy
<p>Automatic descaling could not be started. The machine was not ready. See the operating instructions appears when the machine is switched on.</p>	<p>If you have made drinks with milk, the milk pipework must be pushed into the drip tray and when the machine is switched off, the message about this in the display confirmed with OK.</p> <p>All removable parts, such as the water container, drip tray, brew unit or central spout must be inserted at the start time.</p> <p>The machine door was not closed.</p> <ul style="list-style-type: none"> ■ Confirm the message with OK. ■ Make sure that the coffee machine is ready to use before the next descaling process. <p>The coffee machine was not switched off at the start time using the On/Off ① sensor.</p> <p>The coffee machine pipework will only be filled with descaling solution when the coffee machine is switched off.</p> <ul style="list-style-type: none"> ■ Confirm the message with OK. ■ Change the start time if necessary.
<p>When the machine is switched on, Automatic descaling could not be started. Start the automatic descaling process (approx. duration 4 hours) or switch to manual descaling appears in the display. No drinks can be made.</p>	<p>Automatic descaling could not be carried out twice.</p> <p>If you still want the coffee machine to descale automatically:</p> <ul style="list-style-type: none"> ■ Make sure the coffee machine is ready for use (see "Tips for automatic descaling"). ■ Touch OK to start automatic descaling. <p>If you want to make drinks straight away, and therefore switch to manual descaling:</p> <ul style="list-style-type: none"> ■ Touch Manual.
<p>The descaling process could not be carried out. Replace the cartridge with a new one appears when the machine is switched on.</p>	<p>The descaling cartridge is depleted. You can still make drinks on this day.</p> <ul style="list-style-type: none"> ■ Confirm the message with OK. ■ Insert a new descaling cartridge (see "Miele descaling cartridge").

Problem solving guide

Unsatisfactory results

Problem	Possible cause and remedy
The coffee is not hot enough.	<p>The cup has not been pre-heated. The smaller the cup and the thicker its walls, the more important it is to pre-heat it.</p> <ul style="list-style-type: none">■ Pre-heat the cups, e.g. using the cup heating (depending on model).
	<p>The brewing temperature is set too low.</p> <ul style="list-style-type: none">■ Set a higher brewing temperature.
	<p>The filters in the brew unit are blocked.</p> <ul style="list-style-type: none">■ Remove the brew unit and clean it by hand.■ Degrease the brew unit.
Drinks are being dispensed from the central spout considerably more slowly. The heating-up time is getting longer and the coffee machine is not performing properly.	<p>The coffee machine needs descaling.</p> <ul style="list-style-type: none">■ Carry out the Descale the machine maintenance programme. You will need one descaling tablet. <p>If you use hard water ($> 20 \text{ °dH} / 3.6 \text{ mmol/l}$) or if the coffee machine is used intensively, it may be necessary to descale the machine manually in addition to automatic descaling.</p> <p>Manual descaling: it may be necessary to descale the coffee machine more frequently in areas with very hard water.</p>
The consistency of the milk froth is unsatisfactory.	<p>The milk temperature is too high. Good milk froth can only be achieved when cold milk (below 10 °C) is used.</p> <ul style="list-style-type: none">■ Check the temperature of the milk in the milk flask.
	<p>The milk pipework is blocked.</p> <ul style="list-style-type: none">■ Clean the central spout with integrated cappuccinatore and the milk pipework with the cleaning brush supplied.
The coffee grinder makes a louder noise than usual.	<p>The coffee bean container has become empty during the grinding process.</p> <ul style="list-style-type: none">■ Fill the container with fresh beans.
	<p>There may be stones in amongst the coffee beans.</p> <ul style="list-style-type: none">■ Switch the coffee machine off immediately. Call Miele.

Problem solving guide

Problem	Possible cause and remedy
The crema on the coffee or espresso is not as it should be.	<p>The grinder setting is not correct.</p> <ul style="list-style-type: none">■ Set the grinder to a finer or coarser setting. <p>The brewing temperature is too high for this type of coffee.</p> <ul style="list-style-type: none">■ Set a lower brewing temperature. <p>The coffee beans are no longer fresh.</p> <ul style="list-style-type: none">■ Add fresh coffee beans to the coffee bean container.
The coffee tastes weak. The coffee grounds in the waste container are sludgy and grainy.	<p>Insufficient coffee beans are getting into the grinder and less ground coffee is being brewed. If you have used a dark roast, this type of coffee bean is often more oily. These oils can cling to the inside of the coffee bean container and hinder the flow of beans.</p> <ul style="list-style-type: none">■ Make a coffee and observe whether the coffee beans drop into the coffee bean container.■ Clean the coffee bean container more often if you are using a darker, more oily bean. <p>Try other types of coffee bean which are less oily.</p>

Transporting the machine

If you are not going to use the coffee machine for an extended period of time and you intend to transport it, e.g. when moving house, a number of procedures will need to be carried out:

- Empty and clean the coffee bean container
- Empty and clean the water container
- Evaporate the coffee machine
- Remove the descaling cartridge and insert the adapter
- Clean the interior of the machine
- Pack the machine securely

Evaporating the coffee machine


The coffee machine should be evaporated before it is stored for a long period of time or transported any distance - particularly at temperatures below freezing.

Evaporating the machine involves removing all traces of water from the system to prevent the risk of water and frost damage.

The Drinks menu is visible in the display.


 Caution! Danger of burning and scalding from hot steam coming out of the hot water spout.

- Touch ↵.
- Select Settings  and then Service.
- Select Evaporate and then Yes.
- Follow the instructions in the display.



- If you have switched on Automatic descaling, remove the descaling cartridge. Put the cap on the descaling cartridge.

The descaling cartridge can be stored for a maximum of three weeks outside the coffee machine. Store the cartridge upright in a dark place at room temperature (16 – 38 °C).



- Insert the adapter in place of the cartridge.

When the display goes out, the machine has finished evaporating.

- Set the master switch to the "0" position.
- Clean the drip tray and waste container.

The coffee machine is now ready to be packed.

Packing

The coffee machine should only be packed when it is clean and dry. Residues of coffee grounds can cause scratches on surfaces. Coffee and milk residues or water can cause a build-up of bacteria.

Use the original packaging including polystyrene blocks to pack the coffee machine.

Also pack the operating instructions so that they are available when the coffee machine is next used.

After sales service and warranty

After sales service

In the event of a fault which you cannot correct yourself, please contact Miele.

The contact details for Miele are given at the back of these instructions.


Warranty

This appliance has a manufacturer's warranty period of 2 years.

For further information, please refer to your warranty booklet.

When contacting Miele, please quote the **model** and **serial number** of your coffee machine.

These can be found on the data plate:



If the settings of the following functions are altered from the factory default, energy consumption will increase:

- Eco mode
- Lighting
- Time of day display
- Timer
- Cup heating

Switching the machine off with the master switch and at the wall socket

If the coffee machine is not going to be used for a longer period of time, e.g. whilst on holiday, set the master switch to "0" and switch it off at the wall socket.

Pre-heating cups with hot water

If you only want to pre-heat your cups occasionally, you can switch the cup heating surface off.

You can then use hot water from the cappuccinatore to pre-heat the cups.

Electrical connection

Before connecting the appliance, make sure that the connection data on the data plate (voltage and frequency) match the mains electricity supply. This data must correspond in order to avoid the risk of damage to the appliance. Consult a qualified electrician if in any doubt.

The connection data is given on the data plate. The data plate can be seen on the left-hand side when the drip tray is pulled out.

The machine is supplied with a mains cable with moulded plug for connection to a 50 Hz 220-240 V supply.

The coffee machine must be connected to the mains supply via a suitable switched socket with earthing contact. Connection must comply with national and local safety regulations.

The fuse rating must be at least 10 A.

The socket should be next to the appliance and easily accessible.

Do not connect the machine to the mains electricity supply by a multi-socket adapter or an extension lead. These do not guarantee the safety of the appliance (e.g. danger of overheating).

Do not connect the machine to an **inverter** such as those used with an autonomous energy source, e.g. solar power. When switched on, peak loads in the system can cause the safety switch-off mechanism to be triggered. This can damage the electronic unit.

The machine must not be used with so-called **energy saving plugs**. These reduce the amount of energy supplied to the machine, causing it to overheat.

If the connection cable is faulty, it may only be replaced by a qualified electrician in order to avoid a hazard.

Danger of overheating!

Please ensure that there is adequate ventilation around the machine. Do not cover the machine with tea towels or similar objects whilst it is in use.

Danger of overheating!

If the coffee machine is installed behind a kitchen furniture door, it may only be used with the furniture door open.

Do not close the furniture door while the coffee machine is in use.

If the machine is installed in a niche, the niche must provide the following minimum dimensions:

Height	550 mm
Width	510 mm
Depth	575 mm


When setting up the machine: make sure that the front of the machine can be fully opened so that the brew unit can be removed with ease when required.

■ The machine must be set up in the niche such that it sits flush with the front edge of the niche.

Please observe the following installation instructions:

- The location of the machine must be dry and well ventilated.
- The ambient temperature of the room in which the machine is used must be between +16 °C and +38 °C.
- Do not place the coffee machine near a window in direct sunshine or right next to an appliance that gives off heat. These would subject the machine to ambient temperatures outside its permitted operating range.
- The machine must be set up on a level surface. The surface must be water resistant.

Appliance dimensions



Technical data

Current draw in standby mode (default setting):	< 0.5 Watt
Pump pressure:	max. 15 bar
Through-flow heater:	1 stainless steel thermo block
Appliance dimensions (W x H x D):	311 x 397 x 445 mm
Net weight:	13.4 kg
Connection cable length:	120 cm
Water container capacity:	2.2 l
Bean container capacity:	500 g
Stainless steel milk flask capacity:	0.5 l
Waste container capacity:	max. 16 portions of coffee grounds
Central spout:	Height adjustable from 80-160 mm
Grinder:	Stainless steel mill
Grinder setting:	5 settings
Ground coffee amount:	max. 12 g

Miele Australia Pty. Ltd.

ACN 005 635 398

ABN 96 005 635 398

Miele Experience Centre and

Head Office Melbourne:

1 Gilbert Park Drive

Knoxfield, VIC 3180

Miele Experience Centre South Melbourne:

206-210 Coventry Street

South Melbourne, VIC 3205

Miele Experience Centre and Office Sydney:

3 Skyline Place

Frenchs Forest, NSW 2086

Miele Experience Centre and Office Brisbane:

39 Harvey Street North

Eagle Farm, QLD 4009

Miele Experience Centre Gold Coast:

131 Ferry Road

Southport, QLD 4215

Miele Experience Centre and Office Adelaide:

83-85 Sir Donald Bradman Drive

Hilton, SA 5033

Miele Experience Centre and Office Perth:

205-207 Stirling Highway

Claremont, WA 6010

The Miele logo, featuring the brand name in a bold, sans-serif font. The letter 'M' is larger and positioned above the word 'iele'.**Miele New Zealand Limited**

IRD 98 463 631

Head Office:

Level 2, 10 College Hill

Freemans Bay, Auckland 1011

Miele Experience Centre

Auckland:

8 College Hill

Freemans Bay, Auckland 1011

Telephone:

0800 464 353 (0800 4 MIELE)

www.miele.co.nz

Miele Global Headquarters

Germany

Miele & Cie. KG

Carl-Miele-Straße 29

33332 Gütersloh

Federal Republic of Germany



1300 4 MIELE (1300 464 353)

www.miele.com.au

Miele

CM 7500

CE

en – AU, NZ

M.-Nr. 10 458 511 / 01