


**HANSGRÖHE CROMA 389MM  
WALL SHOWER ARM**

[327852]



**NOTE**

1. Seal all wall penetrations with a neutral cure silicone.
2. This is only an installation guide. Rogerseller recommends having the product onsite before commencing rough in.