



Fantini Fukasawa  
Hand Shower  
329558

#### Please note

- Seal all penetrations with a neutral cure silicone.
- The wall union requires a half inch male BSP water connection installed by the plumber at a suitable height during rough in.
- This is only an installation guide. Rogerseller recommends having the product on site before commencing rough in.