


70cm 4 zone induction cooktop with maxisense zone flexibility, 14 stage slide controls, power boost and stop & go function.

RRP AUS \$2,549.00



Product Details

FEATURES

Selected stockists only Only available at selected Good Guys, Domayne, Harvey Norman and Joyce Mayne stores.	High performance induction technology	Residual heat indicators all zones Indicates which area is too hot to comfortably touch.	Timer
Minute minder	Auto warm-up function	STOP & GO function	Touch and slide controls Touch the control bar at the necessary heat setting
Child safety device	Acoustic signal Confirms use of the control panel		

BENEFITS

High performance induction technology Have complete control with precise cooking. Cook from simmer to a boil instantly while using induction technology. Providing the ultimate in safety induction cooking generates heat in the cookware, so surfaces around the pot are cool to touch. The cooking environment remains cooler and is therefore safer too. The surface is also easy to clean, as spills can be simply wiped away.	Maximum flexibility Maxisense induction cooktops are developed with three or four extra large zones, which detect pan presence and location and are not restricted to traditional circular zones
Professional results Maxisense Induction combines the speed of gas with the addition of precise control. A range of cooking zones allow the cook to prepare any sized meal faster with a more consistently high quality	Intuitive Maxisense cooktops are easy to use and intuitive featuring touch and slide control. Simply slide your finger along the glass surface to change cooking temperature instantly

Ultimate in safety and comfort

Induction cooking generates heat in the cookware, so surfaces around the pot are cool to touch, and the cooking environment remains cooler. The surface is also easy to clean, as spills are simply wiped away

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	Induction
Materials/Colour	black
Removable trim (for cleaning)	No
Wok included designed to fit cooktop	No

CONTROLS

Controls of Cooktops	slide touch pad
Position of controls	front
Functions of Cooktops	stop and go,automatic warm up,timer,Keep warm function,auto heat up,cooking timer with acoustic signal,acoustic signal,booster,automatic switch off,power booster
Indicators/display	fault indicator,residual heat warning lamps,3 level residual heat indicator

DIMENSIONS

Total product height (mm)	55
Total product width (mm)	710
Total product depth (mm)	520
Cut out width (mm)	680
Cut out depth (mm)	490

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	induction extended
Left front Watts	2300
Left front boost watts	3200
Left front diameter	210

CONTROLS

Features of Cooktop	safety cut off,overheating protection,electronic timer,minute minder,function lock,hot surface indicator,automatic pan sensing,safety child lock,pot sensors
Timer of Cooktop	programmable 99min,auto off,countdown,CountUp
Readable temperature setting	No

LEFT REAR ZONE

Left rear zone	induction extended
Left rear watts	2300
Left rear diameter	210

RIGHT REAR ZONE

Right rear zone	induction extended
Right rear watts	2300
Right rear diameter	210

RIGHT FRONT ZONE

Right front zone	induction extended
Right front Watts	2300
Right front diameter	210



ELECTRICAL SPECIFICATIONS

Connected load KW	7.4
Type of connection	hardwired

Dimensions

Dimensions

	width	height	depth
Cut-out (mm)	680		490
Product (mm)	710	55	520



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz