Gourmet Warmer Drawers



ESW 6114

14 cm high gourmet warming drawer without handle with the low temperature cooking function - much more than a warming drawer.



- Ultimate enjoyment with Low temperature cooking
- Versatile use thanks to four operating modes
- Convenient and easy Touch control
- Easiest handling Push2Open
- Safe is safe Timer function with automatic switch off

Gourmet warming drawer	
	•
Design	
PureLine	
Colour	Stainless steel/Clean Stee
ContourLine	
Decorative stainless-steel trim	Wide
Glass fascia panel with sensor controls	
Control panel with symbols	•
Handleless	•
Convenience features	
Pre-heating crockery	<u>•</u>
Keep food warm for menu cooking	•
Perfect cooking results at low temperature	•
Precise electronic temperature regulation from 40 °C to 85 °C	•
Operating modes	
Cup warming	
Plate warming	
Keeping food warm	•
Low temperature cooking	•
User convenience	
Fully telescopic runners for easy loading and unloading	<u> </u>
Push2open mechanism	<u>•</u>
Stop programming/Timer function	•
Capacity	6 place settings
Connection with coffee machine possible	•
Cleaning convenience	
Stainless steel front with CleanSteel finish	•
Flush touch display	•
Safety	
Cool front	•
Safety switch-off	•
Anti-slip mat	•
Technical data	
Appliance width in mm	595
Appliance height in mm	141
Appliance depth in mm	570
Useable interior height in mm	80
Total rated load in kW	1
Voltage in V	230
Fuse rating in A	10
Number of phases	1
	50-60
· · · · · · · · · · · · · · · · · · ·	
Frequency in Hz	2 0
Frequency in Hz Length of supply lead in m	2.0
Frequency in Hz	Yes


Gourmet Warmer Drawers



ESW 6114

14 cm high gourmet warming drawer without handle with the low temperature cooking function - much more than a warming drawer.






ESW 6114, ESW 6214 (Installation drawing)

- * appliances with glass front ** Appliances with metal front
- 1) Cut-out support base for DGD 4635/6635/6605 2) AB 45-7 / optional accessories

To operate the DGD 4635 a plumbed water connection and water drainage is required. To plan the installation, refer to the connection requirements in advance of the sketch for water inlet and outlet.




734-736

DGC 6000, ESW 6*-14, CLST (installation drawing)

- * Appliances with glass front ** Appliances with metal front
- 560-568

ESW 6114, ESW 6214 (Installation drawing)

- * appliances with glass front ** Appliances with metal front



ESW 6114, ESW 6214 CLST (Installation drawing)

- * Appliances with glass front ** Appliances with metal front


Gourmet Warmer Drawers



ESW 6114


14 cm high gourmet warming drawer without handle with the low temperature cooking function - much more than a warming drawer.






ESW 6114, ESW 6214 (Installation drawing)

- * appliances with glass front ** Appliances with metal front




ESW 6114, ESW 6214 with DGC 6500/6600/6800 (Installation drawing)

- * appliances with glass front ** Appliances with metal front



ESW 6114, ESW 6214 (Installation drawing)

- * appliances with glass front ** Appliances with metal front



ESW 6114, ESW 6214 with DGC 6300/6400 (Installation drawing) $\,$

- * Appliances with glass front ** Appliances with metal front